EWRC 300/500/5000 NT

Hardware Guide





Legal Information

The information provided in this document contains general descriptions, technical characteristics and/ or recommendations related to products/solutions.

This document is not intended as a substitute for a detailed study or operational and site-specific development or schematic plan. It is not to be used for determining suitability or reliability of the products/solutions for specific user applications. It is the duty of any such user to perform or have any professional expert of its choice (integrator, specifier or the like) perform the appropriate and comprehensive risk analysis, evaluation and testing of the products/solutions with respect to the relevant specific application or use thereof.

The Schneider Electric brand and any trademarks of Schneider Electric SE and its subsidiaries referred to in this document are the property of Schneider Electric SE or its subsidiaries. All other brands may be trademarks of their respective owner.

This document and its content are protected under applicable copyright laws and provided for informative use only. No part of this document may be reproduced or transmitted in any form or by any means (electronic, mechanical, photocopying, recording, or otherwise), for any purpose, without the prior written permission of Schneider Electric.

Schneider Electric does not grant any right or license for commercial use of the document or its content, except for a non-exclusive and personal license to consult it on an "as is" basis.

Schneider Electric reserves the right to make changes or updates with respect to or in the content of this document or the format thereof, at any time without notice.

To the extent permitted by applicable law, no responsibility or liability is assumed by Schneider Electric and its subsidiaries for any errors or omissions in the informational content of this document, as well as any non-intended use or misuse of the content thereof.

CONTENTS

1.	INTRODUCTION	11
	1.1. GENERAL DESCRIPTION	11
	1.2. MODELS	11
2.	TECHNICAL SPECIFICATIONS	12
	2.1. TECHNICAL DATA	
	(EN 60730-2-9:2010, EN 61439-1:2011 / 61439-2:2011 / EN 60204-1:2006)	
	2.2. ELECTRICAL SPECIFICATIONS	
	2.3. FURTHER INFORMATION	13
	2.3.1. INPUT CHARACTERISTICS	
	2.3.2. OUTPUT CHARACTERISTICS	
	2.3.3. MECHANICAL CHARACTERISTICS	14
3.	MECHANICAL INSTALLATION	15
	3.5. INSTALLATION PROCEDURE	17
4.	ELECTRICAL CONNECTIONS	21
	4.1. WIRING BEST PRACTICES	
	4.1.1. WIRING GUIDELINES	
	4.1.2. RULES FOR SCREW-TYPE TERMINAL BOARDS	23
	4.1.3. ANALOGUE INPUTS-PROBES	24
	4.1.4. SERIAL CONNECTIONS	25
	4.1.5. RS-485 CONNECTION	25
	4.1.6. TTL CONNECTION	
	4.1.7. TERMINALS	
	4.2. WIRING DIAGRAM FOR MODELS WITH MAGNETOTHERMAL SWITCH INSTALLED	
	4.2.1. TERMINALS	27
5.	USER AND START-UP INTERFACE	28
	5.1. DISPLAY	28
	5.1.1. KEYS	28
	5.1.2. DISPLAY MEANING	29
	5.1.3. CONNECTION TO HACCP MODULE	
	5.1.4. ICONS	
	5.1.5. PRELIMINARY CONFIGURATIONS	
	5.1.6. OPERATION IN DEFAULT CONFIGURATION	
	5.1.7. NAVIGATION	
	5.1.9. PASSWORDS	
	5.1.10. SETPOINT PROGRAMMING	
	5.1.11. VIEWING PROBE VALUES	
	5.1.12. HOW TO MODIFY THE DATE AND TIME	
	5.1.13. DISPLAYING ALARMS	38

	5.1.14. SYSTEM ALARMS EXAMPLE	39
	5.1.15. MODIFYING A PARAMETER	40
6.	FUNCTIONS AND REGULATORS	42
	6.1. SETTINGS	
	6.1.1. PROBE SETTING AND CALIBRATION	
	6.1.2. DISPLAY SETTINGS	42
	6.2. FUNCTIONS	43
	6.2.1. UPLOAD, DOWNLOAD, FORMAT	43
	6.2.2. UNICARD	44
	6.3. BOOT LOADER FIRMWARE	45
	6.4. COMPRESSOR	46
	6.4.1. COMPRESSOR CONFIGURATION	46
	6.4.2. SECOND COMPRESSOR CONFIGURATION	46
	6.4.3. COMPRESSOR OPERATING CONDITIONS	46
	6.5. COMPRESSOR/GENERAL PROTECTIONS	47
	6.5.1. COMPRESSOR SAFETY TIMINGS	48
	6.6. DEFROST/DRIPPING	49
	6.6.1. DEFROST TYPE AND ACTIVATION	49
	6.6.2. AUTOMATIC DEFROSTING	
	6.6.3. MANUAL DEFROST	
	6.6.4. EXTERNAL DEFROST	
	6.6.5. DEFROST WITH REMOTE START/STOP	
	6.7. DEFROST MODE	
	6.7.1. DEFROST WITH ELECTRIC HEATERS	
	6.7.2. INVERSE DEFROST	
	6.7.3. DOUBLE EVAPORATOR DEFROST	
	6.8. EVAPORATOR FANS	
	6.8.1. EVAPORATOR FAN OPERATING CONDITIONS	
	6.8.2. FAN OPERATION IN TEMPERATURE CONTROL MODE	
	6.8.3. FAN OPERATION IN DUTY-CYCLE MODE	
	6.8.4. FAN OPERATION IN DEFROST	
	6.8.6. POST-VENTILATION	
	6.9. DEEP COOLING CYCLE - DCC	
	6.10. PREHEAT	
	6.11. PRESSURE SWITCH	
	6.11.1. AUXILIARY OUTPUT (AUX/LIGHT)	
	6.13. DEMISTING HEATERS (FRAME HEATERS)	
	6.14. CONDENSER FANS	
	6.15. STAND-BY	69

	6.16. PUMP DOWN	69
	6.16.1. SERVICE STOPPAGE	69
7.	PARAMETERS	70
	7.1. HOW TO MODIFY THE USER PARAMETERS	70
	7.2. HOW TO EDIT THE INSTALLER PARAMETERS	70
	7.3. PARAMETER TABLE	
	7.3.1. PARAMETER H60	
8.	ALARMS	82
	8.1. ALARMS AND SIGNALS TABLE	_
	8.2. ALARM CAUSE/EFFECT TABLE	83
	8.3. DESCRIPTION OF ALARMS	
	8.3.1. PROBE ALARM	
	8.3.2. MINIMUM AND MAXIMUM TEMPERATURE ALARM	86
	8.3.3. END OF DEFROST DUE TO TIMEOUT ALARM	88
	8.3.4. EXTERNAL ALARM	88
	8.3.5. DOOR OPEN ALARM	
	8.3.6. PRESSURE SWITCH INPUT ALARM	
	8.3.7. PANIC ALARM	
	8.3.8. LEAK DETECTOR ALARM	91
9.	MODBUS MSK 554 /812 FUNCTIONS AND RESOURCES	92
	9.3.1. DATA FORMAT (RTU)	
	9.3.2. NETWORK	
	9.3.3. MODBUS COMMANDS AVAILBLE AND DATA AREAS	
	9.3.4. ADDRESS CONFIGURATION	
	9.3.5. PARAMETER VISIBILITY AND VALUES	
	9.3.6. MODBUS TABLES	
	9.3.7. PARAMETER/VISIBILITY TABLE	
	9.3.8. PARAMETER/VISBILITY H60 TABLE	
	9.3.10. RESOURCES TABLE	
40	D. ADVANCED FUNCTIONS - NIGHT AND DAY	
10		
	10.1. DAY/NIGHT REGULATOR OPERATION	
	10.2. OPERATION WITH DEFROST GROUP	
	10.4. OPENING FOLDER NAD - DAY/NIGHT	
11	1. ADVANCED FUNCTIONS - HACCP	
	11.1. DISPLAYING HACCP ALARMS	109

SAFETY INFORMATION

Important information

Read these instructions carefully and visually inspect the equipment to familiarise yourself with the device before attempting to install it, put it into operation, overhaul or service it. The following warning messages may appear anywhere in this documentation or on the equipment to warn of potential dangers or to call attention to information that can clarify or simplify a procedure.



The addition of this symbol to a 'Danger' or 'Warning' safety label indicates that an electrical hazard exists which will result in personal injury if the instructions are not followed.



This is the safety warning symbol. It is used to warn the user of the potential dangers of personal injury. Observe all the safety warnings that follow this symbol to avoid the risk of serious injury or death.

A DANGER

DANGER indicates a dangerous situation that, unless avoided, will result in death or serious injury.

WARNING

WARNING indicates a potentially dangerous situation which, if not avoided, could result in death or serious injury.

A CAUTION

CAUTION indicates a potentially dangerous situation which, if not avoided, could result in minor or moderate injury.

NOTICE

NOTICE used in reference to procedures not associated with physical injuries.

PLEASE NOTE

Electrical equipment should be installed, operated, serviced, and maintained only by qualified personnel.

No responsibility is assumed by Schneider Electric and Eliwell for any consequences arising out of the use of this material. A qualified person is one who has skills and knowledge related to the construction and operation of electrical equipment and its installation, and has received safety training to recognize and avoid the hazards involved.

Personnel qualification

Only personnel with suitable training and an in-depth knowledge and understanding of the contents of this manual and any other documentation relevant to the product are authorized to work on and with this product. Qualified personnel must be capable of identifying any dangers which may arise from the parameterization or changing of parameter values, and from the use of mechanical, electric and electronic equipment in general.

Plus, they must be familiar with the personal safety laws, provisions and regulations which must be observed during system

Permitted use

The device must be installed and used in accordance with the instructions provided. In particular, parts carrying dangerous voltages must not be accessible under normal conditions.

It must be adequately protected from water and dust with regard to the application, and must only be accessible using tools or a keyed locking mechanism (with the exception of the front panel).

The device is suitable for use in household refrigeration appliances and/or similar equipment and has been tested in accordance with the harmonized European reference standards.

Prohibited use

Any use other than that expressly permitted is prohibited.

The relay contacts provided are mechanical and subject to failure; any protection devices required by product standards, or suggested by good practice in view of obvious safety requirements, must be installed externally of the device.

Liability and residual risks

The liability of Schneider Electric and Eliwell is limited to the correct and professional use of the product according to the directives referred to herein and in the other supporting documents, and does not cover any damage (including but not limited to) the following causes:

- unspecified installation/use and, in particular, in contravention of the safety requirements of the legislation in force in the country of installation and/or specified in this document;
- use on equipment which does not provide adequate protection against electrocution, water and dust in the actual installation conditions;
- · use on devices which allow access to dangerous parts without the aid of a keyed or tooled locking mechanism;
- tampering with and/or modification of the product;
- · installation/use on equipment that does not comply with the regulations in force in the country of installation.

Disposal



The equipment (or product) must be subjected to separate waste collection in compliance with the local legislation on waste disposal.

Date of production

The date of production is shown on the device label, indicating the week and year of production (WW-YY).

ABOUT THE DOCUMENT

Document Scope

The EWRC 300/500/5000 NT Hardware Guide by Eliwell provides detailed instructions for installation, configuration, and operation of cold room controllers. It outlines model variants, technical specifications, wiring diagrams, and user interface functions. The document explains how to set parameters for compressors, fans, defrost cycles, and auxiliary outputs. It includes guidance on using UNICARD for firmware updates and parameter transfer, and describes Modbus communication setup. The manual also covers advanced features like Night & Day scheduling, display settings, and probe calibration, help ensuring optimal performance and adaptability across refrigeration applications.

NOTE: Read and understand this document and all related documents, before installing, operating, or maintaining your device.

Validity Note

The characteristics of the products described in this document are intended to match the characteristics that are available on www.eliwell.com. As part of our corporate strategy for constant improvement, we may revise the content over time to enhance clarity and accuracy. If you see a difference between the characteristics in this document and the characteristics on www.eliwell.com, consider www.eliwell.com to contain the latest information.

Product related information

A A DANGER

HAZARD OF ELECTRIC SHOCK, EXPLOSION OR ARC FLASH

- Disconnect all power from all equipment including connected devices prior to removing any covers or doors, or installing or removing any accessories, hardware, cables or wires.
- Always use a properly rated voltage sensing device to confirm the power is off where and when indicated.
- · Before powering the device back up, fit back and fix all the covers, hardware components and wiring.
- · Check the earthing connections on all earthed devices.
- · Use only the specified voltage when operating this equipment and any associated products.
- · Comply with all standards regarding accident protection and local applicable safety directives.

Failure to follow these instructions will result in death or serious injury.

A A DANGER

HAZARD OF OVERHEATING AND/OR FIRE

- Do not use with loads other than those indicated in the technical specification.
- · Do not exceed the maximum permitted current; for higher loads, use a meter with sufficient power capacity.

Failure to follow these instructions will result in death or serious injury.

This equipment is designed to operate outside all hazardous locations and is not to be used in applications which generate (or could potentially generate) hazardous environments. Install this equipment only in areas and applications known to be free from dangerous atmospheres at all times.

A DANGER

POTENTIAL FOR EXPLOSION

- · Install and use this equipment in non-hazardous locations only.
- Do not install or use this equipment in applications which could generate hazardous atmospheres, such as applications which use flammable refrigerants.

Failure to follow these instructions will result in death or serious injury.

For information regarding the use of control equipment in applications capable of generating hazardous materials, please contact the relevant national regulatory bodies or certifying authorities.

AWARNING

POTENTIAL OF OVERHEATING AND/OR FIRE

Verify that your application has not been designed with device outputs connected directly to devices generating a frequently operated capacitive load ⁽¹⁾.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

(1) Even if your application not apply a frequently operated capacitive load on the relay, capacitive loads will reduce the life of any electromechanical relay, and installation of a contactor or an external relay, that is sized and maintained according the dimensions and characteristics of the capacitive load, will help minimize the consequence of relay degradation.

AWARNING

UNINTENDED EQUIPMENT OPERATION

- The equipment signal cables (probes, digital inputs, communication, and the relative power supplies) must be routed separately from the power cables.
- Every end application of this device must be tested individually and completely in order to check its proper operation before putting it in service.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

HACCP Module - RCN • • • • • • • • MODELS

NOTICE

INOPERABLE EQUIPMENT

For TTL serial line connection, use cables no longer than 1 m (3.28 ft).

Failure to follow these instructions can result in equipment damage.

NOTE. For information on the cables to be used with the HACCP Module, contact your local Eliwell representative.

General Cybersecurity Information

In recent years, the growing number of networked machines and production plants has seen a corresponding increase in the potential for cyber threats, such as unauthorized access, data breaches, and operational disruptions. You must, therefore, consider all possible cybersecurity measures to help protect assets and systems against such threats.

To help keep your Schneider Electric products secure and protected, it is in your best interest to implement the cybersecurity best practices as described in the Recommended Cybersecurity Best Practices document.

Schneider Electric provides additional information and assistance:

- Subscribe to the Schneider Electric security newsletter.
- Visit the Cybersecurity Support Portal to:
 - · Find Security Notifications
 - Report vulnerabilities and incidents
- Visit the Schneider Electric Cybersecurity and Data Protection Posture to:
 - Access the cybersecurity posture
 - · Learn more about cybersecurity in the cybersecurity academy
 - · Explore the cybersecurity services from Schneider Electric

Environmental Data

For product compliance and environmental information refer to the Schneider Electric Environmental Data Program.

Languages available for this document

This document is available in the following languages:

- Italian (9MA00258)
- English (9MA10258)
- Spanish (9MA30258)
- German (9MA50258)
- French (9MA20258)
- Brasilian Portuguese (9MAN0258)
- Polish (9MAF0258)
- Russian (9MAA0258)
- Greek (9MAI0258)

Related Documents

Title of documentation	Reference number		
Cybersecurity Best Practices	Refer to "General Cybersecurity Information" page 8		
EWRC 300/500/500 Quick Start Guide	9IS54389		

To find documents online, visit the Eliwell website (www.eliwell.com).

Terminology Derived from Standards

The technical terms, terminology, symbols and the corresponding descriptions in this manual, or that appear in or on the products themselves, are generally derived from the terms or definitions of international standards. In the area of functional safety systems, drives and general automation, this may include, but is not limited to, terms such as safety, safety function, safe state, fault, fault reset, malfunction, failure, error, error message, dangerous, etc.

Information on Non-Inclusive Terminology

As part of a group of responsible, inclusive companies, we are updating our communications and products that contain non-inclusive terminology. Until we complete this process, however, our content may still contain standardized industry terms that may be deemed inappropriate by our customers.

1.1. GENERAL DESCRIPTION

The **Coldface EWRC 300/500/5000 NT** series controls the temperature of a static or ventilated cold room. The instrument controls positive or negative cold rooms and is capable of managing a double evaporator and condenser fan.

Coldface has 3 or 5 configurable relays, depending on the model, and 2(3) configurable digital inputs for door switches or other devices. Models are available with clock with yearly calendar and HACCP event logging.

The instrument can be connected to Televis System / Modbus via the RS-485 plug-in module (optional).

The container lets you install one or more electromechanical devices, depending on the model.

1.2. MODELS

- EWRC 300 NT Versions with 3 configurable relays for controlling all the accessory loads in the room.
- EWRC 500 NT Versions with 5 configurable relays for controlling all the accessory loads in the room.
- EWRC 500 NT HACCP Versions with 5 configurable relays for controlling all the accessory loads in the room, HACCP function with clock and yearly calendar.
- **EWRC 500 NT 4DIN** Versions with 5 configurable relays for controlling all the accessory loads in the room, plus door for installation of magnetothermal switch or accessories on a DIN rail.
- EWRC 500 NT 4DIN HACCP Versions with 5 configurable relays for controlling all the accessory loads in the room, HACCP function with clock and yearly calendar, plus door for installation of magnetothermal switch or accessories on a DIN rail.
- **EWRC 500 NT BREAKER** Versions with 5 configurable relays for controlling all the accessory loads in the room, plus door and magnetothermal switch installed.
- **EWRC 500 NT 4DIN BREAKER HACCP** Versions with 5 configurable relays for controlling all the accessory loads in the room, HACCP function with clock and yearly calendar, plus door and magnetothermal switch installed.
- **EWRC 5000 NT HACCP** Version with larger container, with 5 configurable relays for controlling all the accessory loads in the room, HACCP function with clock and yearly calendar, plus door for installation of components on a DIN rail.

2.1. TECHNICAL DATA (EN 60730-2-9:2010, EN 61439-1:2011 / 61439-2:2011 / EN 60204-1:2006)

Front panel protection rating IP65

Classification: Electronic automatic control device (not safety device) for stand-alone

installation

Installation: wall
Type of action: 1.B
Pollution class: 2

Panel use: Internal use
Panel type: Fixed panel
Maximum installation site altitude: 2000 m (2187 yd)
Weight: < 2 kg (< 4.41 lb)

Material class: IIIa
Over-voltage category: II

Nominal pulse voltage: 2500 Vac

Operating temperature: -5...50°C (23°F...122°F) (EN 60730-2-9:2010)

Storage temperature: -20...85°C (-20°F...185°F)

-20...70 °C (-20 °F...158 °F) ⁽¹⁾ 10...90% non-condensing

Operating humidity: 10...90% non-condensing Storage humidity: 10...90% non-condensing Power supply: 230 Vac ±10 % 50/60 Hz

Power consumption: 11 VA max

Magnetothermal switch: **EWRC 500 BREAKER**: Two-pole (2P)

Control: EWRC NT electronic controller

Connection: device on external flexible cable, Y type connection

Digital outputs (relay): refer to the label on the device

Fire resistance category: D
Software class: A

Ball test temperature: 100°C (212°F)

Clock backup: Up to four days in the absence of an external power supply.

(HACCP models only)

2.2. ELECTRICAL SPECIFICATIONS

Rated voltage (Un):

Rated operating voltage (Ue):

Rated insulation voltage (Ui):

230 Vac

230 Vac

230 Vac

Rated impulse withstand voltage (Uimp): **EWRC 500 BREAKER** (1): 4 kV (EN 61439-2:2011) Rated panel current (InA): **EWRC 500 BREAKER** (1): 16 A (EN 61439-2:2011) **EWRC 500 BREAKER** (1): 16 A (EN 61439-2:2011)

Conditioned short circuit current (Icc): < 4.5 kA Rated frequency (fn): 50/60 Hz

2.3. FURTHER INFORMATION

2.3.1. INPUT CHARACTERISTICS

Measurement range: NTC: -50.0...110°C (-58°F...230°F); (on 3-digit display with +/- sign)

PTC: -55.0...150°C (-67°F...302°F); (on 3-digit display with +/- sign)

Accuracy: better than 0.5% integral scale + 1 digit

Resolution: 0.1°C (0.1°F)

Buzzer: only on models where this is provided Analogue inputs: 3(2) configurable NTC/PTC inputs

Digital inputs: 2(3) multi-function, voltage-free digital inputs (DI)

2.3.2. OUTPUT CHARACTERISTICS

RELAY OUTPUTS								
MODEL EWRC 300 NT			EWRC 500/5000 NT		EWRC 500 NT			
			RCS•U•	•••••				
			RCA•U•	•••••	RCS•P•	•••••		
0005	RCS•H•	•••••	RCH300	•••••	RCA•P•	•••••		
CODE	RCNS•H	•••••	RCNS•U	•••••	RCNS•P	•••••		
			RCNA•U	•••••	RCNA•P•••••			
			RCNH30	0•••••				
OTANDADD	EN60730	UL60730	EN60730	UL60730	EN60730	UL60730		
STANDARD	max 250 Vac	max 240 Vac	max 250 Vac	max 240 Vac	max 250 Vac	max 240 Vac		
OUT1	12(8) A	12FLA - 72LRA	12(8) A	12FLA - 72LRA	12(8) A	12FLA - 72LRA		
OUT2	8 A	8FLA - 48LRA	8 A	8FLA - 48LRA	8 A	8FLA - 48LRA		
ОПТЗ	8(4) A	8A resistive 4.9FLA - 29.4LRA	8(4) A	8 A resistive 4.9FLA - 29.4LRA	12(8) A	12FLA - 72LRA		
OUT4	-	-	8 A	8FLA - 48LRA	8 A	8FLA - 48LRA		
OUT5	-	-	NO 8(4) A, NC 6(3) A	NO 8 A, NC 6 A resistive NO 4.9FLA - 29.4LRA	NO 8(4) A, NC 6(3) A	NO 8 A, NC 6 A resistive NO 4.9FLA - 29.4LRA		
NOTE	Maximum common flow rate 16 A for models EWRC500 BREAKER: RCA•••S••••• / RCA•••R••••• RCNA•••S••••• / RCNA•••R••••• Maximum common flow rate 18 A for all other models							

2.3.3. MECHANICAL CHARACTERISTICS

Casing: PC+ABS

Dimensions: EWRC 300/500

front panel 213 x 318 mm, depth 102 mm

EWRC 500 BREAKER

front panel 221 x 318 mm, depth 107 mm

EWRC 5000

front panel 420 x 360 mm, depth 147 mm

Terminals: screw

See "4.1.2. Rules for screw-type terminal boards" page 23

Connectors: TTL for UNICARD / Copy Card / Device Manager connection (via DMI)

Humidity: Operation / Storage: 10...90% RH (non-condensing)

NOTE: The technical specifications stated in this document regarding the measurement (range, accuracy, resolution, etc.) refer strictly to the instrument and not to any accessories provided, such as the probes.

3.1. Before starting

Before starting to install your system, read this chapter carefully. Caution must be exercised concerning compliance with all safety information, other electrical requirements or laws which may apply to your machine or process when using this equipment.

A WARNING

REGULATORY INCOMPATIBILITY

Make sure that all equipment used and the systems designed comply with all applicable local, regional and national laws.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

3.2. Disconnection from the power supply

A A DANGER

HAZARD OF ELECTRIC SHOCK, EXPLOSION OR ARC FLASH

- Disconnect all power from all equipment including connected devices prior to removing any covers or doors, or installing or removing any accessories, hardware, cables or wires.
- · Always use a properly rated voltage sensing device to confirm the power is off where and when indicated.
- · Before powering the device back up, fit back and fix all the covers, hardware components and wiring.
- · Check the earthing connections on all earthed devices.
- · Use only the specified voltage when operating this equipment and any associated products.
- · Comply with all standards regarding accident protection and local applicable safety directives.

Failure to follow these instructions will result in death or serious injury.

3.3. Operating environment

Flammable refrigerant gases

This equipment is designed to operate outside all hazardous locations and is not to be used in applications which generate (or could potentially generate) hazardous environments. Install this equipment only in areas and applications known to be free from dangerous atmospheres at all times.

A DANGER

POTENTIAL FOR EXPLOSION

- · Install and use this equipment in non-hazardous locations only.
- Do not install or use this equipment in applications which could generate hazardous atmospheres, such as applications which use flammable refrigerants.

Failure to follow these instructions will result in death or serious injury.

For information regarding the use of control equipment in applications capable of generating hazardous materials, please contact the relevant national regulatory bodies or certifying authorities.

A WARNING

UNINTENDED EQUIPMENT OPERATION

Install and use the equipment in compliance with the conditions described in the Technical Specifications chapter.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

3.4. Comments concerning installation

WARNING

UNINTENDED EQUIPMENT OPERATION

- · Use appropriate safety interlocks where personnel and/or equipment hazards exist.
- · Do not use this equipment in safety-critical machine functions.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

The devices are designed for wall mounting.

When handling the equipment, use caution to avoid damage caused by electrostatic discharge. In particular, the unshielded connectors and in certain cases the open circuit boards are vulnerable to electrostatic discharge.

A WARNING

UNINTENDED EQUIPMENT OPERATION DUE TO ELECTROSTATIC DISCHARGE

- · Keep the equipment in the protective packaging until ready for installation.
- The equipment must only be installed in type-approved casing and/or in points that prevent unauthorised access and provide protection from electrostatic discharge.
- When handling sensitive equipment, use an antistatic bracelet or equivalent earthed protective device against electrostatic discharge.
- Before handling the equipment, always discharge the static electricity from the body by touching an earthed surface or type-approved antistatic mat.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

HACCP Module - RCN ---- MODELS

NOTICE

INOPERABLE EQUIPMENT

For TTL serial line connection, use cables no longer than 1 m (3.28 ft).

Failure to follow these instructions can result in equipment damage.


NOTE. For information on the cables to be used with the HACCP Module, contact your local Eliwell representative.


3.5. INSTALLATION PROCEDURE

NOTE: procedural steps that are common to all models. ONLY the EWRC 5000 model is used as an example.


1) Remove the cover and drill the holes for the cable clamps (at least one for power cables and one for signalling cables) on the bottom of the panel.

NOTE: for the 300/500 models, use the drilling template provided.






2) Drill the wall fixing holes on the back of the panel, in the areas marked on the back.



Hinges are available for mounting on special compartments for opening the cover both right and left. Screw on the respective anchoring screws taking care that the hinges are fitted well and lie flush so that they do not interfere with the compression of the seal.

3) Optional. Fir the panel.

NOTE: on models 300/500 with front door two more DIN spaces can be created: open the door with both hands as shown in the figure, then remove the factory-fitted push-through tabs.



4) Optional. Install the plug-in RS-485 module for communication with the supervisor.

EWRC 5000 only:


- Remove the seven screws securing the plastic protecting the board.
- 2) Remove the protective element, then use a box cutter to remove the two terminal covers.
- Connect the RS-485 plug-in module (optional) using the specific spacers, then replace the cover and secure it using the screws.


NOTICE


INOPERABLE DEVICE

Fit the plug-in RS-485 module in the plug-in connector aligning the four posts with the holes in the control board.


Failure to follow these instructions can result in equipment damage.








Fix the back of the panel to the wall using four screws (not supplied) suited to the wall thickness.
NOTE: TDI20 screw caps (not provided) can be fitted to 300/500 models at the wall mounting points so that the IP rating is not altered.





AA DANGER

HAZARD OF ELECTRIC SHOCK, EXPLOSION OR ARC FLASH

For models with magnetothermal switch, before connecting make sure that switch is in the OFF position.

Failure to follow these instructions will result in death or serious injury.

6) Make the electrical connections referring to the wiring diagrams shown page 23 and page 27. Use suitable cable/pipe clamps.

NOTE: only models with magnetothermal switch. Connect the switch to the electronic board power supply using the accessory cable provided in the packaging.

7) Hinges are available for mounting on special compartments for opening the cover both right and left.


Screw on the respective anchoring screws taking care that the hinges are fitted well and lie flush so that they do not interfere with the compression of the seal. Fit the hinges to secure the cover.


EWRC 5000

Place the panel cover on the base making it stick to the perimeter seal. Then, while holding the cover in place, fit the two hinges provided into the corresponding holes and press them until you hear them click as they are locked into place.


EWRC 300/500

Fit the hinges provided into their housings on the right or left side of the panel and tighten the corresponding screws to secure them.





8) Close the cover and secure it with the screws provided.





AA DANGER


RISK OF ELECTRIC SHOCK, EXPLOSION OR EXPOSURE TO ACCESSIBLE PARTS

The final application must disallow access to parts at hazardous voltage, as the instrument offers no intrinsic protection against this risk.


Failure to follow these instructions will result in death or serious injury.

9) DIN rail-mounted models with window only. Close access to inside the panel from the front window using the dedicated DIN plugs.

For EWRC NT 500 models with the plastic knockout removed and no internal magnetothermal switch, the end user is responsible for ensuring that the open parts of the box are not accessible.



- **10)** EWRC 5000 only. Fit the door (a): align the front door with the two hooks at the bottom of the panel and push it towards the right until you hear it click as it locks into place.
- 11) Close the door (b)



A WARNING

UNINTENDED EQUIPMENT OPERATION

- · Place the devices dissipating the most heat in the top of the cabinet and ensure suitable ventilation.
- · Do not place this equipment near or above any devices which could cause overheating.
- Install the device in a point that guarantees the minimum distances from all structures and adjacent equipment as indicated in this document.
- · Install all equipment in conformity with the technical specifications given in the respective documentation.

Failure to follow these instructions can result in death, serious injury, or equipment damage.




Fig. 1. Distance valid for all models

4.1. WIRING BEST PRACTICES

The following information describes the guidelines for wiring and the associated best practices to follow when using the device

A DANGER

HAZARD OF ELECTRIC SHOCK, EXPLOSION OR ARC FLASH

- Disconnect all power from all equipment including connected devices prior to removing any covers or doors, or installing or removing any accessories, hardware, cables or wires.
- · Always use a properly rated voltage sensing device to confirm the power is off where and when indicated.
- · Before powering the device back up, fit back and fix all the covers, hardware components and wiring.
- · Check the earthing connections on all earthed devices.
- Use only the specified voltage when operating this equipment and any associated products.
- · Comply with all standards regarding accident protection and local applicable safety directives.

Failure to follow these instructions will result in death or serious injury.

AADANGER

HAZARD OF OVERHEATING AND/OR FIRE

- Do not use with loads other than those indicated in the technical specification.
- · Do not exceed the maximum permitted current; for higher loads, use a meter with sufficient power capacity.

Failure to follow these instructions will result in death or serious injury.

This equipment is designed to operate outside all hazardous locations and is not to be used in applications which generate (or could potentially generate) hazardous environments. Install this equipment only in areas and applications known to be free from dangerous atmospheres at all times.

A DANGER

POTENTIAL FOR EXPLOSION

- · Install and use this equipment in non-hazardous locations only.
- Do not install or use this equipment in applications which could generate hazardous atmospheres, such as applications which use flammable refrigerants.

Failure to follow these instructions will result in death or serious injury.

For information regarding the use of control equipment in applications capable of generating hazardous materials, please contact the relevant national regulatory bodies or certifying authorities.

4.1.1. Wiring guidelines

The following regulations must be complied with for wiring:

- Make connections as short as possible and do not wind them around electrically connected parts.
- · Check that the operating conditions and surroundings comply with the specification values.
- Use wires of the correct diameter and suited to the voltage and current requirements.
- · Use copper conductors (obligatory).

A WARNING

UNINTENDED EQUIPMENT OPERATION

- The equipment signal cables (probes, digital inputs, communication, and the relative power supplies) must be laid separately from the power cables.
- Every end application of this device must be tested individually and completely in order to check its proper operation before putting it in service.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

HACCP Module - RCN ---- MODELS

NOTICE

INOPERABLE EQUIPMENT

For TTL serial line connection, use cables no longer than 1 m (3.28 ft).

Failure to follow these instructions can result in equipment damage.

NOTE. For information on the cables to be used with the HACCP Module, contact your local Eliwell representative.

4.1.2. Rules for screw-type terminal boards

The table below illustrates the types of cables and wire sections for a screw-type terminal board with 5.08 (0.197 in.) spacing:




Fig. 2. Spacing 5.08 mm (0.197 in.)

The table below illustrates the types of cables and wire sections for a screw-type terminal board with 7.62 (0.30 in.) spacing:




Fig. 3. Spacing 7.62 mm (0.3 in.)

The table below illustrates the types of cables and wire sections for the magnetothermal switch:




Fig. 4. Cable types and tightening torque for the magnetothermal switch

A A DANGER

LOOSE WIRING CAN RESULT IN ELECTRIC SHOCK

Tighten the connections in compliance with the technical specifications for pairs.

Failure to follow these instructions will result in death or serious injury.

Specific considerations for handling

When handling the equipment, use caution to avoid damage caused by electrostatic discharge. In particular, the unshielded connectors and in certain cases the open circuit boards are vulnerable to electrostatic discharge.

WARNING

UNINTENDED EQUIPMENT OPERATION DUE TO ELECTROSTATIC DISCHARGE

- · Keep the equipment in the protective packaging until ready for installation.
- The equipment must only be installed in type-approved casing and/or in points that prevent unauthorised access and provide protection from electrostatic discharge.
- When handling sensitive equipment, use an antistatic bracelet or equivalent earthed protective device against electrostatic discharge.
- Before handling the equipment, always discharge the static electricity from the body by touching an earthed surface or type-approved antistatic mat.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

4.1.3. Analogue Inputs-Probes

A WARNING

UNINTENDED EQUIPMENT OPERATION DUE TO CONNECTIONS

• The equipment signal cables (probes, digital inputs, communication, and the relative power supplies) must be laid separately from the power cables.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

NOTICE

INOPERABLE DEVICE

Before switching on the electrical power, check all the wiring connections.

Failure to follow these instructions can result in equipment damage.

NOTE: The NTC temperature probes do not feature any connection polarity and can be extended using normal bipolar cable.

4.1.4. Serial connections

The controller can be connected to Televis**System** / Modbus remote control systems by a direct RS-485 connection using the RS-485 optional plug-in module.

4.1.5. RS-485 connection

- Use a "twisted pair" shielded cable with two conductors with cross-section 0.5 mm² (AWG 20), plus sheath, such as, for example, a Belden cable version 3105A (typical impedance 120 Ω) with PVC sheath, rated capacity between conductors 36 pF/m, rated capacity between conductor and sheath 68 pF/m. Alternatively, use a "twisted pair" shielded cable with two conductors with cross-section 0.5 mm² (AWG 20), plus sheath, such as, for example, a Belden cable version 8762 with PVC sheath, rated capacity between conductors 89 pF/m, rated capacity between conductor and sheath 161 pF/m. For laying wires, comply with the indications given in standard EN 50174 on information technology wiring.
- Follow the applicable regulations for laying and connecting the cables. Extra care must be taken in separating data transmission circuits from power lines.
- The length of the RS-485 network which can be connected directly to the controller is 1200 m. This length can be extended and the number of devices for each channel increased using appropriate repeater modules.
- Input impedance: 1/8 unit load.
- · Single terminal board with 3 conductors: use all 3 conductors ("+" and "-" for the signal and "GND" for the braiding).
- Attach the 120 Ω 1/4W resistors between the "+" and "-" terminals on the interface and the last controller in each branch
 of the network.
- The RS-485 physical level can be used for Modbus SL communication
 Concurrent communication of different protocols on the same serial port is NOT permitted.

Pay special attention when connecting serial lines. Incorrect wiring may cause the equipment to stop working.

NOTICE

INOPERABLE DEVICE

Do not communicate simultaneously via Modbus and Televis protocols on the same serial port.

Failure to follow these instructions can result in equipment damage.

4.1.6. TTL connection

Use a 5-wire TTL cable up to 3 m (118 in.) in length.

An Eliwell-supplied TTL cable is recommended. Contact Eliwell Sales Office for item availability.

HACCP Module - RCN ----- MODELS

NOTICE


INOPERABLE EQUIPMENT

For TTL serial line connection, use cables no longer than 1 m (3.28 ft).

Failure to follow these instructions can result in equipment damage.

NOTE. For information on the cables to be used with the HACCP Module, contact your local Eliwell representative.


WIRING DIAGRAM



4.1.7. TERMINALS

TERMINALS							
1, 5, 8 GND			9, 10	LINE/NEUTRAL. Power supply			
2	2 Analogue input Pb1		11	NO OUT1			
3	Analogue input Pb2		12	NEUTRAL			
4	Analogue input Pb3 / Digital input DI3		13	NO OUT2			
6	Digital input DI2		14	NEUTRAL			
7	Digital input DI1		15	NO OUT3			
CARD	TTL for connection to HACCP Module (MODELLE RCN•••••••) / UNICARD / Copy Card / TelevisSystem		16	NEUTRAL			
RS-485	Plug-in module for connection to TelevisSystem / Modbus (optional)		17	NO OUT4			
			18	NEUTRAL			
			19	NC OUT5			
			20	OUT5 Common terminal			
			21	NO OUT5			

4.2. WIRING DIAGRAM FOR MODELS WITH MAGNETOTHERMAL SWITCH INSTALLED




4.2.1. TERMINALS

TERMINALS								
1, 5, 8	1, 5, 8 GND			LINE/NEUTRAL. Power supply				
2	Analogue input Pb1		11	NO OUT1				
3	3 Analogue input Pb2		12	NEUTRAL				
4	Analogue input Pb3 / Digital input DI3		13	NO OUT2				
6	Digital input DI2		14	NEUTRAL				
7	Digital input DI1		15	NO OUT3				
CARD	"4.2.1. TERMINALS" page 26		16	NEUTRAL				
RS-485	"4.2.1. TERMINALS" page 26		17	NO OUT4				
			18	NEUTRAL				
			19	NC OUT5				
			20	OUT5 Common terminal				
			21	NO OUT5				

5.1. DISPLAY

5.1.1. KEYS




No.	KEY	press and release	press and hold for about 3 seconds	NAVIGATION MENU	Notes
А	ESC Defrost	• Functions Menu	Manual defrost Return to Main Menu	• Output	Configurable - see parameter H33
В	▲ UP Alarms	Alarms Menu (always visible)	1	Scroll Increase values	HACCP alarms only on foreseen models and if present
С	SET	Display setpoint / probe values / time (Models with clock only)	Access Parameters menu	Confirm values Move right	Time only visible on models with clock
D	▼ DOWN AUX	system INFO See Technical Support	Activate auxiliary function	Scroll Decrease values	Configurable - see parameter H32
Е	ON/OFF	1	Switch On/Off device	1	Configurable - see parameter H34
F	LIGHT	Switch light On/Off	Switch light On/Off	1	Configurable - see parameter H35

5.1.2. DISPLAY MEANING


G	Н
3-FIGURE TOP DISPLAY plus the - sign	4-FIGURE BOTTOM DISPLAY
Display:	Display:
operating value	parameters value
parameters label	probe value
alarms, functions	function state
	HACCP models
if TOP display is	• time
blinking	
it means that the value of the BOTTOM Display	
can be modified	

5.1.3. CONNECTION TO HACCP Module



RCN•••••• models: when the HACCP Module is connected and the Bluetooth connection to the Eliwell Air App is active, the btL label appears on the TOP DISPLAY and the BOTTOM DISPLAY and icons are turned off.

5.1.4. ICONS



Icons have the following meaning:

No.	ICON	colour	description			
17	%RH	amber	not used			
18	TIME	amber	access in case of time display or editing			
19	DATA	amber	access in case of date display or editing			

Al	ICON 9	Colour	Dumor	OFF		
Alarms	ICON 7	ICON 8	Coloul	Buzzer	Icon	Buzzer
ALARM)	((•))	Red	See "8.2. ALARM CAUSE/EFFECT TABLE"		LE" page 83
PANIC	((!))	((•))	Red	₹ Ø		
LEAK DETECTOR	-\(\bar{\bar{\bar{\bar{\bar{\bar{\bar{	((•))	Red	√ 测	((°), ((°¶))	
PANIC + LEAK DETECTOR	(° <u>"</u> 3)	((•))	Red	√ 测		◆ 3D) (1)

(1) = As long as the Panic alarm persists it will not be possible to mute the buzzer from the keypad.

No.	Icon	colour	ON	BLINKING	OFF
1	POWER SUPPLY	green	Power supply ON	1	Power supply OFF
2	ENERGY SAVING	amber	Energy saving ON	1	Energy saving OFF
3	NIGHT & DAY	amber	Night & Day ON	1	Night & Day OFF
4	HACCP	amber	HACCP menu	1	1
5	DEEP COOLING (DCC)	amber	Drip cooling cycle ON	1	Drip cooling cycle OFF
6	PUMP DOWN	amber	Compressor Pump Down ON	I	Compressor Pump Down OFF
9	COMPRESSOR	amber	Compressor ON	Delay	Compressor OFF
10	DEFROST 1	amber	Defrost	Dripping	No defrost
11	EVAPORATOR FANS	amber	Fans ON	Forced ventilation	Fans OFF
12	DEFROST 2	amber	Defrost	Dripping	No defrost
13	HACCP ALARM	red	HACCP alarm	Not displayed	No alarm
14	AUXILIARY (AUX)	amber	AUX ON	1	AUX OFF
15	LIGHT	amber	Light ON	1	Light OFF
16	CONDENSER FANS	amber	Fans ON	1	Fans OFF
ON: function/alar	m ON; OFF: function/alarm OFF				

5.1.5. PRELIMINARY CONFIGURATIONS

After making the electrical connections, simply power up the device to start operation. At first start-up, Eliwell recommends that you:

- 1. make sure the instrument is powered (green POWER SUPPLY icon on)
- make sure the display is working: when the controller is powered up it performs a lamp test, during which time the display and icons will blink for several seconds to ensure that they all function correctly
- 3. make sure there are no active alarms (ALARM / HACCP ALARM icon off and labels E1, E2, E3 not displayed).
- 4. configure the main parameters listed in the USER menu to suit your requirements, as described below

5.1.6. OPERATION IN DEFAULT CONFIGURATION

The instrument is configured for negative cold. For positive cold, disable the evaporator probe Pb2 (set **H42**=n) and relay OUT3 (set **H23**=6) to prevent continuous ventilation.

COMPRESSOR

The compressor is active if the cold room temperature measured by Pb1 exceeds the value of SEt + **diF**. The compressor stops if the cold room temperature detected by Pb1 falls below the SEt value. The instrument includes compressor on/off protection.

DEFROST

Defrost is by means of electric heaters (parameter **dty** = 0) and the time counter is always active with the instrument switched on (**dCt**=1).

Manual defrost

Manual defrost is activated by pressing and holding the ESC key (A)

If conditions are not right for defrosting, (e.g. the evaporator probe temperature is higher than the defrosting end temperature) or parameter **OdO**≠0, the display will blink three times to indicate that the operation will not be performed.

Default Defrost settings

dit = 6 hours. interval between 2 defrost cycles

dSt = 6.0 °C. defrosting end temperature. set by Pb2

The Defrost cycle may terminate due to a timeout based on the parameter dEt (default 30 min).

EVAPORATOR FANS

The OUT3 relay is configured as the fan relay and is activated when required, according to the delay and parameter settings.

Default fan settings

dt = 0 min. dripping time

dFd = Y. Fans off during defrosting

LIGHT (EWRC 500/5000)


The light is activated by pressing and holding the LIGHT key (F)

As digital input DI1 is configured as door switch, relay OUT4 (light) is activated when the door is opened. The light also switches on with the instrument in stand-by.

ALARM relay (EWRC 500/5000)

Relay OUT5 is configured as alarm relay and is activated in the case of alarms, according to delays and parameter settings.

5.1.7. NAVIGATION



5.1.8. FUNCTIONS MENU AND KEY-ENABLED FUNCTIONS

The Functions menu is used to perform a number of manual functions such as putting the device into stand-by, clearing pressure switch interventions and clearing HACCP alarms, etc.

Access the Functions menu by pressing the ESC key.

The following table lists the functions, which are all OFF by default.

Display	Function	description
	Keypad lock	The UP/ESC/ON-OFF/LIGHT keys and the functions programmed via keys are locked The DOWN key may be used to view the Setpoint only; the value cannot be modified Only function visible if keypad locked (On)
rEd OFF	Disables HACCP alarm recording	Disables HACCP alarm recording
rPR OFF	Reset pressure switch alarm	Clears pressure switch alarm NOTE: the function reverts to OFF status when you exit the Functions Menu
rSE OFF	Reduced set	Reduced set
<u>-H[</u> []FF	Reset HACCP alarms	Clears HACCP alarms May be protected by Password PA3

All models have the **UP** key set to display the Alarms Menu.

All models also allow the setting of other keys to activate a specific function as identified by the client. The parameters for configuring the two keys are:

- H32 = DOWN key configuration
- H33 = ESC key configuration
- H34 = ON/OFF key configuration
- H35 = LIGHT key configuration

The values that can be set apply to these keys and the functions that can be activated are:

Value of H32/H33/H34/H35			
0 = disabled	10 = Activate / disable Frame Heater relay		
1 = defrost	11 = Enable/disable Night And Day functions		
2 = Auxiliary	12 = deep cooling cycle		
3 = Activate reduced set	13 = Clear voltage drop errors		
4 = Reset HACCP alarms	(Reset Power Failure)		
5 = Disable HACCP alarms	14 = Service stoppage		
6 = Light	15 = Activate economy set + Night And Day		
7 = Stand-by			
8 = NOT USED			
9 = Evaporator fans ON			

5.1.9. PASSWORDS

Password PA1 is disabled by default.

Password "PA1": allows access to User parameters.

To enable (PA1≠0): press and hold SET for more than 3 seconds. The label USr appears. Press SET again. Scroll through the parameters using UP and DOWN until you find label PA1, press SET to display its value, change it using UP and DOWN and save by pressing SET or ESC.

Example with password enabled (PA1≠0): it will be requested before access to the User parameters is granted.

Display	description
- 7.8 - 8.0	Press SET for 3 seconds
<u>15-</u> PRI	Label PA1 appears
PR	Press SET Use UP and DOWN keys to enter the password
PR1	In the example the password is 12 Press SET
d, F 2.0	User menu accessed The first User parameter appears If the value entered is incorrect, label PA1 will be shown again and the procedure must be repeated

Password "PA2": allows access to Installer parameters.

The example is the same. Note. Password PA2 is set by default to 15

Display	description
-¦7,8 -¦8.0	Press SET for 3 seconds
US- PRI	Label USr appears Use 'UP' and 'DOWN' to search for InS

Display	description
, <u>n</u> 5 PR2	Press SET
PR2	Use UP and DOWN keys to enter the password
PR2 (5	In the example the password is 15 Press SET
[Pr	Installer menu accessed the first CPr folder appears If the value entered is incorrect, label PA2 will be shown again and the procedure must be repeated

5.1.10. SETPOINT PROGRAMMING

By way of example, we will change the Setpoint value from -18.0 degrees centigrade to -20.0 degrees centigrade.

Display	description
- 7,8 - 8.0	Press and release the SET key
SEL -18.0	The top display will show SEt, the bottom display will indicate the current setpoint value Press and release the SET key once more
<u> 5EL</u> -20.0	The top display will show SEt blinking Use the UP & DOWN keys to adjust the setpoint value
-17.8	Press the ESC key several times to return to the normal display (or press the SET key to confirm, followed by ESC to exit) The new Setpoint value is saved and appears on the bottom display

5.1.11. VIEWING PROBE VALUES

Display	description
-17.8	Press and release the SET key
SEL -20.0	The top display will show SEt, the bottom display will indicate the current setpoint value Use the DOWN key to view the value of probe Pb1
<u>rtc</u> 5.28	The time is displayed in HACCP models
P5 {	Use the DOWN key again to view the value of probe Pb1
P62	Use the DOWN key again to view the value of probe Pb2
Pb3 -18.6	If H43 is not 0 (probe 3 present) Use the DOWN key again to view the value of probe Pb3
-17.8	Press the ESC key to return to the normal display Normal display

5.1.12. How to modify the date and time

Function only available in HACCP models

Display	description
-{7, <u>8</u> -20,0	Press and release the SET key
<u> 5EL</u> -20.0	The top display will show SEt, the bottom display will indicate the current setpoint value Use the DOWN key to display the time
r <u>tc</u> 5.28	The CLOCK icon will be on Press and release the SET key.
<u>rtc</u> 5.28	The CLOCK icon will be on The hour value will begin to blink Use the UP & DOWN keys to adjust the hour value
r tc 17.28	The CLOCK icon will be on Press and release the SET key
<u>rtc</u> 17.28	The CLOCK icon will be on The hour value has been changed The minute value begins to blink Use the UP & DOWN keys to adjust the hour value
r <u>tc</u> 31.05 r <u>tc</u> 2014	Repeat this procedure to adjust the date value (DAY.MONTH) and YEAR In this case the DATA icon (31) is on Press the ESC key several times to return to the normal display

5.1.13. Displaying Alarms

Display	description
- 7.8 - 8.0	Press and release the UP key. The top display will show ALr.
AL - AL - 545E	The bottom display will show a. nOnE if no alarms active b. SYSt if system alarms present
AL- HR[P	HACCP models ONLY The top display will show ALr. The bottom display will show HACP if HACCP alarms are present NOTE: parameter H50 must = 1

5.1.14. System Alarms example

- Let us suppose two alarms have occurred,
 one HIGH TEMPERATURE on the cold room probe
- one HIGH TEMPERATURE on probe 3 (parameter H43 different from 0)

Display	description
-17.8	Press and release the UP key.
<u> 71</u> r 545t	The top display will show ALr. The bottom display will indicate SYSt Press and release the SET key.
AL r HAI	The top display will show ALr. The bottom display will show HA1 HIGH TEMPERATURE alarm on the cold room probe Use the UP & DOWN keys to view other alarms, if present
RLr HR3	In the example, the bottom display will indicate HA3 HIGH TEMPERATURE alarm on probe 3 (see para. H43) Press the ESC key several times to return to the normal display

5.1.15. Modifying a parameter

The User parameters **USr** are not divided into subfolders.

They are always visible by default (access password PA1 is not enabled by default).

The same parameters are also visible in the respective folders 'Compressor', 'Fans', etc. within the Installer parameters menu **InS**. The password is enabled (PA2=15) by default.

NOTE: It is advisable to switch the device off and on again each time the configuration of the parameters is changed, so as to prevent malfunctions affecting the configuration and/or the current timings.

How to modify a user parameter

Instructions are provided below on how to modify a User parameter

The same procedure applies to Installer (inS) level parameters.

Let us take the dit parameter as our example.

There are no sub-folders at User level. At Installer level the parameter is in the folder containing **dEF** defrost parameters. We will now show how to change the value from 6 hours to 8 hours.

Display	description
-17.8	Press and hold the SET key for approx. 3 seconds
<u>15</u> -	The folder for USr parameters will appear Press and release the SET key. Press and release the SET key to access the first parameter
<u>d</u> , F 2.0	The first User parameter appears Use the UP & DOWN keys to find the parameter that you wish to modify
d, L 5	Press and release the SET key. The dit label will blink Use the UP & DOWN keys to adjust its value
d, L	Press and release the SET key to confirm the modification.

How to modify an Installer parameter

Instructions are provided below on how to modify the same User parameter but via the Installer menu Let us take the **dit** parameter as our example.

At Installer level the parameter is in the folder containing **dEF** defrost parameters.

We will now show how to change the value from 8 h to 6 h.

Display	description
-17.8 -20.0	Press and hold the SET key for approx. 3 seconds
<u>15</u> -	The folder for USr parameters will appear Use the UP & DOWN keys to search for the inS folder Press and release the SET key.
	Press and release the SET key to access the first parameter
[P- 	The first folder appears Use the UP & DOWN keys to search for the dEF folder
<u>d, t</u> 8	Press and release the SET key. The first parameter in the dEF folder will appear Use the UP & DOWN keys to find the parameter you want to change
<u>d</u> <u>t</u> 5	Press and release the SET key. The dit label will blink Use the UP & DOWN keys to adjust its value Press and release the SET key to confirm the modification.

6. FUNCTIONS AND REGULATORS

This chapter describes the various functions of the devices.

NOTE: some functions may not be available in certain models.

6.1. SETTINGS

6.1.1. PROBE SETTING AND CALIBRATION

EWRC 300/500/5000 NT have 3 configurable NTC/PTC inputs (Pb1...Pb3).

The temperature probes (Pb1...Pb3) must all be the same type and should be configured via parameter **H00**, visible at User level (**USr**) or inside folder **CnF**, Installer level (**inS**)

- H00 = 0 if using PTC probes
- H00 = 1 if using NTC probes (Default)

After installation, the values read by the probes can be corrected/calibrated using the following parameters:

- CA1: probe 1 offset. Positive or negative value to be added to the value read by Pb1 (Range: -30.0...30.0)
- CA2: probe 2 offset. Positive or negative value to be added to the value read by Pb2 (Range: -30.0...30.0)
- CA3: probe 3 offset. Positive or negative value to be added to the value read by Pb3 (Range: -30.0...30.0)

6.1.2. DISPLAY SETTINGS

At User level (**Usr**) or inside the **diS** folder at Installer level (**inS**) you will find the parameters used to set the temperature readout, decimal point usage, unit of measure and display during defrost.

• ndt: (USr/inS) enables/disables decimal point display

(with resolution of one-tenth of a degree; e.g.: 10.0°C)

Display with decimal point is only possible within the range of values from -99.9°C to 99.9°C

- ndt = n
 → displays read values without decimal point
- NOTE: enabling/disabling the decimal point only affects the on-screen display of values. The controller will continue to perform calculations with decimal point.
- ddL: (USr/inS) sets the type of display during and up to the end of defrost
 - ddL = 0 → displays the probe value (default)
 - ddL = 1 continues to display the value read by the probe at the start of defrosting
 - ddL = 2 → displays the fixed label dEF
- dro: (inS) sets temperature display to °C or °F.
 - dro = 0 → display in °C (default)
 - dro = 1 → display in °F
 - **NOTE**: switching between °C and °F DOES NOT modify the values of temperature parameters (e.g. setpoint=10°C becomes 10°F).

This means that the maximum and minimum limits of parameters as absolute values are the same for both units of measure and hence the ranges are different.

• ddd: (inS) establishes the value to be shown on the top display.

All other display and adjustment modes are the same.

- ddd = Set → displays the Setpoint value
- ddd = Pb1 → displays the values read by Pb1 (default)
- ddd = Pb2 → displays the values read by Pb2
- ddd = Pb3 → displays the values read by Pb3

6.2. FUNCTIONS

6.2.1. UPLOAD, DOWNLOAD, FORMAT

Description

The UNICARD / Copy Card must be connected to the (TTL serial port and allows the rapid programming of instrument parameters.

DOWNLOAD from reset operating mode: at power-on, if the UNICARD / Copy Card is inserted in the device, the controller automatically downloads data.

After connecting the UNICARD / Copy Card with the instrument switched off and on completion of the lamp test, one of the following labels will be displayed:

- · dLY if the operation was successful
- dLn if the operation was not successful

After about 5 seconds, the display will show the probe or set point value, depending on the default settings.

NOTE: once the download has been completed successfully, the controller will start to work with the new map loaded.

Operating mode: access "Installer" parameters by entering the password "PA2" if enabled (PA2≠0), scroll through the folders using UP & DOWN until the folder "FPr" appears. Select it using SET, scroll through the parameters using UP & DOWN and then select one of the functions by pressing SET:

- **UL** (Upload): With this function, the programming parameters are uploaded from the instrument to the card. If the operation is successful, the display will show "**y**", otherwise it will show "**n**".
- Fr (Format): This command is used to format the copy card (which is necessary when using the card for the first time).

NOTE: the use of the Fr parameter deletes all data present and this operation cannot be reversed.

• **Download**: Connect the UNICARD / Copy Card when the instrument is switched off. At power-on, data will automatically start downloading from the UNICARD / Copy Card to the instrument. At the end of the

lamp test, the display will show "dLy" if the operation was successful and "dLn" if not.

NOTE: before Uploading or Downloading a map, make sure that communication with the supervisor (PC with Televis, TelevisGo system, etc.) has been cut off.

This means you should make sure that the RS-485 is disconnected from the instrument or that Supervision system acquisitions have been stopped.

Parameters

The parameters that control this function are:

Label	Description
	Transfer of programming parameters from device to UNICARD / Copy Card
UL	COLDFACE → UNICARD / Copy Card
-11	Transfer of programming parameters from UNICARD / Copy Card to device
dL	UNICARD / Copy Card → COLDFACE
Fr	UNICARD / Copy Card formatting. Erases all data on the UNICARD/UNICARD / Copy Card


6.2.2. UNICARD

The Unicard lets you download/upload a parameter map from/to a controller, in the same way as the UNICARD / Copy Card. It is a versatile tool that also allows you to quickly and easily customise devices. It differs from the UNICARD / Copy Card in the following ways:


- 1) it can be connected to a computer via USB
- 2) it can be plugged into a USB socket or USB battery, to power the device directly during upload/download.

The UNICARD can be powered in the following ways:

A) Cabinet powered



B) Site powered



6.3. BOOT LOADER FIRMWARE

The device is equipped with a Boot Loader, so it is possible to update the Firmware directly on site. Updating may be carried out using UNICARD or UNICARD / Copy Card (UNICARD / Copy Card). Updating procedure:

- Connect the UNICARD/UNICARD / Copy Card equipped with the application;
- Power the device if it is off, otherwise switch it off and on again

NOTE: the UNICARD/UNICARD / Copy Card can be connected even with the instrument powered.

- · Wait until the LED for the UNICARD/UNICARD / Copy Card is blinking (operation in progress);
- The operation will be concluded when the LED for the UNICARD/UNICARD / Copy Card is:
 - **ON**: operation concluded correctly;
 - OFF: operation not performed (application not compatible...)

NOTE: the LED display is only provided for UNICARDS produced from week 18-12 onwards.

6.4. COMPRESSOR

The compressor is controlled by the device's relay. It will be switched on or off depending on:

- the temperature status readings from the cold room probe
- · the temperature control functions set
- · the defrost/dripping functions (see Defrost chapter)

6.4.1. Compressor configuration

See the wiring diagrams for details of how to connect the compressor to the device Relay polarity is fixed.

NOTE: you MUST check the Compressor → digital output (relay) association by setting parameter H2x accordingly.

NOTE: By default H21 = 1 (compressor)

6.4.2. Second compressor configuration

Coldface offers the option of using a second compressor

NOTE: you MUST check the Compressor 2 → digital output (relay) association by setting parameter **H2x** accordingly. Example **H25 = 10 (compressor 2).**

NOTE: to prevent the two compressors from starting up with an insufficient interval in between, an activation delay can be set for the second compressor using **dSC**.

6.4.3. Compressor operating conditions

Compressor operation

The regulator is active when:


- the device is ON
- there is not an alarm E1 indicating control probe fault
- · the time set in parameter OdO has elapsed
- · a defrost cycle is not underway (except in FREE mode)

(There is a fixed interval of one second between the request and activation of the relay)

The parameters that control this regulator are:

- · the setpoint that can be set via the keypad, with a range from minimum to maximum setpoint.
- · the differential

The diagram below indicates the compressor activation mode for cooling based on parameters **SEt** and **diF** > 0.



6.5. COMPRESSOR/GENERAL PROTECTIONS

Description

If the cold room probe is in error **E1** the output relay configured as compressor/general regulates in accordance with the times set in parameters **Ont** and **OFt**.

The first time to consider is Ont.

If Ont >0 the protection programmed in parameters

dOn-dOF-dbi (see safety compressor times).

NOTE: remember that parameter **OdO** inhibits the activation of all outputs commanding a relay for its entire duration (compressor/general, defrost, fans), excluding buzzers or alarm relays.

Operating conditions

The table below lists the ways the compressor relay output can be managed:


Ont	OFt	Compressor OUT
0	0	OFF
0	>0	OFF
>0	0	ON
>0	>0	Duty-cycle

If Ont > 0 and OFt = 0 the compressor regulator entrusts relay deactivation to the safety protection CAt.

If **Ont** > 0 and **OFt** > 0: the compressor regulator activates in operating cycle mode irrespective of the values read by the probes (cold room probe failure) and of requests from other loads (**Duty-cycle** mode).

If the cold room probe is working properly, Duty-cycle mode does **NOT** activate as it does not have priority over normal compressor regulator settings.

The following diagram shows the **Duty-cycle** operating mode, based on parameters **Ont** and **OFt > 0**:



6.5.1. Compressor safety timings

Compressor on-off operations must respect the safety times that you can set using the special parameters as described below.

The compressor icon will flash to indicate when a compressor activation request has been received but a safety protection exists.


A safety time (compressor On... Off safety time) regulated by the parameter **dOF** must be respected between a switch-off and switch-on of the same compressor. This waiting time also occurs at switch-on of the device.

A safety time regulated by the parameter **dbi**must be respected between one switch-on and the next.

The safety time set in parameter **dOn** must elapse between a compressor start-up request and actual start-up. Times set with parameters **dOn**, **dOF** and **dbi**, if active, are not accumulative but parallel.

The following diagram illustrates the operation of the compressor protection with parameters **dOn**, **dOF**, **dbi** set where:

IN Input status for compressor regulator.	
OUT	Output status for compressor regulator.



NOTE: See the chapter entitled Compressor Function During Defrost for other safety measures and compressor timings.

Maximum timer period

The maximum compressor activation time before its deactivation can be set via the parameter **CAt**.

Minimum timer period

The minimum compressor activation time before its deactivation can be set via the parameter Cit.

User parameters

The parameters that manage this regulator are:

Label	Description		
Ont	Compressor output ON time in the event of a faulty Pb1 probe		
OFt	Compressor output OFF time in the event of a faulty Pb1 probe		
dOn	Compressor output activation delay from request		
dOF	Compressor output activation delay from shutdown		
dbi	Delay between two consecutive starts of the compressor output		
OdO	Output activation delay from power-on		
Cit	Minimum compressor output activation time		
CAt	Maximum compressor output activation time		

6.6. DEFROST/DRIPPING

6.6.1. Defrost type and activation

Defrost is used to stop ice from forming on the surface of the evaporator. Its **activation** can be:

- automatic, in one of the following modes selected via dCt:
 - · compressor hours (Digifrost);
 - · device hours:
 - · compressor stop;
 - via clock (see corresponding paragraph under RTC);
- via digital input (DI);
- · via key;
- · remotely.

The type of defrost can be selected via the parameter dty and can be:

- 1. defrost with electric heaters;
- 2. inverse;
- 3. FREE

Dripping

On completion of defrost, given that there will be water on the evaporator, it is better not to start "cooling" right away as this would ruin the effect of the defrost by creating ice immediately.

The dripping interval is regulated via parameter dt.

Defrost conditions and operation

Defrosting is enabled if:

- the evaporator temperature, read by probe 2, is lower than the defrost end setpoint configured via parameter dSt
- manual defrosting has not already been activated, in which case the request for automatic defrost will be cancelled.

Defrost requests can be made in the following ways:

Controller power-on	Controller power-on if parameter dPO (defrost at power-on) is programmed accordingly.		
Time intervals	if dit > 0 whenever the defrost time interval set in parameter dit elapses.		
Manually (via key)	by pressing the UP key The cycle will not start if OdO≠0 ; the request will be refused and the display will flash three times to indicate that defrost is impossible.		
External request via digital input (DI)	If the digital input (DI) is suitably configured. Activation via digital input (DI) respects the protections of the automatic cycle. The cycle will not start if OdO≠0 ; the request will be refused and the display will flash three times to indicate that defrost is impossible.		

HACCP models also offer the following mode:

Time	imo	if dit = 0 and dCt=3 with rtc function (real time clock).
	ine	At the times set in parameters dE1dE8 (dd folder)

6.6.2. Automatic defrosting

The defrost cycle is programmed to start at intervals.

NOTE: To disable the automatic cycle, set dit=0.

If dit>0, the defrost cycles will be run at fixed intervals, as indicated in parameter dit and the interval time is counted as follows:

Par.	Value	U.M.	Description	Notes	
1 num Hours of compressor if compressor (DIGIFROST method®) To num Device running time In I	0	num	compressor compressor (DIGIFROST	In this case, the counter runs only if the compressor is on. A new count starts when the defrost interval elapses and a new defrost cycle starts if conditions permit. NOTE: compressor running time is counted separately from the evaporator temperature. If the evaporator probe is missing or faulty, the count continues for the time the compressor is on.	
	The defrosting interval is counted continuously when the device is on and starts at each power-on. A defrost cycle starts when the defrosting interval elapses (indicated by dit) if conditions permit and the controller immediately starts counting a new defrosting interval.				
	2	num	Compressor stop	Each time the compressor stops, a defrost cycle is run according to the mode set in parameter dty .	
	3	num	RTC (clock)	The clock can be used to set: • defrost times (6 bands for weekdays and 6 bands for weekends/holidays), • regular defrosts (every n days) • daily events (1 event for weekdays and 1 event for weekends/holidays) Time band defrosts and periodic defrost are mutually exclusive functions (they cannot be activated simultaneously). If defrost by RTC has been enabled and the clock has failed, the defrost will run according to the mode set in dit (provided the value is ≠ 0).	

NOTE: regardless of how the interval is counted, the following conditions apply:

If parameter **OdO** is underway or the temperature read by the evaporator probe is higher than **dSt**, then defrost will not be permitted: a new interval will be counted and only at the end of this subsequent count will conditions be tested for the start of a defrost cycle.

6.6.3. Manual defrost

Press and hold the manual defrost key **ESC** (or from digital input (DI) if appropriately configured **H11...H13 = 1**), the device enters defrost. Procedures for the activation of this defrost cycle are the same as for external defrost.

The defrosting interval will now be counted as described for Automatic Defrost (time **dEt** is not cleared, it continues).

If the conditions for defrost activation are not present, i.e.:

- the time set in parameter OdO has not elapsed
- the evaporator temperature is higher than the value set in parameter dSt

this will be indicated on the display (screen flashes three times) and the defrost will stop.

Manual defrost is always enabled except when dit = 0.

6.6.4. External defrost

If the Digital Input is configured for this function (if **H11...H13 = 1**) and if conditions permit, defrost can be requested and the corresponding regulator activated.


Time graphs for signals in each of the various function modes are presented below.

NOTE: Defrost activation occurs when the signal is toggled and the polarity can be selected.

Hence you can only activate a defrost, NOT stop one that is underway.

Defrost or dripping currently underway and the defrost or dripping interval count cannot be suspended.

IN (Digital Input)	nput status for defrost regulator, with activation from Digital Input.			
OUT (Defrost)	Output status for defrost regulator.			
DurDl	igital Input duration.			
NOTE:	dSt indicates end defrost time when Setpoint temperature reached and dEt indicates end of defrost due to timeout.			



6.6.5. Defrost WITH REMOTE START/STOP

If the Digital Input is configured for this function (if **H11...H13 = ±22**) defrost with start/stop is activated from remote.

The defrost is switched on when the digital input becomes active. Vice versa, when the digital input is disabled, the defrost ends.

If the automatic defrost is also active, the two functions will proceed in parallel. In this case, the defrost interval set in the parameter dit will be reset when the remote defrost is activated (digital input). Having ended the remote defrost, the dripping function will be activated if dt > 0.

The conditions for activation are:

- Defrost probe present and temperature lower than **dSt**;
- Defrost not inhibited by an alarm.

The defrost will not be activated if the following conditions are present:

- 1. Defrost end probe present and temperature higher than dSt;
- 2. Alarm condition inhibiting the defrost,

The defrost may end before the defrost is disabled from the digital input (DI) if:

- dEt ends the count;
- Defrost probe present and temperature higher than **dSt**;
- · Alarm condition ending the defrost early.

To manage the activation delays of the digital inputs DI1 and DI2 separately:

- Set **dAd** = 0;
- Add a delay using parameters **O1i** (to delay the activation of digital input DI1) and **O2i** (to delay the activation of digital input DI2), the delay of the digital input DI3 can be set using parameter **di3**.

NOTE: If $dAd \neq 0$, any delays set in **O1i** and **O2i** will not be considered by the instrument.

User parameters

Label	Description			
dAd	Delay activating digital input DI1 and digital input DI2.			
O1i	Delay activating digital input DI1			
O2i	Delay activating digital input DI2			
di3	Delay activating digital input DI3			

6.7. DEFROST MODE

6.7.1. Defrost with electric heaters

Defrost with electric heaters is configured via parameter **dty = 0**.

The compressor remains stopped for the duration of the defrost cycle and the relay configured as defrost regulator output, to which the electric heaters are connected, activates. On completion of defrost, the electric heaters are switched off and the compressor remains off for the dripping time set in parameter \mathbf{dt} , if it is not equal to zero.


Defrost ends due to:

Evaporator Probe	End of defrost description	
Evaporator Probe ABSENT	Due to timeout set in parameter dEt (defrost timeout)	
	Temperature setpoint for the end of defrost set in parameter dSt reached. If this setpoint is not reached within the time set in parameter dEt (defrost timeout), the defrost will end due to timeout.	

NOTES:

- If dSt intervenes before dEt, dripping (dt and Fdt) aligns with dSt.
- If Fdt < dt then Fdt = dt.
- During defrost, fans are OFF if parameter dFd is set accordingly, otherwise they will behave as set for the fan regulator.

The operating diagram is as follows:



Key:

*	Output status for Compressor regulator			
***	Output status for Defrost regulator			
×	Output status for Evaporator Fan regulator			

6.7.2. Inverse defrost

Hot gas defrost is configured by setting parameter dty = 1.

The compressor stays on for the entire duration of the defrost cycle and the relay configured as defrost regulator output, and that the solenoid valve is connected to, activates.

On completion of the defrost cycle, the valve relay is de-energised and the dripping phase set in parameter **dt** (if not equal to zero) is interrupted. The compressor relay is once again controlled by the compressor regulator.

Defrost ends due to:


Evaporator Probe	End of defrost description	
Evaporator Probe ABSENT	Due to timeout set in parameter dEt (defrost timeout)	
	Temperature setpoint for the end of defrost set in parameter dSt reached. If this setpoint is not reached within the time set in parameter dEt (defrost timeout), the defrost will end due to timeout.	

NOTE: Parameters dOn, dOF and dbi still have priority.

NOTES:

- If dSt intervenes before dEt, dripping (dt and Fdt) aligns with dSt.
- If Fdt < dt then Fdt = dt.
- During defrost, fans are OFF if parameter **dFd** is set accordingly, otherwise they will behave as set for the fan regulator.

The operating diagram is as follows:



6.7.3. Double evaporator defrost

The defrost for a second evaporator can be controlled via the probe configured as second evaporator.

Configure a relay output (see configuration parameters H21...H25) as a defrost relay for evaporator 2.

To enable this function, you need to:

- set probe Pb3 to control defrost evaporator 2 mode (parameter H43).
- configure a relay output (see configuration parameters H21...H25) as a defrost relay for evaporator 2.
- Define defrost mode by setting parameter H45.

Input mode

A double evaporator defrost can take place in three different ways on the basis of parameter H45, as described below:

- H45=0: Defrost is enabled only when the temperature of evaporator 1 is lower than the value set in parameter dSt.
- H45=1: Defrost is enabled when the readings from at least one of the two probes is below its defrosting end temperature (dSt for evaporator 1 and dS2 for evaporator 2)
- H45=2: Defrost is enabled when both probe values are below the corresponding end of defrost setpoints (dSt for evaporator 1 and dS2 for evaporator 2)

The probe error condition is considered as a probe calling for defrost.

The defrost for every single evaporator ends when the following conditions have been met:

- the dEt/dE2 timeout period has elapsed
- the dSt/dS2 temperature has been reached

Ending mode

Defrost in the case of a double evaporator takes place when both probe values have reached or exceeded the relative end of defrost setpoints (**dSt** for evaporator 1 and **dS2** for evaporator 2)

If one or both probes are in error, the end of defrost will take place due to timeout.

In any case

If there are no conditions for performing the defrost the request will be cancelled.

The defrost for a single evaporator will end when the corresponding probe reaches or exceeds the defrosting end temperature or when the timeout period begins.

Dripping begins when both defrosts have ended.

If one or both probes are in error, the defrost for the corresponding evaporator will end due to timeout. Onset is allowed as if the corresponding temperature is lower than the corresponding setpoint (dSt or dS2).

If the probe is not configured to be the probe for the second evaporator ($H43 \neq 2$), the defrost for the second evaporator may take place if a digital output is configured to control defrost on the second evaporator (H21..H25 = 9). In this case consent for defrost will be granted, as if the probe temperature (evaporator 2) < dS2 and the output takes place due to timeout. The fan regulator is not affected.

User parameters

The parameters that manage this regulator are:

Label	Description			
dty	Selects defrost type			
dit	Time interval between 2 consecutive defrost cycles			
dCt	Selects the count mode for the defrost interval			
dOH	Defrost cycle activation delay after request			
dEt	Defrost timeout evaporator 1. Determines the maximum defrost duration			
dE2	Defrost timeout evaporator 2. Determines the maximum defrost duration			
dSt	Defrost 1 end temperature - determined by evaporator probe 1			
dS2	Defrost 2 end temperature - determined by evaporator probe 2			
dPO	Determines whether the instrument must enter defrost mode at power-on			
Fdt	Fan activation delay after a defrost cycle			
dt	Dripping time			
dFd	Allows exclusion of the evaporator fans to be selected or not selected during defrosting.			
dAO	Temperature alarm disabling time after defrost cycle			
dAt	Alarm signalling end of defrost due to timeout			
ddL	Display mode during defrost cycle (lock display.)			
Ldd	Timeout value for display unlock - label dEF			

Summary table

Defrost on evaporator 1

ost START	Defrost END	
rator 2) (evaporator 1) temperature	Probe Pb3 (evaporator 2) (evaporator 1) temperature > dSt	
rator 2) (evaporator 1) temperature	or if Probe Pb3 (evaporator 2) (evaporator 1)	
rator 2) (evaporator 1) temperature (evaporator 2) < dS2	temperature < dSt due to time-out or if probe Pb2 in error due to timeout	
((

Note: if the probe is in error or **H43** ≠2 and a digital output is configured as a regulator for the second evaporator, the following condition applies: Probe temperature (evaporator 2) < **dS2**

Defrost on evaporator 2

	Defrost START	Defrost END
If H45 =0	Probe Pb3 (evaporator 2) (evaporator 1) temperature < dSt and Probe temperature (evaporator 2) < dS2	Probe 3 temperature (evaporator 2) > dS2 or if
If H45 =1	21 Probe temperature (evaporator 2) < dS2	Probe temperature (evaporator 2) < dS2 due to
If H45 =2	Probe Pb3 (evaporator 2) (evaporator 1) temperature < dSt	timeout or if probe in error due to timeout.
	and Probe temperature (evaporator 2) < dS2	

Note: if the probe is in error or **H43** ≠2 and a digital output is configured as a regulator for the second evaporator, the following condition applies: Probe temperature (evaporator 2) < **dS2**

Dripping

Drip cooling START	Drip cooling END	
End of defrost for both evaporators if defrosting takes place for	ce for Unahangad	
both evaporators, otherwise end of the only defrost in progress	Unchanged	

6.8. EVAPORATOR FANS

6.8.1. Evaporator fan operating conditions

The regulator is active when:

- the time set in parameter **OdO** has elapsed.
- the temperature of the evaporator probe, if present, is between the values of parameters Fot and FSt
- during defrost it is not excluded by the parameter **dFd** (**dFd = y**).
- dripping is not active (dt).
- the fan delay is not active after defrost (Fdt).

The request to switch fans on or off can be made in the following ways:


- by the compressor regulator to help in the "cooling" process (temperature control mode.)
- by the defrost regulator to check and/or limit the diffusion of hot air.

	FCO	Compressor ON	Compressor OFF
	0	THERMOSTAT CONTROLLED	OFF
Drohe present and	1	THERMOSTAT CONTROLLED	THERMOSTAT CONTROLLED
Probe present and working	2	THERMOSTAT CONTROLLED	THERMOSTAT CONTROLLED
	3	THERMOSTAT CONTROLLED	DUTY-CYCLE*
	4	THERMOSTAT CONTROLLED	DUTY-CYCLE* **
	0	DUTY-CYCLE	OFF
	1	ON	OFF
Probe present but in error	2	DUTY-CYCLE	DUTY-CYCLE
	3	DUTY-CYCLE	DUTY-CYCLE
	4	DUTY-CYCLE	DUTY-CYCLE
	0	ON	OFF
	1	ON	ON
Probe absent	2	DUTY-CYCLE*	DUTY-CYCLE*
	3	ON	DUTY-CYCLE*
	4	ON	DUTY-CYCLE* **

^{*} see paragraph "Fan operation with probe Pb2 absent" (H42 ≠ 0).

^{**} Normal Duty-Cycle operation reversed (OFF cycle - ON cycle)

The graphs below illustrate fan operation on the basis of the **FCO** value. In the graphs, we can see that:



6.8.2. Fan operation in temperature control mode

During "cooling", the fans operate as shown in this diagram:

Thermostat control of fans takes place at the values set in parameters

- FSt (fan disabling temperature) and FAd (fan differential).
- Fot (fan start temperature) and FAd but with the sign inverted.

By default, the fan disabling temperature, set by parameters **FSt** (fan disabling temperature) and **FAd** (fan differential), is an absolute value, as **FPt = 0** (actual temperature value).


Depending on the parameter **FPt**, the fan disabling temperature set at parameter **FSt** can be absolute (actual temperature value) or relative (value to add to the Setpoint SEt).

Depending on the parameter **FPt**, the fan start temperature set at parameter **Fot** can be absolute (actual temperature value) or relative (value to add to the Setpoint SEt).

NOTE: if as an absolute value the parameter Fot is greater than FSt the fans will be excluded

Around the fan start temperature (-50° C by default) the differential will always take account of the differential parameter **FAd** but with the sign inverted (negative side). Fan stop in **Fot**, and activation at value (**Fot** + **FAd**).

The fan regulator operates as indicated below:



6.8.3. Fan operation in Duty-Cycle mode


For Duty-cycle operation, parameters ${\bf Fon}$ and ${\bf FoF}$ must be set accordingly;

The fans operate as follows:

DUTY-CYCLE

Fon	FoF	Fan operation
0	0	OFF
0	≠0	OFF
≠0	0	ON
≠0	≠0	DUTY-CYCLE

The fan regulator will operate in Duty-cycle mode as illustrated below:



6.8.4. Fan operation in defrost

During defrost, the fans operate as shown in this diagram

dFd = n:	the fans are not excluded during defrost (see parameters FCO, Fon, FoF)	TEMPERATURE CONTROL / DUTY-CYCLE
dFd = y:	exclusion of fans during defrost	OFF

Thermostat control of fans takes place at the values set in parameters:

NOTE: during defrost with electric heaters, the compressor is OFF but the fans work as if the compressor was still ON, unless they have been disabled during defrost (see parameter **dFd**).


When the evaporator fans are enabled in defrost (**dFd = n**) and regulate the evaporator probe Pb2 in thermostat controlled mode, when the latter enters error "E2" during defrost, the fans must always be ON, regardless of the values set via the Duty-cycle.

Fan operation without probe

If parameter **H42** = **n** (probe Pb2 absent), depending on the FCO value and the status of the compressor, the fans may assume the status "On", "Off", "Duty-cycle".

The parameter FCO will determine the operating mode of the evaporator fans during the DAY phase and the NIGHT phase.

The following is an example of fan operation on the basis of the value set for FCO.



[•] FSt (fan disabling temperature) and FAd (fan differential).

6.8.5. Fan function during dripping

If parameter $dt \neq 0$ (dripping time), the fans will stay OFF for the time set in this parameter.

See "Defrost with electric heaters".

Note that if **Fdt** (fan delay time) is greater than **dt** (dripping time) the fans stay OFF for the time set in **Fdt** rather than **dt** (e.g. whichever timing is longer will be applied).

6.8.6. Post-ventilation

Parameter **FdC** delays the switching off of the fans after the compressor has stopped (increasing efficiency of the system by making better use of inertia). Post-ventilation must be active with any FCO value and without a configured probe. If **FdC = 0** the function is disabled.

NOTE: Post-ventilation does not have priority over the delay set by parameter dcd.

User parameters

The parameters that manage the fan regulator are:

Label	Description
FPt	Characterises parameter "FSt" which can be expressed either as an absolute value or relative to the
FFt	setpoint
FSt	Evaporator fan disabling temperature
Fdt	Evaporator fans delay after defrost cycle
dFd	Evaporator fans disabling during defrost time
FCO	Evaporator fans operating mode
FAd	Evaporator fans activation differential
dt	Dripping time
FdC	Evaporator fans switch-off delay after compressor deactivation
Fon	Evaporator fans ON time in duty-cycle mode
FoF	Evaporator fans OFF time in duty-cycle mode

6.9. DEEP COOLING CYCLE - DCC

Description

This regulator help ensures that the compressor regulates the setpoint **dCS**, with differential equal to the value set via parameter **diF**.

When the Deep Cooling Cycle (DCC) activates, the interval between defrost cycles is cleared and defrosts are disabled. DCC is activated, by setting the parameter tdc>0, and H01=1

Ending of the DCC is time-based, by setting the parameter tdc≠0, or when the setpoint dCS if tdc = 0.

When a **DCC** has ended and once the time set in parameter **dcc** has elapsed, a defrost cycle is forced and the counters restart for the interval between defrost cycles (value set via parameter **dit**). If **dcc=0** defrost begins at the end of the **DCC**. During the **DCC** the temperature alarms are disabled.

Normal temperature alarm management is restored at the end of the **DCC**, when the temperature value read by probe **Pb1** reaches the regulation setpoint value **SEt**.


Operating conditions

The Deep Cooling Cycle will be activated via Digital Input or via a suitably configured key.

In the event of a probe error and/or power failure, the Deep Cooling Cycle is stopped and standard controller function restored.

If the dCS parameters are changed, tdc and dcc the functioning of the Deep Cooling Cycle is recalculated with new set values.

NOTE: After a Deep Cooling Cycle, the dcc time must elapse before a new cycle can begin.



User parameters

The parameters that manage the fan regulator are:

Label	Description
dCS	Deep Cooling set point
tdc	Deep Cooling Time
dcc	Delay Defrost after Deep Cooling

6.10. PREHEAT

The preheating phase is linked to a suitably configured digital input (H11... H13 = \pm 12).

In the period when the preheat output is active:

- · the compressor output will be forced OFF;
- · the compressor icon will flash.

The Preheat only affects defrosting in applications that require the use of the compressor (dty= 1 and dty= 2).

6.11. PRESSURE SWITCH

This regulator performs diagnostic procedures on an activated digital input by assigning the value ±11 (General pressure switch), ±09 (Minimum pressure switch) or ±10 (Maximum pressure switch) to one of the parameters H11...H13.

If a pressure switch input is activated, power to the compressor loads is immediately cut off, the corresponding alarm icon lights up to provide a visual warning and the alarms folder **ALr** is also displayed. The folder contains labels with the number of pressure switch activations (up to the maximum value set in parameter **PEn**):

- P01, P02, ...P0n... for general pressure switch
- H01, H02, ...H0n... for maximum pressure switch
- L01. L02. ...L0n... for minimum pressure switch

If the number of activations exceeds the maximum number defined by parameter **PEn** within a time less than the value of **PEi**, the following conditions occur:

- The compressor, fan and defrost outputs are disabled
- in the alarms folder **ALr** label **PA**, **LPA** or **HPA** are displayed (general, minimum or maximum pressure switch respectively).
- The alarm relay comes on (if configured).

NOTE: 1) if the number of activations exceeds the number set in PEn in the PEI time, the alarm is automatically reset.

- 2) the input must be:
 - · closed on itself if unused and the input is active when normally closed;
 - · open if unused and active when normally open;
 - · deactivated via digital input configuration parameter.

NOTES: 1) Once it has entered alarm status, the device must be switched off and on again, or reset using the **rPA** key in the functions menu.

- 2) If parameter PEn = 0, the function is disabled and alarms and counters are also disabled.
- 3) The pressure switch alarm is not stored in EEPROM
- 4) During the pressure switch activation period the defrost interval count runs as normal.

Operating conditions


The number of pressure switch errors is counted using a FIFO method. The time interval **PEi** is divided into 32 parts; the counter is incremented by one unit if there are one or more activations during one part of the entire interval **PEi**. Two operating examples are given below: In both cases, suppose that **PEi** = 32' (equal to 32'/32 = 1 minute) and **PEn** = 7.

Example 1: ALARM SIGNALLED.

The interval for storing activations is 1 minute: all activations within that minute are counted as a single activation and the alarm is activated when the sampling interval has elapsed. In this example the pressure switch alarm is signalled because there have been 7 activations during the 32' time window.

Example 2: ALARM NOT SIGNALLED

In this example the alarm is not activated because during the 32' time window the number of activations set in parameter **PEn** was not reached. In practice the time window is a rolling window and all activations that are outside of it are deleted: the reference point is the last activation and the time **PEi** is subtracted from that point to establish how many activations are included in the count.



The parameters that manage the pressure switch regulator are:

Label	Description			
PEn	Number of errors allowed per general/maximum/minimum pressure switch input			
PEI General/minimum/maximum pressure switch error count interval (in 32 parts)				

6.11.1. AUXILIARY OUTPUT (AUX/LIGHT)

Description

If one of the parameters **H21...H25** is set to the value **H2x=5**, it anticipates the relay control as AUX and, by pressing the associated key **H32...H35** which must be set to the value **H3x=2**, the relay is activated if it was off previously and vice-versa.

The on/off status is saved in non-volatile memory hence when power returns after a blackout, the device will restart in the status that was active prior to the blackout.

If one of the parameters **H11...H13** is set to the value**H11...H13=±3**, it anticipates the AUX relay control by the digital input; in this case the relay will mirror the status of the input. In this case, on/off status is not saved in non-volatile memory.

NOTE: the meaning of the digital input (DI) must always remain the same: for example, if the relay is activated by digital input (DI) and switched off by key, when the digital input (DI) is reset to the starting position, the relay does not change status (since it was already de-energised by key).

With the instrument OFF, if set accordingly, only the digital input (DI) and the associated key can change the status of the output.

Operating conditions


The regulator is activated by:

- Kev
- Function
- · Digital Input

if configured accordingly.

The regulator is not active when:

Condition	AUX output status		
during start-up	OFF		
during stand-by	status depending on parameters H06 and H08		



User parameters

The parameters that manage the auxiliary (AUX) output regulator are:

Label	Description
H11H13	Configuration of digital input 13 / Polarity
H21H25	Configuration of digital output 15
H32H35	Configuration of DOWN, ESC, ON/OFF, LIGHT key

6.12. DOOR/EXTERNAL ALARM MANAGEMENT

The door switch input is associated to an appropriately configured digital input ($H1x = \pm 4$).

By controlling the opening of the door, it is possible to disable the compressor output and/or the fans.

It is also possible to associate a deactivation delay with the compressor output by means of parameter dCO.

If the door is opened during a defrost cycle, the cycle is not shut down.

The values that can be set for the parameters involved are:

dod: Door switch switches off loads on digital input (DI) command

- 0 = function disabled
- 1 = disables fans (FAN)
- 2 = disables the compressor (COMP)
- 3 = disables the compressor (COMP) and fans (FAN)

Any protective timers (e.g. compressor start delay, etc.) will still be observed.

rLO: Locks compressor, defrost and fan regulators if the digital input (configured as external alarm) is activated.

- 0 = no resource locked
- 1 = Compressor and Defrost locked
- 2 = compressor, defrost and fans locked

dOA: Establishes what should be enabled/disabled on enabling/disabling of the Digital input. Only applies if **PEA** ≠ 0.

- **0** = activates the compressor (COMP)
- 1 = activates fans (FAN)
- 2 = activates the compressor (COMP) and fans (FAN)
- 3 = deactivates the compressor (COMP)
- 4 = deactivates fans (FAN)
- 5 = deactivates the compressor (COMP) and fans (FAN)

PEA: Establishes which of the door switch and alarm should be linked to the parameter dOA in the following way:

- 0 = function deactivated
- 1 = function linked to door switch
- 2 = function linked to external alarm
- 3 = function linked to door switch and external alarm

dCO: Compressor resource activation/power off delay (0 ...255 min).


dFO: Evaporator fan resource activation/power off delay (0 ...255 min).

tdO: Door open alarm exclusion time (0...255 min). The door open alarm will be activated if the door remains open for a time period greater than the setting for this parameter.

The way in which parameters **dCO** and **dFO** act depends on how parameter **dOA** is configured. To better understand the meaning of these parameters, refer to the figures below.

The graphs below illustrate fan operation on the basis of the dOA value. In the graphs, we can see that:

	Door
*	Evaporator fans
8	Compressor



6.13. DEMISTING HEATERS (FRAME HEATERS)

The controller is equipped with a regulator for the demisting heaters.

Operating conditions

The table below lists the ways the relay output can be managed:


HOn	HOF	FRAME HEATER OUT
0	0	OFF
0	>0	OFF
>0	0	ON
>0	>0	Duty-cycle

Where **HOn** = 0 the regulator is always off, while if **HOn** > 0 and **HOF** = 0 the regulator is always on.

If **HOn** > 0 and **HOF** > 0: the regulator activates in operating cycle mode irrespective of the values read by the probes (cold room probe failure) and of requests from other loads (**Duty-cycle** mode).

If the cold room probe is working properly, the Duty-cycle mode does **NOT** activate as it does not have priority over normal regulator settings.

The following diagram shows the **Duty-cycle** operating mode based on the parameters **HOn** and **HOF > 0**:



User parameters

The parameters that manage the frame heater regulator are:


Label	Description
HOn	Frame Heater regulator output ON time
HOF	Frame Heater regulator output OFF time
dt3	Frame Heater regulator time standard unit of measurement: 0 = hours; 1 = minutes; 2 = seconds

6.14. CONDENSER FANS

This regulator is associated with probe Pb3 (see specific section) and features:

- intervention setpoint SCF
- · operating differential dCF
- exclusion of fans during defrost dCd
- activation delay after end of defrost tCF

If a digital output is set as condenser fans (H21...H25=12), this output will behave as follows:



If probe Pb3 is not present and if alarm E3 is active, the regulator will always be active except during the defrost cycle. Probe 3 can be excluded and, in this case, its lack of connection to the instrument will not cause any error signalling to occur.

NOTE: During the dripping time the output is OFF.

NOTE: If a digital output is programmed as "condenser fans" (**H21...H25**=12), parameter **SA3** is always an absolute value, regardless of the value assumed by the parameter Att.

User parameters

The parameters that manage the condenser fan regulator are:

Label	Description			
SCF	ondenser fans activation Setpoint			
dCF	ondenser fans activation differential			
tCF	Condenser fans switch-on delay after defrost			
dCd	Exclusion of condenser fans during defrost			
dt	Dripping time.			

6.15. STAND-BY

Operating conditions

The stand-by regulator can be activated by digital input (if configured) or by key (if programmed).

With the device OFF the display shows "OFF" and all regulators are blocked including alarms.

When the device is switched on via a key or an appropriately configured digital input, regular operation commences, the same as from power-on. After power-on, the temperature alarm is excluded for a time set in parameter **PAO**, and the delay set by parameter **OdO** is activated.

Each time that the device is switched off, all cycle times are reset.

The on/off status is saved in non-volatile memory hence when power returns after a blackout, the device will restart in the status that was active prior to the blackout.

The output from stand-by is linked to the delay set in parameter **OdO**.

NOTE: With the controller off, all relays are de-energized except for Aux: button/aux input-light-door switch are active.

User parameters

The parameters that manage the stand-by regulator are:

Label	Description	
PAO	Alarm disabling after power-on	
OdO	Output activation delay from power-on	
OAO	High/low temperature alarm exclusion time after door closing	

6.16. PUMP DOWN

In some applications, Coldface manages the fluid solenoid valve, located in the cold room, while the refrigeration output is generated by a condenser unit, where the compressor is switched on/off directly by a minimum pressure switch on the unit itself.

Pump-down mode can be used to manage the compressor directly by connecting the minimum pressure switch to the Coldface, which means it can also be used for diagnostics.

The purpose of this regulator is to allow compressor activation (pump-down compressor output) exclusively on the basis of minimum pressure switch regulation and regardless of the status of the main temperature controller, which will be used to enable/disable solenoid valves (compressor output) instead.

6.16.1. Service stoppage

Service stoppage switches the cold room OFF, and this status is indicated on the display. It also allows compressor activation every time the pressure on the suction line rises until the minimum pressure switch starts running (pump-down).

7.1. HOW TO MODIFY THE USER PARAMETERS

The 'User' parameters are the most useful ones. This document describes them in the Parameter Table section.

- 1) Press and hold the SET button for at least 3 seconds, until the display shows USr
- 2) Press and release the SET key. The top display will show the first parameter, the bottom display will indicate the current parameter value
- 3) Using the UP & DOWN keys, find the parameter that you wish to modify
- 4) Press and release the SET key again. The top display will show the name of the blinking parameter
- 5) Use the UP & DOWN keys to adjust the parameter value
- 6) Press and release SET to save the parameter value
- 7) Return to step 3) or press ESC several times to return to the normal display.

IT IS POSSIBLE TO EDIT OTHER INSTALLER PARAMETERS (inS) ON THE INSTRUMENT

7.2. HOW TO EDIT THE INSTALLER PARAMETERS

- 1) Press and hold the SET key for 3 seconds until the display shows USr
- 2) Use the UP & DOWN keys to select the inS parameter section
- 3) Press and release the SET key again. The display will show the first folder
- 4) Press and release the SET key again. The top display will show the first parameter in the folder, the bottom display will indicate the current parameter value
- 5) Use the UP & DOWN keys to find the parameter that you want to change

The procedure progresses in a similar manner to that described for the User parameters (steps 4-7).

7.3. PARAMETER TABLE

PAR.	LEV.	DESCRIPTION	U.M.	RANGE	DEFAUL
SEt	USr/inS		°C/°F	-58.0302	0.0
		COMPRESSOR parameters (CPr)			
diF	USr/inS	Activation differential N.B.: diF cannot be equal to 0.	°C/°F	030.0	2.0
HSE	USr/inS	Maximum value that can be assigned to the setpoint. NOTE: The two setpoints are interdependent: HSE cannot be less than LSE and vice versa.	°C/°F	LSEHdL	50.0
LSE	USr/inS	Minimum value that can be assigned to the setpoint. NOTE: The two setpoints are interdependent: HSE cannot be greater than LSE HSE and vice versa.	°C/°F	LdLHSE	-50.0
OSP	USr/inS	Temperature value to be added algebraically to the setpoint if reduced set enabled (Economy function). Enabling can take place via key, function or digital input configured specifically for this purpose.	°C/°F	-30.030.0	0.0
Cit	USr/inS	Minimum activation time of compressor before possible deactivation. If Cit = 0 it is not active.	min	0255	0
CAt	USr/inS	Maximum activation time of compressor before possible deactivation. If CAt = 0 it is not active.	min	0255	0
Ont	USr/inS	Controller switch-on time in the event of probe error. - if Ont = 1 and OFt = 0, the compressor stays on permanently (ON), - if Ont > 0 and OFt > 0, it operates in duty-cycle mode.	min	0255	10
OFt	USr/inS	Controller switch-off time in the event of probe error. - if OFt = 1 and Ont = 0, the compressor stays OFF permanently, - if Ont > 0 and OFt > 0, it operates in duty-cycle mode	min	0255	10
dOn	USr/inS	Delayed start. The parameter indicates that a protection is active on the general compressor relay actuations. At least the indicated time must elapse between the request and the actual activation of the compressor relay.	S	0255	2
dOF	USr/inS	Delay time after power-off: the delay time indicated must elapse between deactivation of the compressor relay and the next power-on.	min	0255	0
dbi	USr/inS	Delay between switch-ons; the delay time indicated must elapse between two consecutive compressor power-ons.	min	0255	2
OdO	USr/inS	Delay in activating outputs after the instrument is switched on or after a power failure. 0 = not active	min	0255	0
dSC	inS	Compressor 2 activation delay. Indicates the time after which the relay configured as compressor 2 will be activated in relation to the first compressor. If compressor 1 is disabled during this time, the call for compressor 2 will be cancelled.	S	0255	0
dCS	inS	DEEP COOLING CYCLE Deep cooling cycle setpoint	°C/°F	-58.0302.0	0
tdc	inS	Deep cooling cycle duration	min	0600	10
dcc	inS	Delay defrost after deep cooling cycle	min	0255	0
		DEFROST parameters (dEF)			
dty	USr/inS	Defrost mode 0 = electric defrost (defrost cycle OFF), or compressor not running during defrost. NOTE: electric defrost + air defrost, in the case of fans connected in parallel to the defrost output relay 1 = cycle inversion defrost (hot gas, or compressor on during defrost;) 2 = "free" mode defrost (independent of compressor)	num	02	0
dit	USr/inS	Interval between defrost cycles Time interval between the start of two consecutive defrost cycles. 0 = function disabled (defrost is NEVER activated). See dt1 for UM.	hrs/min/s	0255	6 hours
dt1	inS	Unit of measure for defrost intervals (parameter dit). 0 = parameter dit in hours 1 = parameter dit in minutes 2 = parameter dit in seconds	num	02	0
dt2	inS	Unit of measure for duration of defrost (parameter dEt/dE2). 0 = parameter dEt/dE2 in hours 1 = parameter dEt/dE2 in minutes 2 = parameter dEt/dE2 in seconds.	num	02	1

PAR.	LEV.	DESCRIPTION	U.M.	RANGE	DEFAULT
dCt	USr/inS	Defrost interval count mode 0 = compressor running time (DIGIFROST® method); defrost active ONLY when compressor is on. N.B.: compressor running time is counted separately from the evaporator probe (count active even if the evaporator probe absent or error). 1 = device running hours; defrost count is always active when machine is on and starts at each power-up. 2 = compressor stop. Every time the compressor stops, a defrost cycle is run depending on parameter dty; 3 = RTC. Defrost at specific times set by parameters dE1dE8, F1F8	num	03	1
dOH	USr/inS	Defrost cycle enabling delay from request Delay preceding start of first defrost after call.	min	059	0
dEt	USr/inS	Defrost timeout Determines the maximum defrost time on Evaporator 1. See dt2 for UM.	hrs/min/s	1255	30
dSt	USr/inS	Defrost end temperature Defrost 1 end temperature (determined by evaporator probe 1).	°C/°F	-58.0302.0	6.0
dS2	inS	Evaporator 2 defrost end temperature Determines the maximum defrost time on Evaporator 2	°C/°F	-58.0302.0	8.0
dE2	inS	Evaporator 2 maximum defrost duration Determines the maximum defrost time on Evaporator 2. See dt2 for UM.	hrs/min/s	1255	30
dPO	USr/inS	Defrost enabling request from power-on Determines whether the instrument must enter defrost mode at power-on (provided that the temperature measured at the evaporator will allow defrost). n = no, does not start defrosting at power-on; y = yes, starts defrost at power-on	flag	n/y	n
tcd	inS	Compressor output activation/deactivation time before a defrost Minimum time that must elapse with the compressor ON or OFF before defrost is activated.	min	-3131	0
Cod	inS	Time preceding a defrost, during which the compressor output is not activated	min	060	0
dE1dE8 F1F8		Parameters dE1dE8 / F1F8 – ONLY VISIBLE IN HACCP MODELS NOTE: do not confuse parameters dE1dE8 with values d0d7 in fold regulator. Parameters for setting the time of single defrosts • daily (dE1dE8) • daily "weekends/public holidays" (F1F8), used by the Day/Night regulator. The parameters will only be displayed if: • dit = 0 • dCt = 3 (Real time clock) • H48 = y (rtc option declared present) • the device has been switched off and on again after the above parameters have be Setting the time for defrosts on weekdays If parameter dit (defrosting interval) = 0, dCt = 3 and the rtC option is (declared) present, then parameters dE1dE8 allow you to set the hours and minutes. Only on the basis of these values will a defrost cycle begin. If you do not wish to use some of the defrost times (dE1dE8), exclude them as explained below: Select the parameter (dE1dE8) that you want to exclude, then increase the value until 24 appears on the display, indicating that the parameter has been excluded. Bear in mind that the times do not have to be set in exact chronological order, e.g.: dE1 = h 12.25 dE2 = h 06.05 dE3 = h 18.30		The parameter into dEn_H (h dEn_m (mi n=1	is then split ours), nutes),

PAR.	LEV.	DESCRIPTION	U.M.	RANGE	DEFAULT
		Setting the time for defrosts on weekends/public holidays			
		If parameter dit (defrosting interval) is dit = 0, dCt = 3 and the RTC option is			
		declared present, then parameters F1F8 allow you to set the hours and minutes. Only on the basis of these values will a defrost cycle begin.		The parameter	ic than enlit
		If you do not wish to use some of the defrost times (F1F8), exclude them as		into	•
F1F8		explained below:	hours/	Fn_H (ho	
		Select the parameter (F1F8) that you want to exclude, then increase the value	mins	Fn_m (mir	
		until 59 appears on the display, indicating that the parameter has been excluded.		n=1	,
		Bear in mind that the times do not have to be set in exact chronological order, e.g.:			
		• F1 = h 12.25			
		• F2 = h 06.05			
		• F3 = h 18.30			
dE1H		Start time weekday defrost 1. 023 = start hour; 24 = disabled.	hours	024	0
dE1m		Start time minutes weekday defrost 1.	min	059	0
dE2H		2nd workday defrost start hour. d1H23 = start hour; 24 = disabled.	hours	024	0
dE2m	USr/inS	2nd workday defrost start minutes.	min	059	0
dE3H	USr/inS	3rd workday defrost start hour. d2H23 = start hour; 24 = disabled.	hours	024	0
dE3m		3rd workday defrost start minutes.	min	059	0
dE4H	USr/inS	4th workday defrost start hour. d3H23 = start hour; 24 = disabled.	hours	024	0
dE4m	USr/inS	4th workday defrost start minutes.	min	059	0
dE5H	USr/inS	5th workday defrost start hour. d4H23 = start hour; 24 = disabled.	hours	024	0
dE5m	USr/inS	5th workday defrost start minutes.	min	059	0
dE6H	USr/inS	6th workday defrost start hour. d5H23 = start hour; 24 = disabled.	hours	024	0
dE6m	USr/inS	6th workday defrost start minutes.	min	059	0
dE7H	USr/inS	7th workday defrost start hour. d4H23 = start hour; 24 = disabled.	hours	024	0
dE7m	USr/inS	7th workday defrost start minutes.	min	059	0
dE8H	USr/inS	8th workday defrost start hours. d5H23 = start hour; 24 = disabled.	hours	024	0
dE8m	USr/inS	8th workday defrost start minutes.	min	059	0
F1H	USr/inS	1st weekend/public holiday defrost start hour. 023 = start hour; 24 = disabled.	hours	024	0
F1m	USr/inS	1st weekend/public holiday defrost start minutes.	min	059	0
F2H	USr/inS	2nd weekend/public holiday defrost start hour. F1H23 = start hour; 24 = disabled.	hours	024	0
F2m	USr/inS	2nd weekend/public holiday defrost start minutes.	min	059	0
F3H	USr/inS	3rd weekend/public holiday defrost start hour. F2H23 = start hour; 24 = disabled.	hours	024	0
F3m	USr/inS	3rd weekend/public holiday defrost start minutes.	min	059	0
F4H	USr/inS	4th weekend/public holiday defrost start hour. F3H23 = start hour; 24 = disabled.	hours	024	0
F4m	USr/inS	4th weekend/public holiday defrost start minutes.	min	059	0
F5H		5th weekend/public holiday defrost start hour. F4H23 = start hour; 24 = disabled.	hours	024	0
F5m		5th weekend/public holiday defrost start minutes.	min	059	0
F6H		6th weekend/public holiday defrost start hour. F5H23 = start hour; 24 = disabled.	hours	024	0
F6m		6th weekend/public holiday defrost start minutes.	min	059	0
F7H		7th weekend/public holiday defrost start hour. F5H23 = start hour; 24 = disabled.		024	0
F7m		7th weekend/public holiday defrost start minutes.	hours		
			min	059	0
F8H		8th weekend/public holiday defrost start hour. F5H23 = start hour; 24 = disabled.	hours	024	0
F8m	USr/inS	8th weekend/public holiday defrost start minutes.	min	059	0
		FAN parameters (FAn)			
FPt	inS	FSt parameter management mode.	flag	0/1	0
	0	0 = absolute value; 1 = relative value	nag	0/1	
		Fans lockout temperature; if the value read is greater than FSt, the fans will be	00/00		
FSt	USr/inS	stopped.	°C/°F	-58.0302	6.0
		The value may be positive or negative Fan start temperature.			
Fot	inS	If the temperature read by the evaporator probe is lower than the set value, the fans	°C/°F	-58.0302	-50.0
1 00	1110	remain off.	0/ 1	-50.0502	-30.0
FAd	USr/inS	Fans activation differential	°C/°F	0.125.0	1.0
Fdt		Fans activation delay after a defrost cycle	min	0255	0
dt		dripping time. Dripping time.	min	0255	0
ut		Operating mode of evaporator fans during defrost.	111111		-
dFd	USr/inS	n (0) = no (depending on the FCO parameter); y (1) = yes (fan off).	flag	n/y	у
				<u> </u>	

PAR.	LEV.	_		DESCRIPTION		U.M.	RANGE	DEFAULT
		Evaporator fans operating mode. The status of the fans will be:						
		FCO	COMPRESSOR ON	COMPRESSOR OFF	Notes			
		0	Thermostat controlled	OFF	_			
		1		Thermostat controlled	_			
FCO	USr/inS	2		Thermostat controlled		num	04	1
	00.70				controlled via parameters			
		3	Thermostat controlled	duty-cycle	FOn and FOF			
		4	Thermostat controlled	duty-cycle	controlled via parameters			
		4	Thermostat controlled	duty-cycle	FOn and FOF			
		_						_
FdC	inS		tor fans switch-off dela			min	0255	0
FOn	inS				s used in duty-cycle mode;	min	0255	0
			o FCO = 3,4 (duty-cycl		and the distance of a second			
FOF	inS			laytime duty-cycle. Far	ns used in duty-cycle mode;	min	0255	0
			o FCO = dc ser Fans					
SCF	inS		ser fans activation Setp	ooint		°C/°F	-50.0150.0	10.0
dCF	inS		ser fans activation diffe			°C/°F	-30.030.0	2.0
tCF	inS		ser fans switch-on dela			min	059	0
	: 0		n of condenser fans du			floor.	m h s	
dCd	inS	n (0)= fa	ns running during defro	ost; y (1) = fans exclude	ed;	flag	n/y	n
				ALAF	RMS parameters (ALr)			
		Paramet	ters HAL and LAL mode	e intended as the abso	lute temperature value or			
		different	ial in relation to the Set	point.	·			
V 11	:0	(0) = a	absolute value				0/4	
Att	inS	(1) = r	relative value			flag	0/1	0
		NOTE: I	n case of relative value	s (par. Att=1), the HAL	parameter should be set to			
			values, while the LAL p					
AFd	USr/inS	Alarms o	arms cut-in differential.				0.125.0	1.0
		Probe 1 maximum alarm. Temperature value (intended either as distance from						
HAL	USr/inS			e based on Att) above	which the probe will trigger	°C/°F	LA1302	50.0
		activatio	n of the alarm signal.	aratura valua (intandas	l as distance from saturint or			
LAL	USr/inS	Probe 1 minimum alarm. Temperature value (intended as distance from setpoint or as an absolute value based on Att) under which the probe will trigger activation of				°C/°F	-58.0HA1	-50.0
LAL	031/1113	the alarn		Att) under which the pr	obe will trigger activation of	0/ 1	-50.011A1	-50.0
			clusion time after devi	ce is switched on follow	ving a power failure.	l .		
PAO	USr/inS		ameter refers to high/lo			hours	010	3
dAO	USr/inS		ature alarm exclusion ti	<u> </u>	•	min	0255	60
040	LIC-/i-C	Alarm in	dication delay (high an	d low temperature) follo	owing deactivation of digital	la a coma	0 10	4
OAO	USr/inS		ort closed).	. ,	·	hours	010	1
tdO	USr/inS	Door ope	en alarm activation dela	ау.		min	0255	10
tAO	USr/inS		eceding temperature a			min	0255	0
IAO	001/1110	1	ameter refers to high/lo	· · · · · · · · · · · · · · · · · · ·	LAL and HAL only	111111	0255	0
			dicating end of defrost	as a result of timeout.				
dAt	inS	` '	larm is not triggered			flag	n/y	n
			riggers the alarm.					
			ors inhibited by externa					
rLO	inS		es not inhibit any resou			num	0/1/2	0
			npressor and defrost bl					
			npressor, defrost and fa	ans biocked				
AOP	inS		utput polarity: m active and output dis	sahled		flag	01	1
AOI	1110		m active and output en			liay	01	'
			ration of temperature al		3:			
			robe 1 (cold room)	ann on probe 1 and/or	.			
PbA	inS		robe 3 (display)			num	03	0
, .			robes 1 and 3 (cold roc	om and display)			33	
			robes 1 and 3 (cold roo		ternal threshold			
SA3	inS	Probe 3	alarm set point			°C/°F	-58.0302.0	0.0
dA3	inS		alarm differential			°C/°F	-300300	2.0
tA3	inS	Delay tin	ne for alarm signal on	probe 3		min	059	0

PAR.	LEV.	DESCRIPTION	U.M.	RANGE	DEFAULT
ArE	inS	Enables alarm relay in the event of probe 3-related alarms: 0 = does not enable alarms in the event of alarms/errors on probe 3 1 = enables the alarm relay in the event of alarms/errors on all probes 2 = enables the alarm relay ONLY in the event of alarms/errors on probe 3	num	02	0
Art	inS	Regulator alarm type. 0 = regulation of temperature alarms disabled with door open; 1 = temperature alarms enabled with door open.	num	01	0
		LIGHTS & DIGITAL INPUTS parameters	(Lit)		
dSd	inS	Light relay / door switch interlock. dd2 n (0) = door opening does not switch on the light; y (1) = door opening switches on the light (if it was off).	flag	n/y	у
dLt	inS	Delay preceding deactivation (switch-off) of light relay (interior light). The interior light remains on for dLt minutes when the door is closed if parameter dSd is set to 'yes'.	min	031	0
OFL	inS	Light relay always deactivated by light key. Enables switching off with cold room light switch even if the delay after closing the door set by dLt is enabled. n (0) = no y (1) = yes.	flag	n/y	у
dOd	inS	Enable utility switch-off on activation of door switch. 0 = disabled 1 = disable fans 2 = disable compressor 3 = disable fans and compressor	num	03	1
dAd	inS	Activation delay for digital inputs DI1, DI2	min	0255	0
di3	inS	Activation delay for digital inputs DI3	min	0255	0
dOA	inS	Forced action of digital input (if PEA ≠ 0): 0 = activate compressor 1 = activate fans 2 = activate compressor and fans 3 = disable compressor 4 = disable fans 5 = disable compressor and fans	num	05	0
PEA	inS	Selection of digital input configured to inhibit/enable resources. 0 = function disabled 1 = associated with door switch 2 = associated with external alarm 3 = associated with external alarm and door switch	num	03	0
dCO	inS	Compressor activation/deactivation delay when enabled.	min	0255	0
dOC	inS	Compressor switch-off delay from acknowledgement.	min	0255	0
dFO	inS	Fan activation/deactivation delay when enabled.	min	0255	0
PEn	inS	Number of errors allowed per pressure switch input. 0= disabled.	num	015	15
PEi	inS	Pressure switch error count interval.	min	199	99
01i 02i	inS	Activation delay for digital inputs DI1. Only if dAd ≠ 0. Activation delay for digital inputs DI2. Only if dAd ≠ 0.	min	0250 0250	0
UZI	inS	NIGHT AND DAY (nAd) parameters	min	0200	0

If the Night & Day regulator is enabled (via key or DI), both weekday and weekend defrost management is active (see parameters dE1...dE8, F1...F8): parameter E3 can be used for every day to establish which defrosts to activate.

If the Night & Day regulator has not been enabled, only weekday defrosts dE1...dE8 will be run

Folder consisting of 7 sub-folders: d0, d1, d2, d3, d4, d5, d6 and d7(°), each of which contain the following parameters. (°) NOTE: it is advisable to consider the first day d0 as SUNDAY. 'd7' can be used to program daily events which are valid for all days

	Functions enabled during events.	5 = enable reduced setpoint*.
	0 = events management disabled	6 = enable reduced set+light*.
E0	1 = enable reduced setpoint	7 = enable reduced set+light+aux*.
	2 = enable reduced set+light	8 = enable stand-by*.
	3 = enable reduced set+light+aux	* disables the buzzer; the alarms and alarm relay continue to run
	4 = enable stand-by	as per the programming

PAR.	LEV.	DESCRIPTION	U.M.	RANGE	DEFAULT
		Start of event hours/minutes. Sets event start time based on the value of E0.			
E1		The "NIGHT" mode begins at this time.			
-'		The duration is determined by parameter E2			
		In hours and minutes (in the parameter table, the parameter is split into E1_h (ho	urs), E1_min (n	ninutes))	
E2		Duration of event. Sets the duration of the event starting as programmed in E1, b	ased on the val	ue of E0	
		In hours			
		Enable defrost weekdays or weekends:			
		0 = "weekdays" defrost sequence defined by parameters dE1dE8.			
E3		1 = "weekends/holidays" defrost sequence defined by parameters F1F8.			
		NOTE: This regulator can be enabled by key (see para. H32H37=11) or by		ee paraH1	1H13=16)
		Note: for the daily event 'd7', this parameter is ignored (it is not possible to mana	ge defrosts)		
d0_E0	inS	Enable functions during events day 1 (SUNDAY)	num	80	0
d0_E1_h	inS	Event start time (hours) day 1	hours	023	0
0_E1_min	inS	Event start time (minutes) day 1	min	059	0
d0_E2	inS	Event duration day 1	hours	072	0
d0_E3	inS	Enable defrost weekdays or weekends day 1	flag	01	0
d1_E0	inS	Enable functions during events day 2	num	08	0
d1_E1_h	inS	Event start time (hours) day 2	hours	023	0
1_E1_min	inS	Event start time (minutes) day 2	min	059	0
d1_E2	inS	Event duration day 2	hours	072	0
d1_E3	inS	Enable defrost weekdays or weekends day 2	flag	01	0
d2_E0	inS	Enable functions during events day 3	num	08	0
d2_E1_h	inS	Event start time (hours) day 3	hours	023	0
2_E1_min	inS	Event start time (minutes) day 3	min	059	0
d2_E2	inS	Event duration day 3	hours	072	0
d2_E3	inS	Enable defrost weekdays or weekends day 3	flag	01	0
d3_E0	inS	Enable functions during events day 4	num	08	0
d3_E1_h	inS	Event start time (hours) day 4	hours	023	0
3_E1_min	inS	Event start time (minutes) day 4	min	059	0
d3_E2	inS	Event duration day 4	hours	072	0
d3_E03	inS	Enable defrost weekdays or weekends day 4	flag	01	0
d4_E0	inS	Enable functions during events day 5	num	08	0
d4_E1_h	inS	Event start time (hours) day 5	hours	023	0
4_E1_min	inS	Event start time (minutes) day 5	min	059	0
d4_E2	inS	Event duration day 5	hours	072	0
d4_E3	inS	Enable defrost weekdays or weekends day 5	flag	01	0
d5_E0	inS	Enable functions during events day 6	num	08	0
d5_E1_h	inS	Event start time (hours) day 6	hours	023	0
5 E1 min	inS	Event start time (minutes) day 6	min	059	0
d5_E2	inS	Event duration day 6	hours	072	0
d5 E3	inS	Enable defrost weekdays or weekends day 6	flag	01	0
d6_E0	inS	Enable functions during events day 7 (SATURDAY)	num	08	0
d6_E1_h	inS	Event start time (hours) day 7	hours	023	0
6_E1_min	inS	Event start time (minutes) day 7	min	059	0
d6_E2	inS	Event duration day 7	hours	072	0
d6_E3	inS	Enable defrost weekdays or weekends day 7	flag	01	0
d7_E0	inS	Enable functions during daily event (EVERY DAY)	num	08	0
d7_E1_h	inS	Daily event start time (EVERY DAY)	hours	023	0
7_E1_min	inS	Daily event start time (minutes) (EVERY DAY)	min	059	0
d7_E2	inS	Daily event duration (EVERY DAY)	hours	072	0
d7_E3	inS	Enable daily defrost weekdays or weekends (EVERY DAY)	flag	01	0
		COMMUNICATION parameters (Add)			
		Protocol selection.			
PtS	inS	t (0) = Televis	flog	t	d (msk 812)
FIS	IIIO		flag	d	t (msk 554)
		d (1) = ModBUS			1
dEA	inS	Device address: indicates the device address to the management protocol.	num	014	0
FAA	inS	Family address: indicates the device family to the management protocol.	num	014	0
Adr	inS	ModBUS protocol controller address (only if PtS = d).	num	1250	1
		Set the ModBUS parity bit (only if PtS = d).		n	E / 040
Pty	inS	n (0) = none	num	Е	E (msk 812)
7		E (1) = parity		0	n (msk 554)
		o (2) = disparity			
		ModBUS stop bit: 1b=1 bit; 2b=2 bit		1b - 2b	1b

PAR.	LEV.	DESCRIPTION	U.M.	RANGE	DEFAULT
bAU	inS	Baudrate selection. 96 (0) = 9600 192 (1) = 19200 384 (2) = 38400	num	96 192 384	96
		DISPLAY parameters (diS)			
LOC	USr/inS	LOCk. Setpoint edit lock. The parameter programming menu can still be accessed, and the settings changed, which means also that the status of this parameter can be changed so as to unlock the keypad. $n\ (0) = no$ $y\ (1) = yes.$	flag	n/y	n
PA1	USr/inS	PAssword 1. When enabled (PA1 \neq 0) this password provides access to level1 parameters (User).	num	0255	0
PA2	inS	PAssword 2. When enabled (PA2 \neq 0), this password provides access to level2 parameters (Installer).	num	0255	15
PA3	inS	PAssword 3. When enabled (PA3 \neq 0), this is the access key used to clear HACCP alarms in the Functions menu.	num	0255	0
ndt	USr/inS	Display values with decimal point. n (0) = no (integers only) y (1) = yes (display with decimal point).	flag	n/y	у
CA1	USr/inS	Calibration of probe Pb1. Positive or negative temperature value added to the value read by Pb1. This sum is used for both temperature display and temperature regulation purposes.	°C/°F	-30.030.0	0.0
CA2	USr/inS	Calibration of probe Pb2. Positive or negative temperature value added to the value read by Pb2. This sum is used for both temperature display and temperature regulation purposes.	°C/°F	-30.030.0	0.0
CA3	inS	Calibration of probe Pb3. Positive or negative temperature value added to the value read by Pb3. This sum is used for both temperature display and temperature regulation purposes.	°C/°F	-30.030.0	0.0
CA	inS	Offset activation on display, thermoregulation or both: 0 = only the temperature shown is modified 1 = only the temperature used by the regulators is modified; the display remains unchanged. 2 = temperature displayed is modified, which is also the one used by the regulators.	num	0/1/2	2
LdL	inS	Minimum value that can be displayed by the device.	°C/°F	-58.0HdL	-50.0
HdL	inS	Maximum value that can be displayed by the device.	°C/°F	LdL302	140.0
ddL	USr/inS	Display mode during defrost. 0 = displays the temperature read by probe 1 = locks the reading at the temperature value registering via the probe when the defrost cycle starts and until the next time the SEt is reached 2 = displays label dEF during defrosts and until the SEt is reached (or until Ldd elapses)	num	0/1/2	1
Ldd	inS	Timeout value for display unlock - label dEF.	min	0255	0
dro	inS	Selection of °C or °F to display the probe value. 0= °C, 1= °F. NOTE: switching between °C and °F or vice-versa DOES NOT modify the setpoint, differential, etc. (e.g. setpoint = 10°C becomes 10°F).	flag	0/1	0
ddd	inS	Selects the type of value to show in the display. 0 = Setpoint 1 = probe Pb1 will be used 2 = probe Pb2 will be used 3 = probe Pb3 will be used	num	03	1
dd2	inS	PARAMETER ONLY VISIBLE IN HACCP MODELS Selects the type of value to show in the display 0 = Setpoint 1 = RCC	num	0/1	1
		HACCP ALARM parameters (HAC)			
		FOLDER ONLY VISIBLE IN HACCP MODELS			

PAR.	LEV.	DESCRIPTION	U.M.	RANGE	DEFAULT
Shi	inS	"Instant" maximum HACCP alarm indication threshold: when the temperature value read by the temperature control probe goes beyond the range set in "SHi", an HACCP alarm is immediately triggered, with the icon/(alarm relay) coming on according to parameter H50 (see specific section).		SHH150.0	35.0
Sli	inS	The differential when returning from the alarm condition is fixed at 0.1°C/°F. "Instant" minimum HACCP alarm indication threshold: when the temperature value read by the temperature control probe goes beyond the range set in "SLi", an HACCP alarm is immediately triggered, with the icon/(alarm relay) coming on according to parameter H50 (see specific section). The differential when returning from the alarm condition is fixed at 0.1°C/°F.	°C/°F	-50.0SLH	-35.0
SHH	inS	Maximum HACCP alarm indication threshold: when the temperature value displayed by the temperature control probe is outside the range set by the value of "SHH" for longer than the time set in parameter "drA", an HACCP alarm is triggered, with the icon/(alarm relay) coming on according to parameter H50 (see specific section). The differential when returning from the alarm condition is fixed at 0.1°C/°F.	°C/°F	SLH150.0	30.0
SLH	inS	Minimum HACCP alarm indication threshold: when the displayed temperature value of the temperature control probe is outside the range set by the value of "SLH" for longer than the time set in parameter "drA", an HACCP alarm is triggered, with the icon/(alarm relay) coming on according to parameter H50 (see specific section). The differential when returning from the alarm condition is fixed at 0.1°C/°F.	°C/°F	-50.0SHH	-30.0
drA	inS	Minimum dwelling time in critical area for the event to be recorded: one this time has elapsed it is saved and an HACCP alarm generated.	min	099	10
drH	inS	HACCP alarm reset time from last reset: this is the time that must pass once the instrument has been switched on before any recorded alarms are cleared automatically. If the parameter is set to 0, automatic reset is inhibited and only manual reset is enabled.	hours	0255	0
H50	inS	Enable HACCP alarms storage with or without alarm relay enabling: NOTE. SWITCH THE INSTRUMENT OFF AND ON AGAIN AFTER MODIFYING PARAMETER H50 • 0 = HACCP alarms disabled • 1 = HACCP alarms enabled and alarm relay NOT enabled • 2 = HACCP alarms enabled and alarm relay enabled	num	02	0
H51	inS	HACCP alarms storage disabling time (key or DI) In minutes	min	0255	0
H52	inS	Probe enabled to signal HACCP alarms: 1=probe 1; 3=probe 3;	flag	1/3	1
		CONFIGURATION parameters (CnF) If one or more parameters present in the folder are changed, the control switched on again.	ler <u>MUST</u> I	be switched of	f and
H00	Usr/inS	Selection of type of probe used (Pb1Pb3). (0) = PTC (1) = NTC	num	0/1	1
H01	inS	Enable deep cooling function n (0) = not enabled; y (1) =enabled.	flag	n/y	n
H02	inS	Activation time for keypad functions	S	015	3
H06	inS	Key or digital input configured as AUX/LIGHT on with device in stand-by n (0)=not active; y (1)=active;	flag	n/y	У
H08	inS	Stand-by operating mode. 0 = the display is off and the regulators on, the device signals any alarms by reactivating the display. 1 = the display is on, plus all regulators including alarms 2 = the display is off, plus all regulators are locked including alarms 3 = the top display shows the label "OFF", plus all regulators are locked including alarms	num	0/1/2/3	3

PAR.	LEV.	DESCRIPTION	U.M.	RANGE	DEFAULT
		Configuration of digital input 1/polarity.			
		NOTE: - The "+" sign indicates that the input is active when the contact			
		- The "-" sign indicates that the input is active when the contact	ct is open		
		±10 = Maximum pressure switch			
		0 = disabled ±11 = General pressure switch ±1 = defrost ±12 = Preheat			
		\pm 1 = defrost \pm 12 = Preheat \pm 2 = Reduced set \pm 13 = Force evaporator fans			
		± 2 - Reduced set ± 15 - Force evaporator rans ± 3 = Auxiliary AUX ± 14 = Activate light relay			
H11	inS	± 4 = Door microswitch ± 15 = Activate Frame Heater relay	num	-22+22	4
		± 5 = external alarm ± 16 = Enable/disable	110111		
		± 6 = Disable HACCP Night And Day functions			
		alarm logging ±17 = Deep cooling cycle			
		± 7 = Stand-by ±18 = Panic alarm			
		± 8 = NOT USED ±19 = Reset HACCP alarms			
		± 9 = Minimum pressure ± 20 = Pressure switch Pump Down	1		
		switch ±21 = Leak Detector			
H12	inS	±22 = Start/Stop remote defrost Configuration of 2/polarity digital input. Same as H11.	num	-22+22	0:300/500
			num		5 : 5000
H13	inS	Configuration of 3/polarity digital input. Same as H11. Configuration of digital output 1 (OUT 1)	num	-22+22	0
		0 = disabled			
		1 = Compressor (cooling) 8 = Buzzer output			
		2 = Defrost 9 = Evaporator 2			
H21	inS	3 = Fans 10 = Compressor 2	num	num 013	1
		4 = Alarm 11 = Frame Heater			
		5 = AUX 12 = Condenser fans			
		6 = Stand-by 13 = Compressor Pump Down			
H22	inS	7 = Light Configuration of digital output 2 (OUT 2). Same as H21	num	013	2
H23*	USr/inS	Configuration of digital output 2 (OOT 2). Same as H21	num	013	3
		PARAMETER ONLY VISIBLE IN MODELS 500 and 5000	Hulli		
H24	inS	Configuration of digital output 4 (OUT 4). Same as H21 PARAMETER ONLY VISIBLE IN MODELS 500 and 5000	num	013	7
H25	inS		num	013	4
		Configuration of digital output 5 (OUT 5). Same as H21			
H28	inS	Enable buzzer. (0) = output disabled	num	013	8
1120	1110	(8) = output enabled	Ilulii	013	
		Configuration of DOWN key			
		0 = disabled			
		1 = defrost	or roley		
		2 = Auxiliary 10 = Activate / disable Frame Heate 11 = Enable/disable Night And Day			
		3 = Activate reduced set	Turicuoris		
H32	inS	4 = Reset HACCP alarms 13 = Clear voltage drop errors	num	015	2
		5 = Disable HACCP alarms 6 = Light (Reset Power Failure)			
		7 - Stand by			
		8 = NOT USED 15 = Activate economy set + Night A	And Day		
		9 = Evaporator fans ON			
H33	inS	ESC key configuration. Same as H32.		015	1
H34	inS	ON/OFF key configuration. Same as H33.	num	015	7
H35	inS	LIGHT key configuration. Same as H34.	num	015	6
H41	inS	Presence of Cold Room probe Pb1	flag	n/y	у
1111	n= not present; y= present.		liug	111,9	J
H42	USr/inS	Presence of Evaporator probe Pb2	flag	n/y	у
2	00/////0	n= not present; y= present.	liag liag	.",	, j
H43	inS	Presence of probe Pb3 n= not present; y= present; 2EP= second evaporator; 3-1= regulation on Pb1 or on Pb3-Pb1 differe	num	n/y/2EP/3-1	n
		ZEF = Second evaporator, S-1 = regulation on PD1 or on PD3-PD1 differe	IIudi		

PAR.	LEV.	DESCRIPTION		U.M.	RANGE	DEFAUL
H44	inS	Setpoint for Pb3-Pb1 temperature differential. Sets the Pb3-Pb1 differential If H43=3-1, regulation of the temperature differential betwe in addition to regulation of probe Pb1, is enabled. In this wa regulation, one or both of the two conditions must be met (ay, to activate compressor on Pb1 or Pb3-Pb1	°C/°F	0255	0.0
		differential). The differential is defined by H44. To disable the conditions must be met, so: Output enabled if: Output not enabled if: Pb1 <set (pb3-pb1)="" and="" applications="" defrost="" double="" evaporator:<="" for="" mode="" start="" td="" with=""><td>o1) > H44+diF < H44</td><td></td><td></td><td></td></set>	o1) > H44+diF < H44			
H45	inS	0 = Defrost is enabled by checking only that the temperature lower than the value set in parameter dSt. 1 = Defrost is enabled, checking that the readings from at laprobes is below its defrosting end temperature (dST for evalue evalue) evalues are laprost is enabled, checking that both probe values are	east one of the two aporator 1 and dS2 for	num	0/1/2	0
		defrost end setpoints (dSt for evaporator 1 and dS2 for eva				
H48	inS	PARAMETER ONLY VISIBLE IN HACCP MODELS Clock presence.		flag	n/y	y
		(0) = no clock			•	
rEL	USr/inS	(1) = clock present. Firmware version release (e.g. 1,2,). Read only. See Technical Support.	1	1	1	/
tAb	USr/inS	Map code. Read only. See Technical Support.	1	1	1	1
H60	inS	Display of selected application. 0 = no vector selected; 1 = vector 1,, 6 = vector 6. It has a subset of parameters which can be programmed in configuration required for the installation. By setting H60, the user can also select one of the six 'sets parameters. If you do not want to enable any of the availab use the programming menu values, simply set parameter F The parameters corresponding to the different programs ar of the table	s' of pre-programmed le setpoints, but prefer to 160 to 0.	num	06	0
		FRAME HEATER parameters (FrH)				
		The Frame Heater function can be selected by key or by D				
		This function can be associated to all relay outputs (by sett H21H25 = 11) and can be used to actuate "Duty-cycle" re				
HOn	inS	intervals set by parameters HOn and HOF. Frame Heater regulator output ON time		min	0255	0
HOF	inS	Frame Heater regulator output OFF time		min	0255	0
dt3	inS	Frame Heater regulator time standard unit of measurement 0=hours; 1=minutes; 2=seconds	! :	num	02	0
		COPY CARD parameters (FPr)				·
UL		Upload. To transfer programming parameters from instrume Card.	ent to UNICARD / Copy	1	/	1
dL		Download. To transfer programming parameters from UNIC instrument.	CARD / Copy Card to	1	1	1
Fr		Formatting. Deletes data on UNICARD / Copy Card. NOTE: If parameter "Fr" is used, the data entered will be put in the operation cannot be reversed.	ermanently lost.	1	1	1

7.3.1. Parameter H60

Display of selected application.

0=no vector selected; **1**= application 1, ..., **6**= application 6. It has a subset of parameters which can be programmed in line with the type of configuration required for the installation. By setting **H60**, the user can also select one of the six 'sets' of pre-programmed parameters. If you do not want to enable any of the available setpoints, but prefer to use the programming menu values, simply set parameter **H60** to 0.

The parameters corresponding to the different programs are described at the bottom of the table

	parameter H60	=1	=2	=3	=4	=5	=6
SEt	Temperature control SEtpoint		2.0	-18.0	2.0	-18.0	5.0
diF	Activation differential (absolute or relative)	2.0	2.0	2.0	2.0	2.0	2.0
LSE	Maximum value that can be assigned to the setpoint	-50.0	-5.0	-25.0	-5.0	-25.0	2.0
HSE	Minimum value that can be assigned to the setpoint	50.0	5.0	-15.0	5.0	-15.0	10.0
dSt	Defrost end temperature	6.0	10.0	15.0	10.0	15.0	10.0
FSt	Fans disabling temperature	6.0	8.0	-5.0	8.0	-5.0	50.0
dty	Defrost mode	0	1	1	0	0	0
dit	Defrost cycle enabling delay from request	6	6	6	6	6	6
dCt	Defrost interval count mode	1	1	1	1	1	1
dOH	Defrost cycle enabling delay from request	0	0	0	0	0	0
dEt	Defrost timeout	30	15	15	30	30	15
Fdt	Fans activation delay after a defrost cycle	3	1	2	1	2	0
dt	dripping time. Dripping time	0	2	2	2	2	0
dPO	PO Defrost enabling request from power-on		0	0	0	0	0
ddL	Display mode during defrost	1	0	0	0	0	0
dFd	Operating mode of evaporator fans during defrost	1	1	1	1	1	1

8.1. ALARMS AND SIGNALS TABLE

When an alarm condition is detected, the ALARM icon will come on

If present and enabled, the buzzer and alarm relay will also activate.

To silence the buzzer, press and release any key, the relative icon will continue to flash.

All alarms are reset automatically (i.e. they disappear when the issue that caused them is removed).

The alarm codes are as follows:

Code	Description	Alarm relay	Reset	Parameters used to ENABLE ALARM
E1	Pb1 probe error	active	Automatic	Ont, OFt
E2	Pb2 probe error	active	Automatic	Ont, OFt
E3	Pb3 probe error	active	Automatic	Ont, OFt
HA1	HIGH temperature alarm	active	Automatic	SP1, Att, AFd, HAL, LAL, PAO, dAO, OAO, tAO
LA1	LOW temperature alarm	active	Automatic	SP1, Att, AFd, HAL, LAL, PAO, dAO, OAO, tAO
EAL	External alarm	active	Automatic	PEA, rLO
OPd	Door open alarm	not active	Automatic	PEA, tdO
Ad2	Defrost end due to timeout	not active	Automatic	dEt, dE2, dAt
PAn	Panic alarm	not active	Automatic	
ALd	leak detector alarm	not active	Automatic	
Prr	Preheat alarm	not active	Automatic	
E10	Clock alarm	not active	Automatic	
PA	General pressure switch alarm	not active	Manual	PEn, PEi
LPA	Low pressure switch alarm	not active	Manual	PEn, PEi
HPA	High pressure switch alarm	not active	Manual	PEn, PEi

NOTES:

- 1. If alarm exclusion times have been set (see "ALr" folder in the Parameters table) the alarm will not be indicated.
- 2. With the exception of faulty probe alarms, all other alarms will record the corresponding label in the ALr folder (press LIP key)
- 3. Faulty probe alarms will be indicated on the display by means of label E1, E2, E3 depending on whether the fault relates to probe Pb1, Pb2 or Pb3 respectively
- 4. In the event of an overlap between the "Panic" alarm and the "Refrigerant leakage" alarm, priority is given to the "Panic Alarm" with its operating modes. Both alarm codes can in any case be viewed in the alarms folder.

8.2. ALARM CAUSE/EFFECT TABLE

EWRC 300/500/5000 NT can run integral diagnostics on the installation, signalling any operating faults with specific alarms found, and record and signal any user-defined unusual events to have greater control over the system as a whole.

Label	Description	Cause	Effects	Remedy
E1	Probe Pb1 in error	Measured values are outside operating range probe errors/short-circuited/open	Label E1 displayed Alarm icon permanently alight	Check probe type (H00) Check probe wiring Replace probe
E2	Probe Pb2 in error	Measured values are outside operating range probe errors/short-circuited/open	Label E2 displayed Alarm icon permanently alight	Check probe type (H00) Check probe wiring Replace probe
E3	Probe Pb3 in error	Measured values are outside operating range probe errors/short-circuited/open	Label E3 displayed Alarm icon permanently alight	Check probe type (H00) Check probe wiring Replace probe
HA1	HIGH temperature Temperature 1	value read by probe 1 > HA1 after time equal to tAO. (see "MAX/MIN TEMP. MAX/MIN)	Label HA1 recorded in folder ALr No effect on regulation	Wait until value read by the probe returns below HA1-AFd.
LA1	LOW temperature Temperature 1	Value read by probe 1 < LA1 after time equal to tAO. (see "MAX/MIN TEMP. MAX/MIN)	Label LA1 recorded in folder ALr No effect on regulation	Wait until value read by the probe returns above LA1+AFd.
НА3	HIGH temperature Temperature 3		Recording of label HA3 in folder ALr No effect on regulation	Wait for value read by probe to return with PbA = 1 or 2 below threshold of HAL-AFd.
		with PbA = 3 and dA3> 0 Value of probe Pb3> SA3 plus tA3 time		with PbA = 3 and dA3> 0 below threshold of SA3-dA3.
LA3	LOW temperature Temperature 3	with PbA = 1 or 2 Value read by probe Pb3< LAL after time equal to tAO.	Recording of label LA3 in folder ALr No effect on regulation	Wait for value read by probe to return with PbA = 1 or 2 above threshold of LAL-AFd.
		with PbA = 3 and dA3< 0 Value of probe Pb3< SA3 plus tA3 time		with PbA = 3 and dA3< 0 above threshold of SA3-dA3.
EAL	Alarm External	Digital input activated	• Alarm Icon nermanently alignt	Check and remove external cause of alarm on DI
OPd	Alarm Door Open	Digital input activated (for a time greater than tdO)	Recording of label OPd in folder ALr Alarm icon permanently alight Lockout of regulation as requested by dOd	Close the door Delay preceding defined alarm signal by OAO.
Ad2	End Defrost due to timeout	end of defrost cycle due to timeout rather than due to defrost end temperature being read by Pb2.	Recording of label Ad2 in folder ALr Alarm icon permanently alight	Await next defrost cycle for automatic return to normal
Prr	Alarm Preheat	Alarm for preheat input regulator ON	Label Prr recorded in folder ALr Compressor icon blinking Regulation inhibited (Compressor and Fans) NOTE: defrost will also be inhibited if it is hot gas defrost.	Preheat input regulator off
E10	Alarm Clock	Clock faulty Extended period without power	Recording of label E10 in folder ALr Functions associated with clock not managed	Connect the instrument to the power supply.

Label	Description	Cause	Effects	Remedy
P01 P99	Alarm general pressure switch	Pressure switch alarm activation by general pressure switch regulator.	If the number n of pressure switch activations is n <pen: (compressor="" activations="" and="" fans)<="" inhibited="" number="" of="" pressure="" recorded="" regulation="" switch="" td=""><td>Check and remove external cause of alarm on DI (Automatic Reset).</td></pen:>	Check and remove external cause of alarm on DI (Automatic Reset).
PA	Alarm general pressure switch	Pressure switch alarm activation by general pressure switch regulator.	If the number n of pressure switch activations is n=PEn: Label PA displayed Recording of label PA in folder ALr Alarm icon permanently alight Regulation inhibited (Compressor and Fans)	Switch the device off and back on again Reset alarms using the rPA key (Manual Reset)
L01 L99	Alarm low pressure switch	Activation of pressure switch alarm by minimum pressure switch regulator.	If the number n of pressure switch activations is n <pen: (compressor="" activations="" and="" fans)<="" inhibited="" number="" of="" pressure="" recorded="" regulation="" switch="" td=""><td>Check and remove external cause of alarm on DI (Automatic Reset).</td></pen:>	Check and remove external cause of alarm on DI (Automatic Reset).
LPA	Alarm minimum pressure switch	Activation of pressure switch alarm by minimum pressure switch regulator.	If the number n of pressure switch activations is n=PEn: Label LPA displayed Recording of label LPA in folder ALr Alarm icon permanently alight Regulation inhibited (Compressor and Fans)	Switch the device off and back on again Reset alarms using the rPA key (Manual Reset)
H01 H99	Alarm high pressure switch	Activation of pressure switch alarm by maximum pressure switch regulator.	If the number n of pressure switch activations is n <pen: (compressor="" activations="" and="" fans)<="" inhibited="" number="" of="" pressure="" recorded="" regulation="" switch="" td="" •=""><td>Check and remove external cause of alarm on DI (Automatic Reset).</td></pen:>	Check and remove external cause of alarm on DI (Automatic Reset).
HPA	Alarm maximum pressure switch	Activation of pressure switch alarm by maximum pressure switch regulator.	If the number n of pressure switch activations is n=PEn: Label PHPA displayed Recording of label HPA in folder ALr Alarm icon permanently alight Regulation inhibited (Compressor and Fans)	Switch the device off and back on again Reset alarms using the rPA key (Manual Reset)
PAn	Panic alarm	Activation of appropriately configured digital input	Recording of PAn label in ALr folder PANIC Alarm icon steadily on Alarm icon steadily on Temperature control is NOT inhibited when the alarm is active	Check and remove external cause of alarm on DI (Automatic Reset).
ALd	Alarm Refrigerant Leak	Activation of appropriately configured digital input	Recording of ALd label in ALr folder Panic Alarm icon blinking Alarm icon steadily on Intermittent buzzer sounding Temperature control is NOT inhibited when the alarm is active	Check and remove external cause of alarm on DI (Automatic Reset).
ALL ALARMS • Alarm icon permanently alight • Buzzer (if present) and alarm relay (OUT5) activated, except Ad2 • Press any key to mute the alarm. The icon changes from steady to blinking. NOTE: the buzzer is deactivated while the alarm relay remains active *E1 - E2: If simultaneous they will be shown alternately on the display at a frequency of 2 seconds			REFRIGERANT LEAK ALARM (LEAK DETECTION OF Blinking alarm icon and Alarm icon steadily of the Intermittent sounding of buzzer (if present) and Press any key to mute the alarm. In this case blinking to steady while the alarm icon will blinking the alarm icon will be alarm icon wil	on on one of the control of the cont

8.3. DESCRIPTION OF ALARMS

8.3.1. PROBE alarm

OPERATING CONDITIONS

When one of the probes is out of the nominal operating range or in the case of an open probe or a probe in short circuit, an alarm is generated if this condition persists for longer than 10 seconds.

The alarm condition is indicated on the display by means of the following error codes:

- E1 = Pb1 probe error
- E2 = Pb2 probe error
- E3 = Pb3 probe error

The alarm icon and alarm relay are activated. Codes **E1**, **E2**, **E3**, when occurring at the same time, are shown in the following sequence: E1 x 2 seconds, E2 x 2 seconds, E3 x 2 seconds, etc.

ACTIONS ON CURRENT REGULATION

For all probes, the probe error condition causes the following actions:

- the display shows code Ex (where x = 1, 2, 3)
- · activation and permanent display of alarm icon and activation of alarm relay (if present)

When the faulty probe condition ceases, regulation resumes as normal.

During the probe error, the defrost interval count continues as normal.

SIGNALLING

Code	Meaning
E1	Probe Pb1 error
E2	Probe Pb2 error
E3	Probe Pb3 error

ALARM ACKNOWLEDGEMENT

In the alarm condition, it is possible to acknowledge the alarm and/or relay configured as an alarm, even if the alarm condition persists, by pressing any key or using the corresponding function in the menu. The alarm icon will start to blink. Eliminating the cause of the alarm disarms the acknowledgement.

The probe alarm error is not stored by the controller.

USER PARAMETERS

Label	Description	
Ont	ON time for compressor output with control probe error	
OFt	OFF time for compressor output with control probe error	

8.3.2. MINIMUM AND MAXIMUM TEMPERATURE alarm

OPERATING CONDITIONS

The alarm regulation is carried out on probe 1. The temperature limits defined in parameters **HAL** and **LAL** are determined by parameter **Att** which specifies if they represent the absolute temperature value or a setpoint differential (in the case of offset on the entered setpoint, the high and low alarms will refer to this new control set point).

- If Att=0 Ab(solute), the temperature limits for probe 1/3 are absolute.
- If Att=1 rE(lative) , the temperature limits for probe 1/3 refer to the Setpoint SEt

NOTE: to obtain the minimum alarm below the setpoint in the case of Att=1 (relative) set LAL < 0

ALARM CONDITIONS

A maximum/minimum alarm is generated when the Pb1 temperature is:

Maximum alarm: ≥ HAL if Att=Ab(solute) and ≥ (SEt + HAL) if Att=rE(lative)
 Minimum alarm: ≤ LAL if Att=Ab(solute) and ≤ (SEt + LAL) if Att=rE(lative)

IfAtt=Ab(solute) the values of HAL and LAL must be with sign, if Att=rE(lative) it is necessary that HAL > 0 and LAL < 0.


When one of the two aforementioned conditions occurs, if no alarm override times apply (see alarm override parameters), the alarm icon lights up and the relay configured as alarm activates (if present).


The maximum/minimum alarm will be reset when the temperature of probe 1/2 is:

• Reset from maximum alarm: ≤ (HAL - AFd) if Att=Ab(solute) and ≤ (SEt + HAL - AFd) if Att=rE(lative)

• Reset from minimum alarm: ≥ (LAL + AFd) if Att=Ab(solute) and ≥ (SEt + LAL + AFd) if

Att=rE(lative)





NOTES:

- During a defrost cycle, high and low temperature alarms are overridden.
- Occurrence of this alarm does not effect any regulation in progress.

SIGNALLING

Code	Meaning
HA1	HIGH temperature alarm, refers to probe
LA1	LOW temperature alarm, refers to probe

ALARM ACKNOWLEDGEMENT

In the alarm condition, it is possible to acknowledge the relay configured as an alarm (if present), even if the alarm condition persists, by pressing any key or using the corresponding function in the menu. The alarm icon will start to blink. Eliminating the cause of the alarm disarms the acknowledgement.

The probe alarm error is not stored by the controller.

HIGH AND LOW TEMPERATURE ALARM OPERATION WITH DOOR OPEN

- If Art = 0 (regulation of temperature alarms disabled with door open)
 - 1. If the door is open and there is no temperature alarm, the alarms are inhibited and cannot be activated;
 - 2. If the door is opened, the temperature alarm must continue;
 - 3. If the temperature alarm is triggered and the door is open, the temperature alarm will cease when the reset conditions return.
- If Art = 1 (temperature alarms enabled with door open)
 - 1. If the door is open, the temperature alarms are not inhibited and can be activated if the required conditions are in place. The delay **OAO**, referred to the previous closing of the door, is not counted.
 - 2. If a temperature alarm is triggered with the door closed, on opening the door the temperature alarm must continue.
 - 3. If the temperature alarm is present with the door open, the temperature alarm will cease when the reset conditions return.

USER PARAMETERS

Label	Description
Att	HAL and LAL parameter mode (absolute or relative)
AFd	Alarm activation differential
HAL	Probe maximum alarm threshold
LAL	Probe minimum alarm threshold
PAO	Temperature alarm exclusion time from power-on
dAO	Temperature alarm disabling time after defrost cycle
OAO	High/low temperature alarm exclusion time after door closing
tAO	Temperature alarms delay time
Art	Regulator alarm type

8.3.3. END OF DEFROST DUE TO TIMEOUT alarm

OPERATING CONDITIONS

The regulator is activated without any delay in the case of end of defrost due to timeout, instead of probe 2 reaching the defrost end temperature.

The action consists of:

- · alarm icon steadily on
- recording of Label Ad2 in the alarms menu.

Automatic reset occurs with the start of the next defrost cycle.

The alarm icon can be switched off using the normal acknowledgement procedure, although the alarm signal is only actually cancelled at the start of the next defrost cycle.

SIGNALLING

Code	Meaning
Ad2	Defrost alarm on Pb2

USER PARAMETERS

Label	Description	
dEt	Evaporator 1 defrost timeout	
dE2	Defrost timeout evaporator 2	
dAt	Alarm signalling end of defrost due to timeout	

8.3.4. EXTERNAL alarm

OPERATING CONDITIONS

In the case of activation of the digital input, the alarm regulator is activated with the delay set by parameter **dAd**, and this alarm persists until the next time the digital input is deactivated.

The action consists of:

- alarm icon steadily on
- recording of Label EAL in the alarms menu.
- Activation of the relay configured as alarm (if enabled)
- deactivation of regulation if parameter **rLO** requires it.

It is possible to mute the alarm relay but the regulators still remain locked until the next time the digital input is deactivated.

The values that **rLO** can be assigned to parameter:

- rLO = 0: an external alarm has not locked any resource;
- rLO = 1: an external alarm has locked the compressor and defrost;
- rLO = 2: an external alarm has locked the compressor, defrost and the fans.

SIGNALLING

Code	Meaning
EAL	External alarm

USER PARAMETERS

Label	Description
rLO	An external alarm blocks the regulators

8.3.5. DOOR OPEN alarm

OPERATING CONDITIONS

The door switch alarm is associated to a specially configured digital input:

• H11, H12, H13 = ± 4

On activation of the digital input (door open) and after delay **tdO** has elapsed, the door open alarm must be signalled in the alarms folder and the icon and alarm relay should come on. The label **OPd** is displayed.

The action consists of:

- · alarm icon steadily on
- recording of Label OPd in the alarms menu.
- · Activation of the relay configured as alarm

As in the case of the other alarms, the relay may be disabled by pressing an acknowledgement key, the alarm icon will blink and label **OPd** will remain in the alarms menu until the door is closed.

If the door is opened, the regulator will operate on the basis of the value of parameter **dOd**. The values that can be assigned to it are:

- dOd = 0: no resource is locked:
- dOd = 1: fans are locked (FAN):
- dOd = 2: the compressor is locked (COMPR);
- dOd = 3: both the fans (FAN) and compressor (COMPR) are locked

If the door open alarm locks the compressor, it can still be reactivated even if the door remains open, by setting the parameter **dCO**.

SIGNALLING

Code	Meaning
OPd	Door open alarm

USER PARAMETERS

Label	Description
dOd	Digital input for switching off loads: 0 = disabled; 1 = disables the fans; 2 = disables the compressor; 3 = disables fans and compressor.
dCO	Compressor activation delay from acknowledgement
tdO	Open door disabling time

8.3.6. PRESSURE SWITCH INPUT alarm

OPERATING CONDITIONS

The pressure switch is associated with a suitably configured Digital Input and can be general, minimum or maximum.

NOTE: behaviour and configuration parameters are the same for all three types.

Every time pressure switch input activation causes the compressor/fans to be disabled instantly, with only visual indication of the activation (WARNING) provided via illumination of the alarm icon and recording of the number of pressure switch activations that have taken place.

If the pressure switch Digital Input is deactivated, the compressor starts up again and the alarm icon switches off, but the alarm folder still contains the number of activations recorded in the previous counting interval (defined using parameter PEi). Once the number of activations set in parameter PEn has been reached PA (general), LPA (minimum) or HPA (maximum) will appear on the display.

Compressor, fans and defrosts are deactivated, the alarm icon lights up and the alarm relay comes on if configured. Once the device has entered alarm mode, it must be switched off and on again, or a key-activated reset performed using the function **rPA** (reset pressure switch alarm) on the functions menu.

NOTA: **PEn** represents the number of pressure switch activations within the interval defined in parameter PEI, which determines activation of alarm mode and deactivation of the compressor, fan and defrost outputs If **PEn = 0** the function is excluded and the pressure switch alarm is ignored.

SIGNALLING

Code	Meaning
PA	General pressure switch alarm
LPA	Minimum pressure switch alarm
HPA	Maximum pressure switch alarm

USER PARAMETERS

Label	Description
PEn	Number of errors allowed per pressure switch input. 0 = disabled.
PEi	Pressure switch error count interval.

8.3.7. PANIC alarm

OPERATING CONDITIONS

The panic alarm is associated to a specially configured digital input:

• H11, H12, H13 = ± 18

After the delay set in parameter dAd, this alarm is activated and persists until the next digital input deactivation. The action consists of:

- · Panic alarm icon steadily on
- · Alarm icon steadily on
- recording of label PAn in the alarms menu.
- activation of the relay configured as alarm (if enabled)

SIGNALLING

С	ode	Meaning
F	PAn	Panic alarm

USER PARAMETERS

Label	Description
dAd	Activation delay DI1, DI2
di3	Activation delay DI3

8.3.8. Leak detector ALARM

OPERATING CONDITIONS

The refrigerant leak (Leak Detector) alarm is associated with an appropriately configured digital input.

• H11, H12, H13 = ± 21

This alarm is activated after the delay set in parameter **di3** and it persists until the next digital input deactivation. The action consists of:

- · Panic alarm icon blinking
- · Alarm icon steadily on
- · intermittent sounding of alarm buzzer
- recording of Label "ALd" in the alarms menu
- · activation of the relay configured as alarm (if enabled)

The alarm relay can be inhibited by pressing any key; this action mutes the buzzer while the icons respond as follows:

- · alarm icon blinking
- · Panic alarm icon steadily on

If the "Leak Detector" alarm occurs in synchrony with the "Panic" alarm, the system response is as follows:

- · Panic alarm icon steadily on
- · Alarm icon steadily on
- · intermittent sounding of buzzer
- \bullet recording of labels "Pan" and "ALd" in the alarms menu

As long as the Panic alarm persists it will not be possible to mute the buzzer from the keypad.

SIGNALLING

Code	Meaning
ALd	Leak Detector Alarm

USER PARAMETERS

Label	Description
dAd	Activation delay DI1, DI2
di3	Activation delay DI3

9. MODBUS MSK 554 /812 FUNCTIONS AND RESOURCES

ModBUS is a client/server protocol for communication between devices connected in a network.

ModBUS devices communicate using a master-slave technique in which only one device (master) can send messages.

The other devices in the network (slave) respond, returning the data requested by the master or executing the action contained in the message sent.

A slave is a device connected to a network that processes information and sends the results to the master using the ModBUS protocol.

The master device can send messages to individual slaves or to the entire network (broadcast) whilst slaves can only respond individually to the master.

The ModBUS standard used by Eliwell employs the RTU code for data transmission.

9.3.1. DATA FORMAT (RTU)

The coding model used defines the structure of messages transmitted on the network and the way in which this information is deciphered. The type of coding is usually selected on the basis of specific parameters (baudRate, parity, etc.); furthermore, some devices support only specific coding models, although it must be the same one for all devices connected in a ModBUS network.


The protocol uses the RTU binary method with bytes configured as follows: 8 bits for data (non-configurable), parity bit none, 1 stop BIT.

Parameter setting allows the integral configuration of the device

Changes can be made via:

- · Device keypad
- UNICARD / Copy Card
- data via Modbus protocol directly to an individual controller or broadcasting it, using the address 0 (broadcast)

9.3.2. NETWORK



9.3.3. ModBUS COMMANDS AVAILBLE AND DATA AREAS

The following commands are implemented:

ModBUS command	Comma	and description									
03 (hex 0x03)	Read 16	ead 16 consecutive registers for Client side.									
04 (hex 0x04)	Read 1	Read 1 single register for parameters.									
16 (hex 0x10)	Write 15	consecutive regist	ters for Client side								
22 (hex 0x16)	Write 1 r	egister for the para	ameters								
43 (hex 0x2B)	Read device ID. It is possible to read the following 3 fields:										
		Field code Field description									
		0	Manufacturer ID (="Invensys")								
								1	Device model/polycarbonate ID format: 00FB_0401 PCH = 251 (FB hex) POLI = 1025 (0401 hex)		
		2	Device family (MSK554)/version ID format: 022A_0259 MSK = 554 (22A hex) REL = 0601 (259 hex)								

9.3.4. ADDRESS CONFIGURATION

The serial TTL - which we will call COM1 - can be used to configure the device, parameters, states, and variables with ModBUS via the ModBUS protocol.

The address of a device within a ModBUS message is set using the parameter Adr.

The address 0 is used for broadcast messages that all slaves recognise. Slaves don't respond to broadcast messages. The parameters for configuring the device are:

Parameter	Description	Values	Range
PtS	Select COM1 (TTL) protocol	d (msk 812) t (msk 554)	t = Televis d = ModBUS
Adr	ModBUS protocol controller address	1	1250
Pty	ModBUS protocol parity bit	E (msk 812) n (msk 554)	n= NONEE = EVEN (parity)o = ODD (disparity)
bAU	Baudrate selection.	96	• 96 = 9600 baud • 192 = 19200 baud • 384 = 38400 baud

NOTE: for correct operation, the controller must be switched off and switched on again after modification

9.3.5. PARAMETER VISIBILITY AND VALUES

NOTE:

- 1) When not indicated otherwise, the parameter is always visible and modifiable, unless customised settings have been configured by the user via serial
- 2) If folder visibility is modified, the new setting will apply to all parameters in the folder.

9.3.6. MODBUS TABLES

The tables below list all information required to read, write and decode all accessible resources in the device. There are 3 tables:

- the "PARAMETER TABLE" contains all device configuration parameters stored in the controller's non-volatile memory, including visibility
- the "FOLDER VISIBILITY TABLE (FOLDER)" indicates the visibility of the folders containing the parameters
- the "CLIENT TABLE" includes all I/O and alarm status resources available in the volatile memory of the instrument.

Description of the columns:

FOI DER

Indicates the label of the folder containing the parameter in question

I ARFI

Indicates the label used to display the parameters in the menu of the controller.

PAR. VALUE ADDRESS

The whole part represents the address of the ModBUS register containing the value of the resource to be read or written in the controller. The value after the decimal point indicates the position of the most significant data bit inside the register; if not indicated it is taken to be zero. This information is always provided when the register contains more than one information item, and it is necessary to distinguish which bits actually represent the data (the working size of the data indicated in the column DATA SIZE is also taken into consideration).

Given that the ModBUS registers have the size of one WORD (16 bit), the index number after the point can vary from 0 (least significant bit -LSb-) to 15 (most significant bit -MSb-).

Examples (in binary form the least significant bit is the first on the right):

PAR. VALUE ADDRESS	DATA SIZE	Value	Content of register					
8806	WORD	1350	1350	(0000010101000110)				
8806	BYTE	70	1350	(00000101 01000110)				
8806.8	BYTE	5	1350	(00000101 01000110)				
8806.14	1 BIT	0	1350	(0 0 00010101000110)				
8806.7	4 BIT	10	1350	(00000 1010 1000110)				

IMPORTANT: when the register contains more than one piece of data, the writing procedure is as follows:

- · Read current value of register
- · Modify bits for the resource concerned
- · Write register

VIS PAR. ADDRESS

The same as above. In this case, the ModBUS register address contains the visibility value of the parameter. By default all parameters have:

Data size
Range
**Visibility
U.M.
Data size
2 bit
0...3
mum

**Value Meaning

- Value 3 = parameter or folder always visible
- Value 2 = **installer level**; these parameters can only be viewed by entering the manufacturer password (see parameter PS2) (all parameters specified as always visible, parameters visible at the installer level and manufacturer level will be visible)
- Value 1 = user level; these parameters can only be viewed by entering the installer password (see parameter PS1) (all parameters specified as always visible and parameters visible at the installer level will be visible)

Value 0 = parameter or folder NOT visible

- 1. Parameters and/or folders with a level of visibility =1,2 (password-protected) will be visible only if the correct password is entered (installer or user) following this procedure:
- 2. Parameters and/or folders with a level of visibility =3 are always visible even without a password: in this case, the following procedure is not necessary.

Examples (in binary form the least significant bit is the first on the right):

Default visibility:

PAR. VALUE ADDRESS	DATA SIZE	Value	Content of register						
49336.6	2 BIT	3	65535	(00000000 11 11111111111111)					
49337	2 BIT	3	65535	(00000000111111 11 1111111)					
49337.2	2 BIT	3	65535	(000000001111 11 111111111)					
49337.4	2 BIT	3	65535	(0000000011 11 11111111111)					
49337.6	2 BIT	3	65535	(00000000 11 111111111111)					

R/W

Indicates the option of reading or writing the resource

R The resource is read-only W The resource is write-only

RW The resource can be both read and written

DESCRIPTION

This is the description of the meaning of parameters in the LABEL column.

DATA SIZE

Indicates the size of the data in bits.

WORD = 16 bit Byte = 8 bit

"n" bit = 0...15 bit based on the value of "n"

CPL

When the field indicates "Y", the value read by the register needs to be converted because the value represents a number with a sign. In the other cases the value is always positive or null.

To carry out conversion, proceed as follows:

- if the value in the register is between 0 and 32,767, the result is the value itself (zero and positive values)
- if the value in the register is between 32,768 and 65,535, the result is the value of the register 65,536 (negative values)

EXP

WHEN UTILISING MODBUS PROTOCOL ONLY

If = -1 the value read by the register is divided by 10 (value/10) to convert it to the values indicated in the RANGE and DEFAULT columns using the unit of measure indicated in the column U.M.

Example: parameter HSE = 50.0. Column EXP = -1:

- The value read by the device /DeviceManager is 50.0
- The value read by the register is 500 --> 500/10 = 50.0

RANGE

Describes the interval of values that can be assigned to the parameter. It can be correlated with other parameters in the instrument (indicated with the parameter label).

U.M

Unit of measure for values converted according to the rules indicated in the CPL and EXP columns.

9.3.7. PARAMETER/VISIBILITY table

NOTE: ModBUS read command: 04 (0x04) and ModBUS write command: 22 (0x16)

FOLDER	LABEL	PAR. Value ADDRESS	Vis. Par.address	R/W	DESCRIPTION	DATA SIZE	CPL	EXP	MU	RANGE
1	SEt	16386	49455	RW	Setpoint	WORD	Υ		°C/°F	LSEHSE
CPr	diF	16388	49455,2	RW	Setpoint differential	WORD	Υ	-1	°C/°F	030.0
CPr	HSE	16390	49455,4	RW	Maximum setpoint value that can be set	WORD	Y	-1	°C/°F	LSEHdL
CPr	LSE	16392	49455,6	RW	Minimum setpoint value that can be set	WORD	Y	-1	°C/°F	LdLHSE
CPr	OSP	16394	49456	RW	Offset on setpoint	WORD	Υ	-1	°C/°F	-30.030.0
CPr	Cit	49235	49456,4	RW	Minimum compressor output activation time	BYTE		-	min	0255
CPr	CAt	49236	49456,6	RW	Maximum compressor output activation time	BYTE		-	min	0255
CPr	Ont	49237	49457	RW	ON time for compressor output with control probe error	BYTE			min ·	0255
CPr	OFt	49238	49457,2	RW	OFF time for compressor output with control probe error	BYTE			min	0255
CPr	dOn	49239	49457,4	RW	Compressor output activation delay from request	BYTE			S .	0255
CPr	dOF	49240	49457,6	RW	Compressor output activation delay from shutdown Delay between two consecutive starts of the	BYTE		-	min	0255
CPr	dbi	49241	49458	RW	compressor output	BYTE			min	0255
CPr	OdO	49242	49458,2	RW	Output activation delay from power-on	BYTE			min	0255
CPr	dSC	49243	49458,4	RW	Compressor 2 activation delay	BYTE			S	0255
CPr	dCS	16396	49458,6	RW	Deep Cooling setpoint	WORD	Υ	-1	°C/°F	-58.0302.0
CPr	tdc	16398	49459	RW	Deep Cooling Duration	WORD			min	0600
CPr	dcc	49244	49459,2	RW	Delay defrost after Deep Cooling	BYTE			min	0255
dEF	dty	49245	49459,4	RW	Defrost mode	BYTE		ļ	num	02
dEF	dit	49246	49459,6	RW	Interval between defrost cycles	BYTE			hrs/min/s	0255
dEF	dt1	49247	49460	RW	Unit of measure for defrost interval	BYTE			num	0/1/2
dEF	dt2	49248	49460,2	RW	Unit of measurement for defrost duration	BYTE			num	0/1/2
dEF	dCt	49249	49460,4	RW	Defrost interval count mode	BYTE			num	03
dEF	dOH	49250	49460,6	RW	Defrost interval count mode	BYTE			min	059
dEF	dEt	49251	49461	RW	Evaporator 1 defrost timeout	BYTE			hrs/min/s	1255
dEF	dSt	16400	49461,2	RW	Probe 1 defrost end temperature	WORD	Υ	-1	°C/°F	-58.0302.0
dEF	dS2	16402	49461,4	RW	Probe 2 defrost end temperature	WORD	Υ	-1	°C/°F	-58.0302.0
dEF	dE2	49252	49461,6	RW	Defrost timeout evaporator 2	BYTE			hrs/min/s	1250
dEF	dPO	49253	49462	RW	Defrost activation request from power-on Minimum compressor ON or OFF time in mins. before	BYTE			flag	0/1
dEF	tcd	16404	49462,2	RW	defrost Time preceding a defrost, during which the compressor	WORD	Y		min	-3131
dEF	Cod	49254	49462,4	RW	output is not activated	BYTE			min	060
dEF	dE1_h	49341		RW	Defrost start time (minutes) no. 1 weekday	BYTE			hours	024
dEF	dE1_min	49340		RW	Defrost start time (hours) no. 2 weekday	BYTE			min	059
dEF	dE2_h	49343		RW	Defrost start time (minutes) no. 2 weekday	BYTE			hours	024
dEF	dE2_min	49342		RW	Defrost start time (hours) no. 3 weekday	BYTE			min	059
dEF	dE3_h	49345		RW	Defrost start time (minutes) no. 3 weekday	BYTE			hours	024
dEF	dE3_min	49344		RW	Defrost start time (hours) no. 4 weekday	BYTE			min	059
dEF	dE4_h	49347		RW	Defrost start time (minutes) no. 4 weekday	BYTE			hours	024
dEF	dE4_min	49346		RW	Defrost start time (hours) no. 5 weekday	BYTE			min	059
dEF	dE5_h	49349		RW	Defrost start time (minutes) no. 5 weekday	BYTE			hours	024
dEF	dE5_min	49348		RW	Defrost start time (hours) no. 6 weekday	BYTE			min	059
dEF	dE6_h	49351		RW	Defrost start time (minutes) no. 6 weekday	BYTE			hours	024
dEF	dE6_min	49350		RW	Defrost start time (hours) no. 7 weekday	BYTE			min	059
dEF	dE7_h	49353		RW	Defrost start time (minutes) no. 7 weekday	BYTE			hours	024
dEF	dE7_min	49352		RW	Defrost start time (hours) no. 8 weekday	BYTE			min	059

FOLDER	LABEL	PAR. Value ADDRESS	Vis. Par.address	R/W	DESCRIPTION	DATA SIZE	CPL	EXP	MD	RANGE
dEF	dE8_h	49355		RW	Defrost start time (minutes) no. 8 weekday	BYTE			hours	024
dEF	dE8_min	49354		RW	Weekday defrost 3 duration	BYTE			min	059
dEF	F1_h	49357		RW	Defrost start time (hours) no. 1 weekend	BYTE			hours	024
dEF	F1_min	49356		RW	Defrost start time (minutes) no. 1 weekend	BYTE			min	059
dEF	F2_h	49359		RW	Defrost start time (hours) no. 2 weekend	BYTE			hours	024
dEF	F2_min	49358		RW	Defrost start time (minutes) no. 2 weekend	BYTE			min	059
dEF	F3_h	49361		RW	Defrost start time (hours) no. 3 weekend	BYTE			hours	024
dEF	F3_min	49360		RW	Defrost start time (minutes) no. 3 weekend	BYTE			min	059
dEF	F4_h	49363		RW	Defrost start time (hours) no. 4 weekend	BYTE			hours	024
dEF	F4_min	49362		RW	Defrost start time (minutes) no. 4 weekend	BYTE			min	059
dEF	F5_h	49365		RW	Defrost start time (hours) no. 5 weekend	BYTE			hours	024
dEF	F5_min	49364		RW	Defrost start time (minutes) no. 5 weekend	BYTE			min	059
dEF	F6_h	49367		RW	Defrost start time (hours) no. 6 weekend	BYTE			hours	024
dEF	F6_min	49366		RW	Defrost start time (minutes) no. 6 weekend	BYTE			min	059
dEF	F7_h	49369		RW	Defrost start time (hours) no. 7 weekend	BYTE			hours	024
dEF	F7_min	49368		RW	Defrost start time (minutes) no. 7 weekend	BYTE			min	059
dEF	F8_h	49371		RW	Defrost start time (hours) no. 8 weekend	BYTE			hours	024
dEF	F8_min	49370		RW	Defrost start time (minutes) no. 8 weekend	BYTE			min	059
FAn	FPt	49255	49463	RW	FSt parameter mode	BYTE			flag	0/1
FAn	FSt	16406	49463,2	RW	Fan disabling temperature	WORD	Υ	-1	°C/°F	-58.0302.0
FAn	Fot	16408	49463,4	RW	Evaporator fans start temperature	WORD	Υ	-1	°C/°F	-58.0302.0
FAn	FAd	16410	49463,6	RW	Fans differential	WORD		-1	°C/°F	0.125.0
FAn	Fdt	49256	49464	RW	Fan activation delay from compressor start	BYTE			min	0255
FAn	dt	49257	49464,2	RW	Dripping time	BYTE			min	0255
FAn	dFd	49258	49464,4	RW	Evaporator fans mode in defrost	BYTE			flag	0/1
FAn	FCO	49259	49464,6	RW	Evaporator fans mode	BYTE			num	04
FAn	FdC	49261	49465,2	RW	Fan switch-off delay from compressor stoppage	BYTE			min	0255
FAn	FOn	49262	49465,4	RW	Fans ON time in duty-cycle	BYTE			min	0255
FAn	FOF	49263	49465,6	RW	Fans OFF time in duty-cycle	BYTE			min	0255
FAn	SCF	16412	49466	RW	Condenser fans activation Setpoint	WORD		-1	°C/°F	-50.0150.0
FAn	dCF	16414	49466,2	RW	Condenser fans activation differential	WORD		-1	°C/°F	-30.030.0
FAn	tCF	49264	49466,4	RW	Condenser fans switch-on delay after defrost	BYTE			min	059
FAn	dCd	49265	49466,6	RW	Condenser fans exclusion during defrost	BYTE			flag	0/1
AL AL	Att AFd	49266 16416	49467	RW RW	HAL and LAL parameter mode	BYTE WORD		-1	flag °C/°F	0/1
			49467,2		Alarm setpoint differential		Υ	-1	°C/°F	0.150.0
AL	HAL LAL	16418 16420	49467,4	RW	Maximum alarm	WORD	Y	-1	°C/°F	LA1302.0
AL AL	PAO	49267	49467,6 49468	RW	Minimum alarm	WORD BYTE	ľ	-1		-58.0HA1
AL	dAO	16422	49468,2	RW	Alarm exclusion at power-on Alarm exclusion after defrost	WORD		\vdash	hours min	010 0255
AL	OAO	49268	49468,4	RW		BYTE				0255
AL	tdO	49268 49269	49468,4	RW	Alarm signalling delay from door closure Open door disabling time	BYTE		\vdash	hours	010
AL	tAO	49269	49468,6	RW	Temperature alarms signalling delay	BYTE		\vdash	min min	0255
AL	dAt	49270	49469,2	RW	Enable alarm at end of defrost	BYTE		\vdash	flag	0255
AL	rLO	49271	49469,2	RW	External alarm switches off loads	BYTE		\vdash	num	0/1/2
AL	AOP	49273	49469,6	RW	Alarm output polarity	BYTE		\vdash	flag	0/1/2
AL	PbA	49275	49470,2	RW	Probe enabled to signal temperature alarms	BYTE		Н	num	03
AL	SA3	16424	49470,4	RW	(probe 1 and/or 3)	WORD	Y	-1	°C/°F	-50.0150.0
\vdash	dA3			RW	Alarm set point related to probe 3		Y	-1 -1	°C/°F	
AL	tA3	16426 49276	49470,6 49471	RW	Probe 3 alarm tripping differential Alarm 3 signalling delay time	WORD BYTE	T	-	min	-30.030.0 059

FOLDER	LABEL	PAR. Value ADDRESS	Vis. PAR.ADDRESS	R/W	DESCRIPTION		CPL	EXP	UM	RANGE
AL	ArE	49277	49471,2	RW	Enables alarm relay in the event of probe 3-related alarms	BYTE			num	0/1/2
AL	Art	16655	49491,4	RW	Regulator alarm type	BYTE			num	0/1
Lit	dSd	49278	49471,4	RW	Enable light relay from door switch	BYTE			flag	0/1
Lit	dLt	49279	49471,6	RW	Light relay deactivation delay	BYTE			min	031
Lit	OFL	49280	49472	RW	Light key always disables light relay	BYTE			flag	0/1
Lit	dOd	49281	49472,2	RW	Door switch switches off loads	BYTE			num	03
Lit	dAd	49282	49472,4	RW	Delay activating digital inputs DI1, DI2	BYTE			min	0255
Lit	di3	49283	49472,6	RW	Delay to activate digital input DI3	BYTE			min	0255
Lit	dOA	49285	49473,2	RW	Action forced by digital input	BYTE			num	05
Lit	PEA	49286	49473,4	RW	Select DI for lock/unlock resources function	BYTE			num	03
Lit	dCO	49287	49473,6	RW	Evaporator fan compressor activation/switch-off delay	BYTE			min	0255
Lit	dOC	49260	49465	RW	Compressor switch-off delay from acknowledgement	BYTE			min	0255
Lit	dFO	49288	49474	RW	Evaporator fan activation/switch-off delay	BYTE			min	0255
Lit	PEn	49334	49474,2	RW	Number of errors permitted	BYTE			num	015
Lit	PEi	49335	49474,4	RW	Error count interval	BYTE			min	199
Lit	01i	16658	49487,2	RW	Delay activating digital input DI1	BYTE			min	0250
Lit	O2i	16659	49487,3	RW	Delay to activate digital input DI2	BYTE			min	0250
nAd	d0_E0	49372		RW	Enable functions during events day 1 (SUNDAY)	BYTE			num	08
nAd nAd	d0_E1_h	49397 49396		RW	Event start time (hours) day 1	BYTE BYTE			hours	023
	d0_E1_m d0_E2	49390		RW	Event start time (minutes) day 1	BYTE			min	059 072
nAd nAd	d0_E2 d0_E3	49388		RW	Event duration day 1 Enable defrost weekdays or weekends day 1	BYTE			hours flag	012
nAd	d0_E3 d1_E0	49373		RW	Enable functions during events day 2	BYTE			num	08
nAd	d1_E1_h	49399		RW	Event start time (hours) day 2	BYTE			hours	023
nAd	d1_E1_m	49398		RW	Event start time (minutes) day 2	BYTE			min	059
nAd	d1_E2	49381		RW	Event duration day 2	BYTE			hours	072
nAd	d1_E3	49389		RW	Enable defrost weekdays or weekends day 2	BYTE			flag	01
nAd	d2_E0	49374		RW	Enable functions during events day 3	BYTE			num	08
nAd	d2_E1_h	49401		RW	Event start time (hours) day 3	BYTE			hours	023
nAd	d2_E1_m	49400		RW	Event start time (minutes) day 3	BYTE			min	059
nAd	d2_E2	49382		RW	Event duration day 3	BYTE			hours	072
nAd	d3_E3	49390		RW	Enable defrost weekdays or weekends day 3	BYTE			flag	01
nAd	d3_E0	49375		RW	Enable functions during events day 4	BYTE			num	80
nAd	d3_E1_h	49403		RW	Event start time (hours) day 4	BYTE			hours	023
nAd	d3_E1_m	49402		RW	Event start time (minutes) day 4	BYTE			min	059
nAd	d3_E2	49383		RW	Event duration day 4	BYTE			hours	072
nAd	d3_E3	49391		RW	Enable defrost weekdays or weekends day 4	BYTE	-		flag	01
nAd	d4_E0	49376		RW	Enable functions during events day 5	BYTE			num	80
nAd	d4_E1_h	49405		RW	Event start time (hours) day 5	BYTE			hours	023
nAd	d4_E1_m d4_E2	49404 49384		RW	Event start time (minutes) day 5 Event duration day 5	BYTE BYTE	-		min	059
nAd nAd	04_E2 d4_E3	49384		RW	Enable defrost weekdays or weekends day 5	BYTE	-		hours flag	072
nAd	d5_E0	49392		RW	Enable deficit weekdays of weekends day 5 Enable functions during events day 6	BYTE	-		num	08
nAd	d5_E1_h	49377		RW	Event start time (hours) day 6	BYTE			hours	023
nAd	d5_E1_m	49406		RW	Event start time (minutes) day 6	BYTE			min	059
nAd	d5_E2	49385		RW	Event duration day 6	BYTE			hours	072
nAd	d5_E3	49393		RW	Enable defrost weekdays or weekends day 6	BYTE			flag	01
nAd	d6_E0	49378		RW	Enable functions during events day 7 (SATURDAY)	BYTE			num	08

FOLDER	LABEL	PAR. Value ADDRESS	Vis. PAR.ADDRESS	R/W	DESCRIPTION	DATA SIZE	CPL	EXP	NU	RANGE
nAd	d6_E1_h	49409		RW	Event start time (hours) day 7	BYTE			hours	023
nAd	d6_E1_m	49408		RW	Event start time (minutes) day 7	BYTE			min	059
nAd	d6_E2	49386		RW	Event duration day 7	BYTE			hours	072
nAd	d6_E3	49394		RW	Enable defrost weekdays or weekends day 7	BYTE			flag	01
nAd	d7_E0	49379		RW	Enable functions during daily event (EVERY DAY)	BYTE			num	08
nAd	d7_E1_h	49411		RW	Daily event start time	BYTE			hours	023
nAd	d7_E1_m	49410		RW	Daily event start time (minutes)	BYTE			min	059
nAd	d7_E2	49387		RW	Duration of daily event	BYTE			hours	072
nAd	d7_E3	49395		RW	Enable defrost weekdays or weekends daily event	BYTE			flag	01
Add	PtS	49289	49474,6	RW	Protocol selection (0: Televis; 1: ModBUS)	BYTE			flag	0/1
Add	dEA	49290	49475	RW	Device address, Micronet	BYTE			num	014
Add	FAA Adr	49291 49422	49475,2 49453,6	RW	Family address, Micronet ModBUS address	BYTE BYTE			num	014 1255
Add Add	Pty	49422	49455,6	RW	Parity bit (ModBUS protocol)	BYTE			num	0/1/2
Add	Pty	49292	49475,6	RW	ModBUS stop bit	BYTE			num num	0/1/2
Add	bAU	49421	49454	RW	BaudRate	BYTE			num	0/1/2
diS	LOC	49294	49476	RW	Keypad lock	BYTE			flag	0/1/2
diS	PS1	16428	49476,2	RW	Password 1	WORD			num	0999
diS	PS2	16430	49476,4	RW	Password 2	WORD			num	0999
diS	PS3	16432	49476,6	RW	Password 3	WORD			num	0999
diS	ndt	49295	49477	RW	Display with decimal point	BYTE			flag	0/1
diS	CA1	16434	49477,2	RW	Calibration Pb1	WORD	Υ		°C/°F	-30.030.0
diS	CA2	16436	49477,4	RW	Calibration Pb2	WORD	Υ		°C/°F	-30.030.0
diS	CA3	16438	49477,6	RW	Calibration Pb3	WORD	Υ		°C/°F	-30.030.0
diS	CA	49296	49478	RW	Calibration operation	BYTE			num	0/1/2
diS	LdL	16440	49478,2	RW	Minimum possible value	WORD	Υ		°C/°F	-58.0HdL
diS	HdL	16442	49478,4	RW	Maximum possible value	WORD	Υ		°C/°F	LdL302
diS	ddL	49297	49478,6	RW	Lock display during defrost	BYTE			num	0/1/2
diS	Ldd	49298	49479	RW	Unlock timeout "ddL"	BYTE			minutes	0255
diS	dro	49299	49479,2	RW	°C/°F selection. (0=°C, 1=°F)	BYTE			flag	0/1
diS	ddd	49300	49479,4	RW	Selection of main display value 1	BYTE			num	0/1/2
diS	dd2	49420	49491,2	RW	Selection of main display value 2	BYTE			flag	0/1
HAC	SHi	16444	49479,6	RW	Maximum HACCP alarm threshold, no delay	WORD	Υ	-1	°C/°F	SHH150.0
HAC	SLi	16446	49480	RW	Minimum HACCP alarm threshold, no delay	WORD	Y	-1	°C/°F	-50.0SLH
HAC	SHH	16448	49480,2	RW	Maximum HACCP alarm threshold	WORD	Y	-1	°C/°F	SLH150.0
HAC	SLH	16450	49480,4	RW	Minimum HACCP alarm threshold Minimum dwelling time in critical area before alarm	WORD	Υ	-1	°C/°F	50.0SHH
HAC	drA	49301	49480,6	RW	signalling	BYTE			min	099
HAC	drH	49302	49481	RW	HACCP alarm reset time from last manual reset	BYTE			hours	0255
HAC	H50	49303	49481,2	RW	Enable HACCP alarms storage with/without alarm relay enabling	BYTE			num	0/1/2
HAC	H51	49304	49481,4	RW	HACCP alarms storage disabling time (key or digital input)	BYTE			min	0255
HAC	H52	49305	49481,6	RW	Probe enabled to signal HACCP alarms	BYTE			flag	1/3
CnF	H00	49306	49482	RW	Probe type Pb1-Pb2-Pb3 (1=NTC, 0=PTC)	BYTE			flag	0/1
CnF	H01	49307	49482,2	RW	Enable deep cooling	BYTE			flag	0/1
CnF	H02	49308	49482,4	RW	Key activation time	BYTE			S	015
CnF	H06	49309	49482,6	RW	Key or auxiliary digital input/light on with device Off	BYTE	Υ		flag	0/1
CnF	H08	49310	49483	RW	Stand-by mode	BYTE			num	03
CnF	H11	16452	49483,2	RW	DI1 input configuration	BYTE	Υ		num	-2222

FOLDER	LABEL	PAR. Value ADDRESS	Vis. PAR.ADDRESS	R/W	DESCRIPTION	DATA SIZE	CPL	EXP	Wn	RANGE
CnF	H12	16454	49483,4	RW	DI2 input configuration	BYTE	Υ		num	-2222
CnF	H13	16456	49483,6	RW	DI3 input configuration	BYTE	Υ		num	-2222
CnF	H21	49311	49484,2	RW	Configuration relay 1	BYTE			num	013
CnF	H22	49312	49484,4	RW	Configuration Relay 2	BYTE			num	013
CnF	H23	49313	49484,6	RW	Configuration Relay 3	BYTE			num	013
CnF	H24	49314	49485	RW	Configuration Relay 4	BYTE			num	013
CnF	H25	49315	49485,2	RW	Configuration Relay 5	BYTE			num	013
CnF	H28	49318	49486	RW	Enable buzzer	BYTE			flag	0/1
CnF	H32	49320	49486,4	RW	Configuration of DOWN key	BYTE			num	015
CnF	H33	49321	49486,6	RW	ESC key configuration	BYTE			num	015
CnF	H34	49322	49487	RW	ON/OFF key configuration	BYTE			num	015
CnF	H35	49323	49487,2	RW	LIGHT key configuration	BYTE			num	015
CnF	H41	49327	49488,2	RW	Pb1 input configuration	WORD			flag	0/1
CnF	H42	49328	49488,4	RW	Pb2 input configuration	WORD			flag	0/1
CnF	H43	49329	49488,6	RW	Pb3 input configuration	WORD			num	n, y , 2EP, 3-1
CnF	H44	49330	49489	RW	Setpoint for Pb3-Pb1 temperature differential	WORD			num	0255
CnF	H45	49331	49489,2	RW	Start defrost mode for applications with double evaporator	WORD			num	02
CnF	H48	49332	49489,4	RW	Clock presence	WORD			flag	0/1
CnF	H60	49333	49489,6	R	Preset selection (Parameters vector selector)	WORD			num	80
CnF	rEL			R	Device version	WORD			num	03
CnF	tAb			R	Map code	WORD			num	03
FrH	HOn	49336	49490,4	RW	Frame Heater regulator output On time	BYTE			min	0255
FrH	HOF	49337	49490,6	RW	Frame Heater regulator output Off time	BYTE			min	0255
FrH	dt3	49338	49491	RW	Frame Heater regulator time standard unit of measurement	BYTE			num	0/1/2
FPr	UL				Parameter transfer function visibility (Controller -> UNICARD / Copy Card)	2 BIT			num	03
FPr	dL				Parameter transfer function visibility (UNICARD / Copy Card -> Controller)	2 BIT			num	03
FPr	Fr				UNICARD / Copy Card formatting function visibility	2 BIT			num	03

9.3.8. PARAMETER/VISBILITY H60 table

LABEL	PAR. Value ADDRESS	Vis. Par.ad- Dress	RW	DESCRIPTION	DATA SIZE	MU	RANGE
V0-SEt	16752		RW	Regulation set point	WORD	°C/°F	LSEHSE
V0-diF	16754		RW	Setpoint differential	WORD	°C/°F	0.130.0
V0-LSE	16756		RW	Minimum setpoint value that can be set	WORD	°C/°F	LSEHdL
V0-HSE	16758		RW	Maximum setpoint value that can be set	WORD	°C/°F	LdLHSE
V0-dSt	16760		RW	Defrost end temperature	WORD	°C/°F	-58.0302.0
V0-FSt	16762		RW	Evaporator fans status with OFF compressor output	WORD	°C/°F	-50.0150.0
V0-dty	49532		RW	Defrost mode	BYTE	num	0/1/2
V0-dit	49533		RW	Interval between defrost cycles	BYTE	min	0255
V0-dCt	49534		RW	Defrost interval count mode	BYTE	num	03
V0-dOH	49535		RW	Defrost cycle enabling delay from request	BYTE	min	059
V0-dEt	49536		RW	Defrost timeout	BYTE	hrs/min/s	1255
V0-Fdt	49537		RW	Evaporator fans delay after defrost cycle	BYTE	min	0255
V0-dt	49538		RW	Dripping time	BYTE	min	0255
V0-dPO	49539		RW	Defrost enabling request from power-on	BYTE	flag	0/1
V0-ddL V0-dFd	49540 49541		RW	Lock display during defrost mode Evaporator fans disabling during defrost time	BYTE BYTE	num flag	0/1/2 0/1
V1-SEt	16774		RW	Regulation set point	WORD	°C/°F	LSEHSE
V1-diF	16776		RW	Setpoint differential	WORD	°C/°F	0.130.0
V1-LSE	16778		RW	Minimum setpoint value that can be set	WORD	°C/°F	LSEHdL
V1-HSE	16780		RW	Maximum setpoint value that can be set	WORD	°C/°F	LdLHSE
V1-dSt	16782		RW	Defrost end temperature	WORD	°C/°F	-58.0302.0
V1-FSt	16784		RW	Evaporator fans status with OFF compressor output	WORD	°C/°F	-50.0150.0
V1-dty	49554		RW	Defrost mode	BYTE	num	0/1/2
V1-dit	49555		RW	Interval between defrost cycles	BYTE	min	0255
V1-dCt	49556		RW	Defrost interval count mode	BYTE	num	03
V1-dOH	49557		RW	Defrost cycle enabling delay from request	BYTE	min	059
V1-dEt	49558		RW	Defrost timeout	BYTE	hrs/min/s	1255
V1-Fdt	49559	-	RW	Evaporator fans delay after defrost cycle	BYTE	min	0255
V1-dt	49560		RW	Dripping time	BYTE	min	0255
V1-dPO	49561		RW	Defrost enabling request from power-on	BYTE	flag	0/1
V1-ddL	49562		RW	Lock display during defrost mode	BYTE	num	0/1/2
V1-dFd	49563		RW	Evaporator fans disabling during defrost time	BYTE	flag	0/1
V2-SEt	16796		RW	Regulation set point	WORD	°C/°F	LSEHSE
V2-diF	16798		RW	Setpoint differential	WORD	°C/°F	0.130.0
V2-LSE	16800		RW	Minimum setpoint value that can be set	WORD	°C/°F	LSEHdL
V2-HSE	16802		RW	Maximum setpoint value that can be set	WORD	°C/°F	LdLHSE
V2-dSt	16804		RW	Defrost end temperature	WORD	°C/°F	-58.0302.0
V2-FSt	16806		RW	Evaporator fans status with OFF compressor output	WORD	°C/°F	-50.0150.0
V2-dty	49576		RW	Defrost mode	BYTE	num	0/1/2
V2-dit	49577		RW	Interval between defrost cycles	BYTE	min	0255
V2-dCt	49578		RW	Defrost interval count mode	BYTE	num	03
V2-dOH	49579		RW	Defrost cycle enabling delay from request	BYTE	min	059
V2-dEt	49580		RW	Defrost timeout	BYTE	hrs/min/s	1255
V2-Fdt	49581		RW	Evaporator fans delay after defrost cycle	BYTE	min	0255
V2-dt	49582		RW	Dripping time	BYTE	min	0255
V2-dPO	49583		RW	Defrost enabling request from power-on	BYTE	flag	0/1
V2-ddL	49584		RW	Lock display during defrost mode	BYTE	num	0/1/2

				7			
LABEL	PAR. Value ADDRESS	Vis. PAR.AD- DRESS	R/W	DESCRIPTION	DATA SIZE	MU	RANGE
V2-dFd	49585		RW	Evaporator fans disabling during defrost time	BYTE	flag	0/1
V3-SEt	16818		RW	Regulation set point	WORD	°C/°F	LSEHSE
V3-diF	16820		RW	Setpoint differential	WORD	°C/°F	0.130.0
V3-LSE	16822		RW	Minimum setpoint value that can be set	WORD	°C/°F	LSEHdL
V3-HSE	16824		RW	Maximum setpoint value that can be set	WORD	°C/°F	LdLHSE
V3-dSt	16826		RW	Defrost end temperature	WORD	°C/°F	-58.0302.0
V3-FSt	16828		RW	Evaporator fans status with OFF compressor output	WORD	°C/°F	-50.0150.0
V3-dty	49598		RW	Defrost mode	BYTE	num	0/1/2
V3-dit	49599		RW	Interval between defrost cycles	BYTE	min	0255
V3-dCt	49600		RW	Defrost interval count mode	BYTE	num	03
V3-dOH	49601		RW	Defrost cycle enabling delay from request	BYTE	min	059
V3-dEt	49602		RW	Defrost timeout	BYTE	hrs/min/s	1255
V3-Fdt	49603		RW	Evaporator fans delay after defrost cycle	BYTE	min	0255
V3-dt	49604		RW	Dripping time	BYTE	min	0255
V3-dPO	49605		RW	Defrost enabling request from power-on	BYTE	flag	0/1
V3-ddL	49606		RW	Lock display during defrost mode	BYTE	num	0/1/2
V3-dFd	49607		RW	Evaporator fans disabling during defrost time	BYTE	flag	0/1
V4-SEt	16840		RW	Regulation set point	WORD	°C/°F	LSEHSE
V4-diF	16842		RW	Setpoint differential	WORD	°C/°F	0.130.0
V4-LSE	16844		RW	Minimum setpoint value that can be set	WORD	°C/°F	LSEHdL
V4-HSE	16846		RW	Maximum setpoint value that can be set	WORD	°C/°F	LdLHSE
V4-dSt	16848		RW	Defrost end temperature	WORD	°C/°F	-58.0302.0
V4-FSt	16850		RW	Evaporator fans status with OFF compressor output	WORD	°C/°F	-50.0150.0
V4-dty V4-dit	49620 49621		RW	Defrost mode Interval between defrost cycles	BYTE BYTE	num min	0/1/2 0255
V4-dit V4-dCt	49621		RW	Defrost interval count mode	BYTE		0255
V4-dOH	49623		RW	Defrost cycle enabling delay from request	BYTE	num min	059
V4-dOH V4-dEt	49624		RW	Defrost cycle enabling delay from request	BYTE	hrs/min/s	1255
V4-GEt V4-Fdt	49625		RW	Evaporator fans delay after defrost cycle	BYTE	min	0255
V4-dt	49626		RW	Dripping time	BYTE	min	0255
V4-dPO	49627		RW	Defrost enabling request from power-on	BYTE	flag	0/1
V4-ddL	49628		RW	Lock display during defrost mode	BYTE	num	0/1/2
V4-dFd	49629		RW	Evaporator fans disabling during defrost time	BYTE	flag	0/1
V5-SEt	16862		RW	Regulation set point	WORD	°C/°F	LSEHSE
V5-diF	16864		RW	Setpoint differential	WORD	°C/°F	0.130.0
V5-LSE	16866		RW	Minimum setpoint value that can be set	WORD	°C/°F	LSEHdL
V5-HSE	16868		RW	Maximum setpoint value that can be set	WORD	°C/°F	LdLHSE
V5-dSt	16870		RW	Defrost end temperature	WORD	°C/°F	-58.0302.0
V5-FSt	16872		RW	Evaporator fans status with OFF compressor output	WORD	°C/°F	-50.0150.0
V5-dty	49642		RW	Defrost mode	BYTE	num	0/1/2
V5-dit	49643		RW	Interval between defrost cycles	BYTE	min	0255
V5-dCt	49644		RW	Defrost interval count mode	BYTE	num	03
V5-dOH	49645		RW	Defrost cycle enabling delay from request	BYTE	min	059
V5-dEt	49646		RW	Defrost timeout	BYTE	hrs/min/s	1255
V5-Fdt	49647		RW	Evaporator fans delay after defrost cycle	BYTE	min	0255
V5-dt	49648		RW	Dripping time	BYTE	min	0255
V5-dPO	49649		RW	Defrost enabling request from power-on	BYTE	flag	0/1
V5-ddL	49650		RW	Lock display during defrost mode	BYTE	num	0/1/2
V5-dFd	49651		RW	Evaporator fans disabling during defrost time	BYTE	flag	0/1

9.3.9. FOLDER VISIBILITY TABLE

LABEL	ModBUS	R/W	DESCRIPTION	DATA	RANGE	UM
LADEL	ADDRESS	IT/VV	DESCRIPTION	SIZE	KANGE	Olvi
vis_CPr	49450	RW	Folder visibility	2 bit	03	num
vis_dEF	49450,2	RW	Folder visibility	2 bit	03	num
vis_FAn	49450,6	RW	Folder visibility	2 bit	03	num
vis_ALr	49451	RW	Folder visibility	2 bit	03	num
vis_Lit	49451,2	RW	Folder visibility	2 bit	03	num
vis_nAd	49450,4	RW	Folder visibility	2 bit	03	num
vis_Add	49451,4	RW	Folder visibility	2 bit	03	num
vis_diS	49451,6	RW	Folder visibility	2 bit	03	num
vis_HAC	49452	RW	Folder visibility	2 bit	03	num
vis_CnF	49452,2	RW	Folder visibility	2 bit	03	num
vis_FrH	49452,4	RW	Folder visibility	2 bit	03	num
vis_FPr	49452,6	RW	Folder visibility	2 bit	03	num

9.3.10. RESOURCES Table

NOTE: ModBUS read command: 03 (0x03) and ModBUS write command: 16 (0x10)

LABEL	ADDRESS	R/W	DESCRIPTION	DATA- SIZE	RANGE	UM
Al1	337		Analogue input (display) 1	WORD	-58.0302.0	°C/°F
Al2	339		Analogue Input (display) 2	WORD	-58.0302.0	°C/°F
AI3	341		Analogue Input (display) 3	WORD	-58.0302.0	°C/°F
ValSondeReg[0]	345		Analogue input (regulation) 1	WORD	-58.0302.0	°C/°F
ValSondeReg[1]	347		Analogue input (regulation) 2	WORD	-58.0302.0	°C/°F
ValSondeReg[2]	349		Analogue input (regulation) 3	WORD	-58.0302.0	°C/°F
DI1	33130,4		Digital input 1	1 bit	01	flag
DI2	33130,3		Digital input 2	1 bit	01	flag
DI3	33130,2		Digital input 3	1 bit	01	flag
DI4	33130,1		Digital input 4	1 bit	01	flag
HA1	33085,5		Analogue input 1 high threshold exceeded	1 bit	01	flag
LA1	33085,6		Analogue input 1 low threshold exceeded	1 bit	01	flag
HA3	33085		Analogue input 3 high threshold exceeded	1 bit	01	flag
LA3	33085,3		Analogue input 3 low threshold exceeded	1 bit	01	flag
EAL	33085,4		External	1 bit	01	flag
PA	33084,7		Pressure switch	1 bit	01	flag
OPd	33085,7		Door open	1 bit	01	flag
Pan	33084,1		Man in cold room alarm	1 bit	01	flag
LPA	33084,2		Low pressure switch	1 bit	01	flag
HPA	33084,3		High pressure switch	1 bit	01	flag
E10	33084,6		Clock error alarm	1 bit	01	flag
Ad2	33160		Defrost timeout	1 bit	01	flag
Prr	33099,2		Preheat input regulator	1 bit	01	flag
E1	33085,1		Analogue input 1 error	1 bit	01	flag
E2	33085,2		Analogue input 2 error	1 bit	01	flag
ALd	33084,4		Refrigerant leak alarm	1 bit	01	flag
E3	33084,5		Analogue input 3 error	1 bit	01	flag
HACCP	33163,2		HACCP alarm	1 bit	01	flag
OnOff	33089,1		Device status	1 bit	01	flag
dEF_1	33092,4		Defrost 1	2 bit	01	flag
dEF_2	33100,2		Defrost 2	2 bit	01	flag
OSP	33089		Economy	1 bit	01	flag
AUX	33089,4		Auxiliary	1 bit	01	flag
FrameH	33101,6		Demisting heaters	1 bit	01	flag
LIGHT	33089,2		Light	1 bit	01	flag
Maintenance	33090,4		Maintenance	1 bit	01	flag

LABEL	ADDRESS	R/W	DESCRIPTION	DATA- SIZE	RANGE	UM
COMP1	33092,3		Compressor 1	1 bit	01	flag
COMP2	33099,4		Compressor 2	1 bit	01	flag
FAN_EVAP	33094,7		Evaporator fans 1	1 bit	01	flag
FAN COND	33102,7		Condenser 1 fans	1 bit	01	flag
DOOR	33096,3		Door status	1 bit	01	flag
Alarm	33097,5		Alarm status	1 bit	01	flag
Deep Cooling	33102,5		Deep Cooling	1 bit	01	flag
Pump Down	33102,4		Pump Down	1 bit	01	flag
LIGHT_ON	33057		Lights on	1 bit	01	num
LIGHT_OFF	33057,1		Light off	1 bit	01	num
OSP_ON	33057,2		Economy mode On	1 bit	01	num
OSP_OFF	33057,3		Economy mode Off	1 bit	01	num
AUX_ON	33057,4		Auxiliary output On	1 bit	01	num
AUX_OFF	33057,5		Auxiliary output Off	1 bit	01	num
ON	33057,6		Device on	1 bit	01	num
OFF	33057,7		Device off	1 bit	01	num
SILENT	33058		Alarm acknowledgement	1 bit	01	num
DEF	33058,1		Manual defrost activation	1 bit	01	num
NIGHTDAY_OFF	33058,5		Disable Night & Day function	1 bit	01	num
NIGHTDAY_ON	33058,6		Enable Night & Day function	1 bit	01	num
LOCK_KBD	33059		Keypad lock	1 bit	01	num
UNLOCK_KBD	33059,1		Unlock keypad	1 bit	01	num
RST_HACCP	33059,2		Reset HACCP alarms	1 bit	01	num
RST_PRESS	33059,3		Reset Pressure switch alarms	1 bit	01	num
FRAMEHEATER_ON	33059,4		Frame Heater regulator activation	1 bit	01	num
FRAMEHEATER_OFF	33059,5		Frame Heater regulator deactivation	1 bit	01	num
HACCP_OFF	33059,6		Disables HACCP alarm recording	1 bit	01	num
HACCP_ON	33059,7		Enable HACCP alarm recording	1 bit	01	num
DEEP_COOL	33060		Deep Cooling regulator activation	1 bit	01	num

10. ADVANCED FUNCTIONS - NIGHT AND DAY

Events and cycles can be programmed at set times during the week using the Night&Day regulator algorithm. The parameters concerned are contained in folder **nAd** / subfolders **d0...d6**, **Ed**

NOTA: do not confuse labels E0 ... E3 with probe error messages E1 ... E2...

NOTE: be careful as to how **E0 = 3** (stand-by regulator) is used. You may not have access to the device for the duration of the event set in **E2**.

10.1. DAY/NIGHT REGULATOR OPERATION

Different events for days of the week

For each day of the week, indicated by parameters/(sub-folders) d0 ... d6, you can set:

- a time for the start of the event (E1, in format HH:mm)
- the duration (E2)
- which functions to enable (**E0**) for the event
- which defrost group to enable (parameters dE1..dE8 weekdays or F1...F8 weekends/holidays) (E3).

Parameters **E0** ... **E3**, can be different for each day.

According to the time set, E1 is the start time, usually set for the Reduced set (Economy) function ("NIGHT" mode). The duration is determined by parameter E2. In this mode, parameter E0 allows you to:

- Activate the reduced set functions.
- Activate the light regulator.
- Activate the aux regulator.
- Activate the stand-by regulator.

You can also decide whether to enable defrost during weekdays (E3 = 0) and weekends/public holidays (E3 = 1).

NOTE that parameter **E3** has no effect on the daily event settings.

Daily event

Using the same parameters, E0 ... E3 in the (sub-)folder Ed, you can also program a daily event, i.e. one that runs every day. Defrosts cannot be managed with this function. Hence parameter E3 in (sub-) folder d7 is not listed.

Daily or weekly events all have the same priority.

Days of the week correspond to these parameters:

Par.	Day of week	Day #
d0	Sunday	day 1
d1	Monday	day 2
d2 d3	Tuesday	day 3
d3	Wednesday	day 4
d4	Thursday	day 5
d5	Friday	day 6
d5 d6	Saturday	day 7
d7	Daily event (Every Day)	Daily event (Every Day)

10.2. OPERATION WITH DEFROST GROUP

If E0 is not equal to 0, the meaning of weekday parameters dE1...dE8 shifts from:

Defrost group valid EVERY day (see Automatic defrost with Real Time Clock.)

to:

Defrost group applicable only to weekdays.

The weekday parameters dE1...dE8 are supplemented with the management of weekend/public holiday parameters F1...F8.

Both folders still make use of the conditions for defrost at a pre-established time.

Hence for each day d0...d6 we can determine whether:

- E3 = 0, so that defrosts run at the times set in dE1...dE8.
- E3 = 1. so that defrosts run at the times set in F1...F8.

Example

Supposing you set these time configurations:

- 3 "weekend" defrosts (when the refrigerated cabinet is not being intensively used)
 - 2 am (F1=> h02 '00)
 - o 10 am (F2=> h10 '00)
 - 6 pm (F3=> h18 '00)
- 4 defrosts on "weekdays" (or days when the refrigerated cabinet is used intensively)
 - 0 5 am (dE1=> h05 '00)
 - 11 am (dE2=> h11 '00)
 - 5 pm (dE3=> h17 '00)
 - 11 pm (dE4=> h23 '00)

if the days considered as weekends/holidays are Sunday and Monday, this means the day settings will be:

```
d0 / E3 = 1
               (Sunday = "weekend" day)
```

(Monday = "weekend" day) d1 / E3 = 1

d2 / E3 = 0(Tuesday = "weekday")

(Wednesday = "weekday") d3 / E3 = 0

(Thursday = "weekday") d4 / E3 = 0

d5 / E3 = 0(Friday = "weekday")

(Saturday = "weekday") d6 / E3 = 0

10.3. DAY/NIGHT REGULATOR DURING A BLACKOUT

- If a blackout occurs during day/night status activation (i.e. caused by a day/night event), and power is restored:
 - during this event, the instrument will return to the status implemented at the time of the blackout, before disabling the event at the programmed time.
 - If it occurs after this event but before the next day/night event, the device starts up as if it has disabled the day/ night event during which the blackout occurred.
 - If it occurs after this event but during the next day/night event, the device starts up as if it has disabled the day/ night event during which the blackout occurred, before switching to the status requested by the day/night event underway when power was restored.
- Manual events (key or digital input) have priority over the day/night status until the next day/night event (event that either disables the current status or activates the next one) if the power supply is uninterrupted.
- If a manual event inverts the status set by the day/night function within the day/night status activation period and this is followed by a blackout, and power is restored:
 - During the same day/night status activation, the controller will return to the status set by the manual event before disabling the event at the programmed time.
 - If it occurs after this event, the device starts in the status set by the manual event.
 - It if occurs after this event but during the status activation of the next day/night event, the controller switches to the status requested by the day/night event concerned before disabling the event at the programmed time.

10.4. OPENING FOLDER NAD - DAY/NIGHT

Display	description
-17.8 -18.8	Press SET for 3 seconds
<u> </u>	Folder USr appears Use the UP & DOWN keys to search for the InS folder Press and release the SET key
[Pr	Use the UP & DOWN keys to search for the nAd folder
nRd 	Press and release the SET key. Press and release the SET key to open the folder
nRd dD	The first day, d0, appears Scroll using 'UP' and 'DOWN' to access the other days d1d6 and Every Day d7 Press and release the SET key
	The first parameter E0 appears Press and release the SEt key to modify it The E0 label will blink Use the UP & DOWN keys to adjust its value
	The first parameter E0 appears Press and release the SEt key to modify it The E0 label will blink Use the UP & DOWN keys to adjust its value
	Press the ESC key several times to return to the normal display, or repeat the procedure to modify another parameter NOTE: in the case of parameter E1, the clock icon will appear. Modification takes place in the same way as the time setting procedure (see User Interface)

11. ADVANCED FUNCTIONS - HACCP

To meet the minimum requirements prescribed in HACCP regulations, there is a set of dedicated parameters. These parameters can be viewed and configured in folder:

HACCP (folder with label "HAC")

The recording of HACCP alarms can be enabled in parameter H50≠0

NOTE. SWITCH THE INSTRUMENT OFF AND ON AGAIN AFTER MODIFYING PARAMETER H50

HACCP alarm START and storing begins every time the alarms are cleared - see paragraph Deleting HACCP alarms

These parameters record and file the high and low temperature alarms for cold room probe Pb1 or display probe Pb3, as well as any instrument power failures.

In addition to alarms, these parameters also record any controller blackouts, saving the number of blackouts that have occurred since the last time the machine was stopped.

Alarms for the HACCP function are managed independently from the rest of the regulators.

Each HACCP alarm consists of a folder containing the following information:

- alarm number: up to 40 alarms can be saved: 20 for high/low temperature and 20 for power failure
- type of alarm: Ht (high temperature), Lt (low temperature) and PF (Power failure)
- time/date and duration of all alarms
- maximum or minimum temperature, with corresponding time/date, reached during the event

SLi, SHi parameters Instant HACCP alarm

When a temperature value exceeds the range defined by parameters SLi and SHi, an HACCP alarm is signalled and recorded.

This threshold indicates the limit beyond which the food concerned would deteriorate irreparably, even for brief periods of time.

SLL, SHH parameters HACCP alarm

When a temperature value exceeds the range defined by parameters SLL and SHH for a time greater than the drA parameter, an HACCP alarm is signalled and displayed

11.1. DISPLAYING HACCP ALARMS

Display	description
RLe	The red HACCP icon will remain permanently on to indicate an HACCP alarm has occurred Press and release the UP key
HREP	The top display will show ALr If HACP alarms have occurred the bottom display will show HACP Press and release the SET key
	To access the information contained within each AHC folder, press the 'set' key
SER	The clock icon will be steadily on In fact, label StA will be shown on the top display, while the alarm start time will appear on the bottom display
	Use the DOWN key to scroll through the other alarm data
	The date icon will be steadily on
<u> </u>	In fact, label StA will be shown on the top display, while the alarm activation date will appear on the bottom display
	Use the DOWN key to scroll through the other alarm data
dLir	Label dur will be shown on the top display, while the alarm duration will appear on the bottom display In HH:mm If— appears the alarm is still active
-,	Use the DOWN key to scroll through the other alarm data
	The clock icon will be steadily on
02.06	and the maximum temperature measured by the probe during the alarm (on the top display) will be displayed along with the relative time (on the bottom display). Use the DOWN key to scroll through the other alarm data
	The clock icon will be steadily on
31.87	and the maximum temperature measured by the probe during the alarm (on the top display) will be displayed along with the relative date (bottom display.) Use the DOWN key to scroll through the other alarm data
	To return to the alarm display screen (label AHC) press the ESC key once
	Press the ESC key several times to return to the normal display



Eliwell Controls s.r.l.

Via dell'Industria, 15 • Z.I. Paludi 32016 Alpago (BL) ITALY T +39 0437 166 0000 www.eliwell.com

Technical Customer Support

T +39 0437 166 0005 E techsuppeliwell@se.com

Sales

T +39 0437 166 0060 (Italy)
T +39 0437 166 0066 (other countries)
E saleseliwell@se.com